

## Using a Modular Service Tool SD to Update the VCCX2 Controller

**NOTE:** Only service tools w/software versions 1.05 or higher may be used to update the VCCX2 Controller.

### *Step by Step Instructions*

Prior to following the instructions on how to update the VCCX2 Controller, you **MUST** update your Modular Service Tool's SD Card. To perform this update, please refer to the "Updating SD Card Screens" section of the TechSupport website which is located right after Prism 2 and USB Drivers.

Once your SD card is updated to the latest version available on our TechSupport website, follow the step by step instructions below to update the VCCX2 Controller.

**Step 1:** Connect the power cords to the Modular Service Tool SD and the VCCX2 Controller and turn both on.

**Step 2:** Connect the Modular Service Tool SD to the VCCX2 Controller via a communication cable.

**Step 3:** After initialization of the Modular Service Tool SD with the updated SD card file in it, press <2> to select the "Communications" option and configure the Service Tool for Stand Alone Mode/Hi Speed Connection by navigating the options with <NEXT> and <PREV>.

**Step 4:** Press <ENTER> to save changes.

**Step 5:** Once you are back to the first Setup Screen, press <NEXT> and at the second Setup Screen press <4> to select "Update Software."

**Step 6:** On the "Select Communication Type", press <1> to select "Wattmaster Comm" as we are utilizing the WattMaster communication cable to talk to the controller. If we were using an E-BUS cable, we would select EBUS Comm instead.

**Step 7:** Enter the VCCX2 Controller's address and then press <ENTER> twice. **NOTE:** To find the controller's address, from the VCCX2 Controller's LED display, press <MENU> once and then <ENTER>.

**Step 8:** The Software Version Screen will appear. Enter <0> if you want the latest software version available on the SD Card. Or if you have requested an older version, enter the three digit version number (X.XX).

**Step 9:** After entering the version number, press <ENTER> twice. **NOTE:** If the VCCX2 Controller already has the latest software version that is available on the SD card, the screen will display "Software Up To Date".

**Step 10:** The screen should display, "Resetting Unit." It will then show "File W441Bxxx.hex" on the first line and "Erasing Flash Memory" on the second line.

**Step 11:** When the downloading is occurring, the screen will show the following:

Line 1 shows: File W441Bxxx.hex

Line 2 shows: Flash Memory Erased

Line 3 shows: Numbers incrementing showing download is in process.

**Step 12:** Once the download process is complete, the screen will display, "Finish download" on the fourth line.

**NOTE:** If the Service Tool displays, "Cannot Find File", your SD Card was not properly updated. Go back to the TechSupport website to perform the SD Card update again.