




RSMVQ2R Technical Guide



RSMVQ2R REVISION LOG

REVISION & DATE	CHANGE
Rev. A March 28, 2021	Original
Rev. B August 18, 2021	Formatting and style guide updates

RSMVQ2R PARTS REFERENCE

PART DESCRIPTION	PART NUMBER
RSMVQ2R	ASM02652
VCCX2 Controller	ASM01698
Prism 2	ASM02533
IP Module Kit	ASM01902
CommLink 5	ASM01874
E-BUS Cable Assembly E-BUS Power & Comm 1.5 Ft, 3 Ft, 10 Ft, 25 Ft, 50 Ft, 75 Ft, 100 Ft, 150 Ft, 250 Ft, and 1000 Foot Spool	G029440 (1.5 Ft), G012870 (3 Ft), G029460 (10 Ft), G045270 (25 Ft), G029510 (50 Ft), G029530 (75 Ft), G029450 (100 Ft), G029470 (150 Ft), V36590 (250 Ft), G018870 (SPOOL)
Modular Service Tool SD - Operator Interface	ASM01895



www.aaon.com

**All manuals are also available for download from
www.aaon.com/controlsmanuals.**

AAON
2425 South Yukon Ave.
Tulsa, OK 74107-2728
www.aaon.com
Factory Technical Support Phone: 918-382-6450
AAON® Controls Support: 866-918-1100
It is the intent of AAON® to provide accurate and current product information. However, in the interest of product improvement, AAON® reserves the right to change pricing, specifications, and/or design of its product without notice, obligation, or liability.

AAON® P/N: G068360, Rev B
Copyright August 2021 AAON, Inc.
AAON® is a registered trademark of AAON, Inc., Tulsa, OK.
Copeland Digital Scroll™ is a registered trademark of Copeland Corporation, Sidney, OH
Danfoss VFD® is a registered trademark of Danfoss Commercial Compressors, S.A., Tallahassee, FL
DMQ® is a registered trademark of DunAn Microstaq, Inc. of Austin, TX.

OVERVIEW 5
RSMVQ2R Overview 5
RSMVQ2R Dimensions 6

INSTALLATION AND WIRING 7
Electrical and Environmental Requirements 7

WIRING 8
RSMVQ2R Inputs Wiring 8
RSMVQ2R Outputs Wiring 9

INPUTS AND OUTPUTS 10
RSMVQ2R Module Inputs/Outputs Map 10
RSMVQ2R Inputs and Outputs 11

SEQUENCE OF OPERATIONS 12
Cooling Mode and Dehumidification Operation 12
Envelope Protection 13
Electronic Expansion Valve Operation and Head Pressure Control 14

LCD SCREENS 15
LCD Display Screen and Navigation Keys 15
Main Screens Map 16
Module Screens 17
System Status Screens 18
Sensor Status Screens 19
Alarms Screens 20
Alarm History Screens 21
Setpoint Status Screens 22
Copeland™ Packaged VFD Screens 23
Danfoss VFD Screens 24
Danfoss VFD Screens 25
Copeland™ VFD Screens 26
Copeland™ VFD Screens and DMQ EXV Screens 27

TROUBLESHOOTING 28
LED Diagnostics 28
Temperature Sensor Testing 29
Head Pressure Transducer 30

APPENDIX A: SYSTEM CONFIGURATION 31
Single Condenser Per Module A 31
Two Condensers Per Module A 32
Compressor Type Selection 33
Unit Tonnage Selection and Compressor Type Specification Table 34

NOTES 35

FIGURES

Figure 1:	RSMVQ2R Dimensions	6
Figure 2:	RSMVQ2R Inputs Wiring.....	8
Figure 3:	RSMVQ2R Outputs Wiring.....	9
Figure 4:	Danfoss VZH028, VZH035, VZH044 Envelope	13
Figure 5:	Danfoss VZH052 and VZH065 Envelope	13
Figure 6:	Copeland™ ZPV0662E Envelope	13
Figure 7:	Copeland™ ZPV0962E Envelope	13
Figure 8:	LCD Display and Navigation Keys.....	15
Figure 9:	RSMVQ2R LED Locations.....	28
Figure 10:	Prism 2 - Single Condenser Module A Configuration.....	31
Figure 11:	Prism 2 - Two Condensers Module A Configuration	32
Figure 12:	RSMVQ2R Module A Compressor Type	33
Figure 13:	Miscellaneous Setpoints Screen - Copeland™ Model Selection	33
Figure 14:	Update Copeland™	33
Figure 15:	RSMVQ2R Unit Tonnage Selection.....	34

TABLES

Table 1:	RSMVQ2R Controller Electrical and Environmental Requirements.....	7
Table 2:	RSMVQ2R Inputs and Outputs	10
Table 3:	Compressor Speed/Head Pressure.....	14
Table 4:	Navigation Key Functions.....	15
Table 5:	Editing Key Functions	15
Table 6:	Temperature, Resistance, and Voltage for Type III Sensors	29
Table 7:	Head Pressure Transducer Chart	30
Table 8:	Compressor Type Specification Table	34

RSMVQ2R Features & Applications

The Refrigerant System Module (RSM) for VFD compressors with DMQ® Superheat Control and second circuit reheat (RSMVQ2R) monitors and controls two refrigeration circuits of the AAON unit. It is used in conjunction with the VCCX2 Controller. The module is designed for R410-A refrigerant.

The RSMVQ2R is for units with the following configurations:

1. Must have second circuit reheat and no reheat on the first circuit.
2. Must have one MODBUS-controlled VFD compressor on the first circuit.
3. Must have a fixed or two-step compressor on the second circuit.
4. Must have at least one DMQ Electronic Expansion Valve (EXV).

Optional configurations include:

1. A single condenser fan output signal for two circuits or one condenser fan output signal per circuit.
2. Single or dual EXVs.

In addition, the RSMVQ2R cannot be a heat pump (air-to-air or water-source) and cannot have multiple RSM modules.

The RSMVQ2R uses an E-BUS cable to connect to the VCCX2 Controller. Only one RSMVQ2R can be connected. There are two E-BUS Expansion Ports which allow connection to the VCCX2 Controller, communicating sensors, and other E-BUS modules.

The RSMVQ2R is configured using Prism 2 software.


The RSMVQ2R provides four analog inputs (AI), two binary inputs (BI), four relays (RLY), and two analog outputs (AO). See **Figures 2 and 3, pages 8 and 9**, for wiring.

The RSMVQ2R provides the following:

- Modulates the compressors or controls staging to satisfy the Suction Coil (Saturated) Temperature. The Suction Coil (Saturated) Temperature Setpoint is reset by the VCCX2 Controller to maintain the Supply Air Temperature during Cooling Mode. During Dehumidification Mode, it controls the compressors to the Suction (Saturation) Temperature Setpoint.
- Modulates the condenser fan(s) to maintain the Head Pressure Setpoint.
- Monitors the performance of the DMQ Universal Superheat Controller/Sensor (USHX) to maintain the Superheat Setpoint of each evaporator coil.
- Provides alarms and safeties for the compressor and condenser operation.
- Provides a 2 x 8 LCD character display and four buttons that allow for status of system operation, system setpoints, system configurations, sensors, alarms, and to change the module's address, if necessary.

OVERVIEW

RSMVQ2R Dimensions



NOTE: All dimensions in inches.

Figure 1: RSMVQ2R Dimensions

Electrical and Environmental Requirements

General

Correct wiring of the AAON unit controller and its modules is the most important factor in the overall success of the controller installation process. The main unit controller and modules are installed and wired at the AAON factory. Some of the following information may not apply to your installation if it was pre-wired at the factory. However, if troubleshooting of the controller or modules is required, it is a good idea to be familiar with the system wiring.

Wiring

The modules must be connected to an 18-30 VAC power source of the proper size for the calculated VA load requirements. All transformer sizing should be based on the VA ratings listed in **Table 1, this page.**

Control Device	Voltage	VA Load	Operating Temperature	Humidity (Non-Condensing)
RSMVQ2R Controller	18-30VAC	18	-22°F to 158°F -30°C to 70°C	0-95% RH
	Inputs		Resistive Inputs require 10KΩ Type 3 Thermistor	
	Outputs		24VAC Inputs provide 4.7kΩ Load Relay Outputs: 1 Amp maximum per output.	

Table 1: RSMVQ2R Controller Electrical and Environmental Requirements

NOTE: If the temperature at the controller is below -4°F (-20°C), the display refresh rate could be less responsive.

WARNING: When using a single transformer to power more than one controller or expansion module, the correct polarity must always be maintained between the boards. Failure to observe correct polarity will result in damage to the unit controller, RSMVQ2R, and any associated module.

Please carefully read and apply the following information when wiring the unit controller, RSMVQ2R, and any associated module.

1. All wiring is to be in accordance with local and national electrical codes and specifications.
2. All 24 VAC wiring must be connected so that all ground wires remain common. Failure to follow this procedure can result in damage to the controller and connected devices.
3. Minimum wire size for 24 VAC wiring should be 18-gauge.
4. Minimum wire size for all sensors should be 24-gauge. Some sensors require two-conductor wire and some require three-or four-conductor wire.
5. Minimum wire size for 24 VAC thermostat wiring should be 22-gauge.
6. Be sure that all wiring connections are properly inserted and tightened into the terminal blocks. Do not allow wire strands to stick out and touch adjoining terminals which could potentially cause a short circuit.
7. When communication wiring is to be used to interconnect AAON unit controllers together or to connect to other communication devices, all wiring must be plenum-rated, minimum 18-gauge, two-conductor, twisted pair with shield. AAON can supply communication wire that meets this specification and is color coded for the network or local loop. Please consult your AAON distributor for information. If desired, Belden #82760 or equivalent wire may also be used.
8. Before applying power to the AAON unit controller, RSMVQ2Rs, and any associated modules, be sure to recheck all wiring connections and terminations thoroughly.

Powering Up

When the controller and modules are first powered up, the POWER LED should light up and stay on continuously. If it does not light up, check to be sure that you have 24 VAC connected to the controller, that the wiring connections are tight, and that they are wired for the correct polarity. The 24 VAC power must be connected so that all ground wires remain common. If after making all these checks, the POWER LED does not light up, please contact AAON Controls Support for assistance.

WIRING

RSMVQ2R Inputs Wiring

RSMVQ2R Wiring

The RSMVQ2R uses an E-BUS cable to connect to the VCCX2 Controller. Only one RSMVQ2R can be connected. There are two E-BUS Expansion Ports which allow connection to the VCCX2 Controller, communicating sensors, and other E-BUS modules.

The RSMVQ2R uses four analog inputs, two binary inputs, four relays, and two analog outputs. See **Figure 2, this page**, for inputs wiring and **Figure 3, page 9**, for outputs wiring.

Head Pressure Control

The RSMVQ2R can monitor the Head Pressure Transducers and control condenser fans to maintain a Head Pressure Setpoint. The condenser fans will be controlled with a 0-10 VDC output signal.

Condenser and Compressor Configuration Options

Please see **pages 31-34** for condenser and compressor configuration details.

WARNING: Observe polarity! All boards must be wired with GND-to-GND and 24 VAC-to-24 VAC. Failure to observe polarity will result in damage to one or more of the boards. Expansion modules must be wired in such a way that the expansion modules and the controller are always powered together. Loss of power to the expansion module will cause the controller to become inoperative until power is restored to the expansion module.




Figure 2: RSMVQ2R Inputs Wiring

RSMVQ2R Outputs Wiring




Figure 3: RSMVQ2R Outputs Wiring

INPUTS AND OUTPUTS

RSMVQ2R Module Inputs/Outputs Map

Inputs/Outputs Map

See Table 2, this page, for the RSMVQ2R inputs and outputs.

REFRIGERATION SYSTEM MODULE FOR VFD HEAT PUMP COMPRESSORS	
Analog Inputs	
1	Head Pressure Sensor 1 (HP1)
2	Head Pressure Sensor 2 (HP2)
3	Discharge Temperature 1 (TEMP1)
4	Saturation Temperature 2 (TEMP2)
Binary Inputs	
1	Compressor Status 1 (BI1)
2	Compressor Status 2 (BI2)
Analog Outputs (0-10 VDC)	
1	Condenser Fan 1 (AO1)
2	Condenser Fan 2 (AO2)
DMQ EXV COMM Ports	
1	Expansion Valve 1 (EXV-1)
2	Expansion Valve 2 (EXV-2)
Binary Outputs (24 VAC)	
1	Compressor 2 Enable Relay (RLY1)
2	Compressor 2 High Speed Relay (RLY2)
3	Condenser 1 Enable Relay (RLY3)
4	Condenser 2 Enable Relay (RLY4)
Communication Terminals	
DUAL E-BUS	2 E-BUS Ports
MODBUS	MODBUS Communication Terminal Block

Table 2: RSMVQ2R Inputs and Outputs

RSMVQ2R Inputs & Outputs

+5 VDC Power

This output is a 5 VDC output that supplies power to the Head Pressure Transducer 1.

HP1 - Head Pressure Transducer 1

The Head Pressure Transducer is used to measure head pressure at the discharge line. This Head Pressure is used to drive Condenser Fan 1 to maintain a given Head Pressure Setpoint.

+5 VDC Power

This output is a 5 VDC output that supplies power to the Head Pressure Transducer 2.

HP2 - Head Pressure Transducer 2

The Head Pressure Transducer is used to measure head pressure at the discharge line. This Head Pressure is used to drive Condenser Fan 2 to maintain a given Head Pressure Setpoint.

TEMP1 - Discharge Temperature Sensor 1 Input

This Sensor is the Discharge Line Temperature Sensor for Circuit 1. It is the G010470 Thermistor 10K ohm strap-on pipe sensor. It is strapped to the discharge line immediately after the VFD compressor and is used as a safety against high compressor temperatures. Units with Copeland™ VFDs have the Discharge Line Temperature Sensor wired directly to the drive. Units with Danfoss VFDs will have a Discharge Line Temperature Sensor wired to TEMP 1 of the RSMVQ2R.

TEMP2 - Saturation Temperature Sensor 2 Input

This Sensor is the Suction Saturation Temperature Sensor for Circuit 2. It is the G049490 Thermistor 10K strap-on pipe sensor. It is strapped to the evaporator coil immediately after Thermal Expansion Valve (TXV) and is used to measure the suction saturation temperature of the second circuit.

BI1 - Compressor Status 1

A wet contact closure (24 VAC) on this input indicates that Compressor 1 is running. Typically, the source for this is a relay output from the VCCX2. If BI1 opens, a Compressor alarm will be generated. Compressor 1 relay needs to be configured on the VCCX2 as “A1 Compressor Run Status.”

BIN2 - Compressor Status 2

A wet contact closure (24 VAC) on this input indicates that Compressor 2 is running. Typically, the source for this is a relay output from the auxiliary contact on the compressor starter. If BI2 opens, Compressor 2 Enable relay and Compressor 2 High Speed Enable relay will de-energize and a compressor alarm will be generated.

NOTE: The binary inputs require wet contacts (24 VAC only) to recognize an active input. If you provide dry contacts, the contact closure will not be recognized.

A01 - Condenser Fan 1 VFD Signal

This is a direct acting output signal that is used to modulate the Condenser Fan 1 VFD (0-10 VDC signal) on an air cooled unit.

A02 - Condenser Fan 2 VFD Signal

This is a direct acting output signal that is used to modulate the Condenser Fan 2 VFD (0-10 VDC signal) on an air cooled unit.

EXV-1 - Electronic Expansion Valve

The EXV-1 is the communications port for EXV setpoints and status communications.

EXV-2 - Electronic Expansion Valve

The EXV-2 is the communications port for EXV setpoints and status communications.

RLY1 - Compressor 2 Enable

This relay turns on Compressor 2.

RLY2 - Compressor 2 High Speed Enable

This relay enables high speed on Compressor 2.

RLY3 - Condenser 1 Enable

This relay turns on the Condenser Fan 1.

RLY4 - Condenser 2 Enable

This relay turns on the Condenser Fan 2.

SEQUENCE OF OPERATIONS

Cooling Mode and Dehumidification Operation

Cooling Mode Operation

Cooling Mode control staging is determined by the supply air temperature. Staging is met by turning the on/off compressor on or off and the two-step compressor to low speed or high speed.

VFD compressor modulation is determined from Saturation Temperature and Supply Air Temperature. If the Supply and Saturation Temperatures are above their respective Setpoints, the compressors will modulate up. If the Supply or Saturation Temperatures are below their Setpoints, the compressors will modulate down. Envelope and/or current protections also affect the VFD compressor modulation.

Staging Up

1. If the Supply Air Temperature is above the Setpoint, Compressor 1 VFD will turn on at the manufacturer's recommended speed for one minute. Compressor 1 VFD will modulate anytime thereafter if it is running.
2. If the Supply Air Temperature is above the Setpoint plus window, and Compressor 1 VFD is at 100% of its capacity, Compressor 2 will turn on at low speed and Compressor 1 will be reset to 67% of its range (min to max). Compressor 1 VFD will modulate anytime thereafter if it is running.
3. If the Supply Air Temperature remains above the Setpoint plus window, and Compressor 1 VFD is at 100% of its capacity, Compressor 2 will be set to high speed and Compressor 1 will be reset to 67% of its range (min to max).

Staging Down

1. If the Supply Air Temperature is below the Setpoint plus window and Compressor 1 VFD is at minimum capacity, Compressor 2 will be set to low speed and Compressor 1 will be reset to 67% of its range (min to max).
2. If the Supply Air Temperature remains below the Setpoint plus window, and Compressor 1 VFD is at minimum capacity, Compressor 2 will be turned off and Compressor 1 will be reset to 67% of its range (min to max).
3. If the Supply Air Temperature continues to remain below the Setpoint plus window, and Compressor 1 VFD is at minimum capacity, Compressor 1 will be turned off.
4. If the Supply Air Temperature rises above the setpoint and Compressor 1 VFD's minimum off time has been met, Compressor 1 will be turned back on.

Dehumidification Operation

Dehumidification Mode control staging/modulation is determined by using the lowest saturation temperature from each circuit. Circuit 1 uses Superheat Controller Saturation Temperature and Circuit 2 uses the Saturation Coil Temperature Sensor (Temp 2 input) mounted after the TXV.

Staging Up

1. Staging begins when the module obtains the Reheat Valve position and Reheat Supply Air Error from the AAON unit controller. Compressor 2 will turn on at low speed.
2. If the Saturation Temperature (lowest of both circuits' readings) is above the Setpoint plus window, Compressor 1 VFD will turn on at the manufacturer's recommended speed for one minute. Compressor 1 VFD will modulate any time thereafter based on the Saturation Temperature (lowest of both circuit's readings).
3. If the Saturation Temperature of Circuit 2 is above the Setpoint plus window, Compressor 1 VFD is at 67% of its range min to max, the Reheat Valve is at 100%, and the Supply Air Temperature is below the Reheat Setpoint, Compressor 2 will be set to high speed.

Staging Down

1. If the Saturation Temperature of Circuit 2 is below the Setpoint plus window, Compressor 1 VFD is below 50% (adjustable), and the Reheat Valve is below 50%, Compressor 2 will be set to low speed.
2. If the Saturation Temperature of Circuit 1 is below the Setpoint plus window and Compressor 1 VFD is at minimum, Compressor 1 will be staged off.

Note: Compressor 2 cannot be turned off in Dehumidification Mode unless failed on alarm fault.

Envelope Protection

The minimum operating speed reference is read from the VFD and can change depending on where the compressor is operating within its envelope.

The VFD compressor is set to 67% at any stage event. Therefore, whenever a staging event occurs, the VFD compressor position will be reset to the middle point of the modulation range. This allows the compressor enough modulation time before making another staging event to try to avoid cycling between staging events.




Figure 4: Danfoss VZH028, VZH035, VZH044 Envelope




Figure 5: Danfoss VZH052 and VZH065 Envelope




Figure 6: Copeland™ ZPV0662E Envelope




Figure 7: Copeland™ ZPV0962E Envelope

SEQUENCE OF OPERATIONS

Electronic Expansion Valve Operation and Head Pressure Control

Electronic Expansion Valve (EXV) Operation

EXV operation is fully integrated into the Superheat Controller. The Superheat Controller will measure suction pressure and temperature to determine superheat and will automatically modulate the EXV to maintain the configured superheat. The RSMVQ2R will communicate with the Superheat Controller to set the desired Superheat setpoint and to retrieve operational data for display and trending purposes.

Head Pressure Control

The RSMVQ2R can monitor a head pressure transducer and control a condenser fan to maintain a Head Pressure Setpoint.

A condenser relay is commanded on when the first compressor is enabled. The condenser fan will be controlled with a 0-10 VDC output signal. When the condenser signal first activates, it maintains at 100% for 10 seconds.

In the Cooling Mode, the condenser signal will modulate to maintain the Cooling Head Pressure Setpoint. The signal can modulate between 15% and 100%. If the head pressure exceeds 550 psig, the condenser control signal will immediately go to 100% and a high head pressure alarm will be generated. The alarm will be deactivated when the head pressure drops below 540 psig.

In the Dehumidification Mode, the Condenser Output Signal controls to the Reheat Head Pressure Setpoint. High head pressure conditions produce the same effects as in the Cooling Mode.

If no Head Pressure Sensor is detected, the Condenser Output Signal will be maintained at 100%.

During condenser fan head pressure control, the head pressure setpoint will decrease when the VFD compressor speed decreases. See **Table 3, this page**.

Compressor Speed	Head Pressure Setpoint (340 default - adjustable)
25% or lower	260 psig
25 - 100%	260 - 340 psig
100%	340 psig

Table 3: Compressor Speed/Head Pressure

LCD Display Screen and Navigation Keys

LCD Display Screen & Navigation Keys

The LCD display screens and buttons allow you to view status and alarms, and enable Force Modes. See Figure 8, this page, and refer to Table 4 and Table 5, this page, for key functions.




Figure 8: LCD Display and Navigation Keys

Navigation Key	Key Function
MENU 	Use the MENU key to move through screens within Main Menu categories and return to the Main Menu while at other screens.
UP 	Use this key to adjust setpoints and change configurations.
DOWN 	Use this key to adjust setpoints and change configurations.
ENTER 	Use the ENTER key to navigate through the Main Menu Screen categories.

Table 4: Navigation Key Functions

Editing Key	Key Function
UP or DOWN 	Use the UP or DOWN key to enter Edit Mode on a user-adjustable screen. Edit Mode is indicated by the underscore appearing on the screen. NOTE: Entering Edit Mode will also adjust the value up one (UP key) or down one (DOWN key), so you may have to readjust the value.
ENTER 	Use the ENTER key to move through the digits in the screen when editing a numeric value. An extended press of the ENTER key saves your edits no matter the location of the editing cursor within the digits. Press the ENTER key to save a non-numeric value such as Hi Speed Network.
MENU 	The MENU key cancels editing when in Edit Mode. The screen you were editing will return to its original value and the underscore will disappear. A second press of the MENU key will return you to the Main Menu.

Table 5: Editing Key Functions

Main Screens Map


RSMVQ2R Main Screens Map

Refer to the following map when navigating through the LCD Main Screens. To scroll through the screens, press the <MENU> button.




Press to scroll through REFRIG MODULE screens.

Press to go to SYSTEM STATUS screens.




Press to scroll through SYSTEM STATUS screens.

Press to go to SENSOR STATUS screens.




Press to scroll through SENSOR STATUS screens.

Press to go to ALARMS screens.



Press to scroll through ALARMS screens.

Press to go to ALARM HISTORY screens.



Press to scroll through ALARM HISTORY screens.

Press to go to SETPOINT STATUS screens.



Press to scroll through SETPOINT STATUS screens.


Press to go to VFD MENU Screens.

Note: There are three separate VFD menus. The one that appears is dependent on your unit's configuration.



Press to scroll through VFD MENU Screens.

Press to go to EXV TYPE screens.



Press to scroll through EXV TYPE screens.

RSMVQ2R Module Screens

Refer to the following map when navigating through the RSMVQ2R Screens. From the RSMVQ2R MODULE Screen, press <ENTER> to scroll through the screens.

RSMVQ2R
1124vXXX



E - BUS
+#

E-BUS COMMUNICATION DIAGNOSTICS
Number of COMM packets received.



SOFTWARE
1024vXXX

SOFTWARE VERSION



ADDRESS
#

CURRENT BOARD ADDRESS



SYS TYPE
COOL ONLY

CURRENT SYSTEM TYPE
COOL ONLY, or HEAT PUMP



#OF COMP
1 or 2

OF COMPRESSORS



#OF EXVs
ISO - #

OF EXPANSION MODULES



COMP A1=
FIXED OR MOD

COMPRESSOR 1 TYPE



COMP A2=
FIXED/TWO STEP

COMPRESSOR 2 TYPE



#OF COND
1 or 2

OF CONDENSERS



TONNAGE

UNIT TONNAGE

System Status Screens

System Status Screens

Refer to the following map when navigating through the System Status Screens. From the SYSTEM STATUS Screen, press <ENTER> to scroll through the screens.

SYSTEM
STATUS



MODE

SYSTEM MODE
MIN RUN, OFF, COOLING, HEATING, DEHUM, or FORCED



COMP A1
ON/OFF or
MODULATING %

COMPRESSOR 1
ON/OFF or MODULATING %

FIXED ON/OFF: Compressor is on or off.
MODULATING %: 0-100%



COMP A2
ON/OFF or HI
SPEED/LO SPEED

COMPRESSOR 2
ON, OFF, HI SPEED, or LO SPEED

FIXED ON/OFF: Compressor is on or off.
TWO STEP: High Speed or Low Speed



COND FAN1
OFF

CONDENSER 1
COND FAN, NOT USED, or OFF

COND FAN MODULATING PERCENTAGE: 0-100%



COND FAN2
OFF

CONDENSER 2
COND FAN, NOT USED, or OFF

COND FAN MODULATING PERCENTAGE: 0-100%



EXV A1
0%

EXV VALVE POSITION
0-100%





EXV 2
0% or NOT USED

EXV VALVE 2 POSITION
0-100% or NOT USED

Sensor Status Screens

Refer to the following map when navigating through the Sensor Status Screens. From the SENSOR STATUS Screen, press <ENTER> to scroll through the screens.



Alarms Screens

Alarms Screen

If an alarm is present, the ALARM LED above the LCD display will light up red and blink. The Alarms will display and scroll automatically from the ALARMS screen when alarms are present.



NO ALARMS: This will be shown if there are no current alarms.

DMQ NOT DETECTED: This will be shown if there is no communication between the RSM and DMQ.

EBUS SLAVE (SLV) TIMEOUT: This alarm indicates that communication has been lost between the RSMVQ2R and the AAON controller. This can be the result of a bad cable, a missing cable, or the module not being configured properly.

NO SUCTION PRESSURE TRANSDUCER (SUCTION) DETECTED: This alarm indicates the Suction Pressure Transducer is not detected by the system. The system will shut down due to unsafe suction safety and will retry after five minutes.

NO HEAD PRESSURE TRANSDUCER (HEAD) DETECTED: This alarm indicates the Head Pressure Transducer is not detected by the system. This will cause the condenser to go to 100%.

COMPRESSOR (COMP) 1 FAULT: This alarm will occur if the compressor fails to run 45 seconds after the relay is activated or if the signal is lost after activation. This will cause an alarm and will shut down the compressor (relay). The system will retry after five minutes.

COMPRESSOR (COMP) 2 FAULT: This alarm will occur if the compressor fails to run 45 seconds after the relay is activated or if the signal is lost after activation. This will cause an alarm and will shut down the compressor through RLY1. The system will retry after five minutes.

HIGH HEAD PRESSURE (HP) DETECTED: This indicates a High Head Pressure Alarm condition which is activated when the Head Pressure rises above 550 psig. This will cause the condenser to go to 100%.

LOW SUCTION PRESSURE FAILURE: This alarm will occur if suction pressure stays below the Low Suction Pressure Setpoint for one minute or falls below 40 psig for five seconds. This alarm will shut down the system. The system will retry after five minutes.

LOW SUCTION PRESSURE (SP) DETECTED: This alarm will occur if suction pressure falls below the Low Suction Pressure Setpoint for 20 seconds. The system will try to protect by lowering compressor modulation percentage.

LOW SUPERHEAT 1 (SH1) DETECTED: This alarm will be activated when the Superheat is less than 4°F for two minutes during normal operation or four minutes during the first 10 minutes. The system will shut down and will retry after five minutes.

LOW SUPERHEAT 2 (SH2) DETECTED: This alarm will be activated when the Superheat is less than 4°F for two minutes during normal operation or four minutes during the first 10 minutes. The system will shut down. The system will shut down and will retry after five minutes.

COIL 1 TEMP 1 FAILURE: This alarm will occur if the Coil Temperature is not within operable range (below -32°F or above 310°F). This could be the result of a bad sensor or faulty wiring. This alarm will shut down the system. The system will reset after five minutes if the sensor is detected.

COIL 2 TEMP 2 FAILURE: This alarm will occur if the Coil Temperature is not within operable range (below -32°F or above 310°F). This could be the result of a bad sensor or faulty wiring. This alarm will shut down the system. The system will reset after five minutes if the sensor is detected.

COMP VFD FAULT: This alarm will occur if the Copeland™ VFD compressor communicates through ModBus that it has shut down due to a fault condition. The compressor module will attempt to reset the fault after five minutes if the compressor sends the signal that it is okay to reset the fault.

LOH2OTMP: Low Leaving H2O Temp .

NOH2OFLO: Proof of Water Flow.

HIGH SUPERHEAT 1 (SH1) WARNING: If Superheat 1 is above 25°F for two minutes, this alarm will appear on the module only. It will not be sent to the main controller to display on Prism 2.

HIGH SUPERHEAT 2 (SH2) WARNING: If Superheat 2 is above 25°F for two minutes, this alarm will appear on the module only. It will not be sent to the main controller to display on Prism 2.

HIGH SUPERHEAT 1 (SH1) FAILURE: If Superheat 1 is above 30°F for 10 minutes, it will turn off the compressors. It will retry after five minutes. If it fails twice in two hours, it will lock out the compressors.

HIGH SUPERHEAT 2 (SH2) FAILURE: If Superheat 2 is above 30°F for 10 minutes, it will turn off the compressors. It will retry after five minutes. If it fails twice in two hours, it will lock out the compressors.

HIGH SUPERHEAT LOCKOUT: If the module fails on High Superheat twice in two hours, it will lock out the compressors.

MODBUS TIMEOUT: Indicates there is no communication between the RSMVQ2R and Compressor VFD.

DANFOSS VFD: Indicates an alarm on the Danfoss VFD.

HI DISCH LINETEMP: If the Discharge Line Temperature is above 260°F, the compressor will back off. If the temperature doesn't drop below 260°F after one minute, the compressor will turn off. Discharge Line Temperature needs to drop below 150°F for the compressor to come back after it has been off for at least five minutes. If this occurs three times in two hours, the compressor will be locked out until the module is reset.

UNIT CFG MISMATCH: Indicates that either the wrong compressor model or unit tonnage is configured.

NOTE: The screen will display minutes for the first 60 minutes of alarm occurrence, hours for the next 72 hours of alarm occurrence, and days for the next 30 days of alarm occurrence. After 30 days, the alarm will clear. Alarm History is not stored in memory. So, if power is lost, the alarms will clear.

Alarm History Screens

The ALARM HISTORY Screen displays past alarms, if any, and how long ago the last of each type occurred. From the ALARM HISTORY Screen, press **<ENTER>** to scroll through the history screens.



The Alarm will appear on the first line and the second line will display how long ago each alarm last occurred. The alarms listed on the ALARMS screen will be abbreviated as shown below.

CL TEMP 1—Coil Temp 1 Failure
CL TEMP 2—Coil Temp 2 Failure
COMP 1 FL—Compressor 1 Not Running
COMP 2 FL—Compressor 2 Not Running
HP SENSE—No Head Pressure 1 Sensor Detected
HIGH HP—High Head Pressure Detected
LOW SP—Low Suction Pressure Detected
LOW SH1—Low Superheat 1 Detected
LOW SH2—Low Superheat 2 Detected
COMM T/O—E-BUS Slave Timeout
SP SENSE—No Suction Pressure Sensor Detected
UNSAFE SP—Unsafe Suction Pressure Detected
LOH2OTMP—Low Leaving H2O Temp
NOH2OFLO—Proof of Water Flow
HI SH1—High Superheat 1 Failure
HI SH2—High Superheat 2 Failure
MODBUS—MODBUS Not Detected
DF VFD—Danfoss VFD Not Detected
HIGH DT—High Discharge Temperature Detected
HP2 SENSE—No Head Pressure 2 Sensor Detected

Setpoint Status Screens

Setpoint Status Screens

Refer to the following map when navigating through the Setpoint Status Screens. From the SETPOINT STATUS Screen, press <ENTER> to scroll through the screens.

SETPOINT
STATUS



HEADPR 1
340 PSIG

HEAD PRESSURE SETPOINT 1
Valid range is 260-475 psig. Default is 340 psig.



HEADPR 2
340 PSIG

HEAD PRESSURE SETPOINT 2
Valid range is 260-475 PSI. Default is 340 PSIG.



SPRHT SP
15

SUPERHEAT SETPOINT SETTING
Valid range is 1-30°F. Default is 15°F.



LOW SUCT
95 PSIG

LOW SUCTION PRESSURE SETPOINT SETTING
Default is 95 psig.



COILT SP
40

COIL TEMPERATURE SETPOINT SETTING
Valid range is 35-70°F. Default is 40°F.



GLYCOL %
40

GLYCOL PERCENTAGE SETPOINT SETTING
Valid range is 35-70%. Default is 40%.
Only appears if configured as WSHP.



LOW H2O
XX.X°F

LOW H₂O SETPOINT SETTING
Automatically resets based on Glycol %.
Only appears if configured as WSHP.

Copeland™ Packaged VFD Screens

Refer to the following map when navigating through the Copeland™ Packaged VFD Screens. From the COPELAND Screen, press <ENTER> to scroll through the screens.



COPELAND™ COMPRESSOR MODEL
NOCONFIG or ZPV0662E or ZPV0962E.




CONNECTION STATUS

YES or NO. VFD is connected and communicated to the RSMVQ2R.



MB RETRY

Totals if it is missing communication packet information.




MB VALID

Totals if it receives good communication packet information.



VFD COMPRESSOR
Enabled or Disabled.



SPEED COMMAND
Commanded speed in RPM.



SPEED FEEDBACK

Speed feedback read from the VFD in RPM.




MAXIMUM RPM

Maximum speed programmed into the VFD in RPM.




ALARM CODE

Alarm code is read from the VFD.



CURRENT AMPS

Live current read from VFD in Amps.



DISCHARGE LINE TEMPERATURE

Discharge line temp read from VFD in Fahrenheit.




SOFTWARE VERSION

Software version read from VFD.

Danfoss VFD Screens


Danfoss VFD Screens

Refer to the following map when navigating through the Danfoss VFD Screens. From the Danfoss Comp Screen, press <ENTER> to scroll through the screens.




CONNECTION STATUS

YES or NO. VFD is connected and communicated to the RSMVQ2R.



MB RETRY

Totals if it is missing communication packet information.



MB VALID

Totals if it receives good communication packet information.



VFD COMPRESSOR

Displays a value read from VFD showing status and configuration information. Then it will display each bit of information separately.



COMPRESSOR COMMAND

Compressor percentage commanded to VFD.




MAXIMUM SPEED

Maximum speed programmed into the VFD in RPM.




MINIMUM SPEED NOT = 0! or CONFIRMED

Minimum speed programmed into the VFD. For proper speed command this should always say confirmed meaning it is set to zero.




ALARM CODE (eight of them)

Alarm codes are read from the VFD.



CURRENT AMPS

Live current read from VFD in Amps.



COMPRESSOR RUNNING HOURS

Compressor running hours read from VFD.






VFD RUNNING HOURS

VFD running hours read from VFD.



MODEL NUMBER

Compressor model number read from VFD.



DRIVE NUMBER

Type of Danfoss VFD - CDS803 or CDS303.

Copeland™ VFD Screens

Copeland™ VFD Screens

Refer to the following map when navigating through the Copeland™ VFD Screens. From the COPELAND VFD Screen, press **<ENTER>** to scroll through the screens.

COPELAND



ENVELOP<
2700 RPM

MINIMUM COMPRESSOR SPEED LIMIT
Minimum compressor envelope speed in rpm.



ENVELOP>
4500 RPM

MAXIMUM COMPRESSOR SPEED LIMIT
Maximum compressor envelope speed in rpm.



ENABLE
ON/OFF

COMPRESSOR ENABLED
ON, OFF or NO RESP
Compressor enable read from VFD.



SPEED
0 RPM

CURRENT SPEED OF COMPRESSOR
Compressor speed read from VFD in rpm.
When in Force Mode, speed can be adjusted from this screen by using the **<UP>** and **<DOWN>** buttons.



REG 78 thru 85
0

COPELAND™ VFD FAULT CODES 78 THROUGH 85
Used for troubleshooting faults.
See Emerson's Copeland™ manual for descriptions.



TO CLEAR
FAULT : UP

CLEAR FAULT
To clear faults at the VFD, press the **<UP>** button.
Faults will automatically clear after five minutes on their own.



MODEL#

MODEL NUMBER
Displays compressor model number that is configured into the drive.
Model number must match compressor to ensure safe speed limit and current limit operation.



I LIMIT
8.7AMPS

CURRENT LIMIT SETPOINT CONFIGURED
Current limit threshold of specified compressor model in amps.




CURRENT

CURRENT AMPS
Live current reading of compressor in amps.



Copeland™ VFD Screens and DMQ EXV Screens**VFD STAT**


Displays code for VFD status register value. Refer to the Copeland manual for more information.

**VFD SOFTWARE VERSION**


Software version read from the VFD.

DMQ EXV Screens

Refer to the following map when navigating through the DMQ EXV Screens. From the EXV TYPE Screen, press <ENTER> to scroll through the screens.

**EXV1-4****DETECTED or NODETECT**

If DMQ is detected and communicating with RSMVQ2R
(each connected DMQ will be displayed on a separate screen)

**DMQ1-4 SUCTION PRESSURE READING**

Suction Pressure reading from DMQ1 through DMQ4
(each connected DMQ will be displayed on a separate screen)



LED Diagnostics

Using RSMVQ2R LEDs To Verify Operation

The RSMVQ2R is equipped with LEDs that can be used to verify operation and perform troubleshooting. There are LEDs for communication, operation modes, and diagnostic codes. See **Figure 9, this page** for the LED locations. The LEDs associated with these inputs and outputs allow you to see what is active without using a voltmeter. The LEDs and their uses are as follows:

Diagnostic LEDs

STATUS - If the software is running, this LED should blink at a rate of one blink per second.

ALARM (on board) - If the RSMVQ2R Module does not receive communications for more than one minute, this LED will light up, the relays will turn off, and the Analog Outputs will go to 0 VDC.

ALARM (above LCD display) - This red LED will light up and stay lit when there is an alarm present. The type of alarm will display on the LCD display. The ALARM LED also blinks when the Expansion Valve is initializing at startup.

COMM - Every time the RSMVQ2R Module receives a valid E-BUS request from the VCCX2 Controller, this LED will blink on and then off, signifying that it received a valid request and responded.

POWER - This LED will light up to indicate that 24 VAC power has been applied to the controller.

Binary Input LEDs

BI1 - This green LED will light up when Compressor Status 1 contact is closed.

BI2 - This green LED will light up when Compressor Status 2 switch is closed.

BI3 - This green LED will light up when the Outside Coil Temperature switch is closed.

BI4 - This green LED will light up when the Emergency Shutdown switch is closed.

Relay LEDs

RLY1 - RLY4 - These green LEDs will light up when the relays are enabled and will stay lit as long as they are active.

RSMVQ2R Stepper Motor Valve LED

EXV-1 - This yellow LED will blink to indicate communication to the Superheat Controller. If the LED is on solid, that indicates no communication to the Superheat Controller.

EXV-2 - This yellow LED will blink to indicate communication to the Superheat Controller. If the LED is on solid, that indicates no communication to the Superheat Controller.




Figure 9: RSMVQ2R LED Locations

Coil Temperature Sensor Testing

The following **Temperature, Resistance, and Voltage for Type III Sensors** table is provided to aid in checking sensors that appear to be operating incorrectly. Many system operating problems can be traced to incorrect sensor wiring. Be sure all sensors are wired per the wiring diagrams in this manual.

If the sensors still do not appear to be operating or reading correctly, check voltage and/or resistance to confirm the sensor is operating correctly per the tables. Please follow the notes and instructions that appear after the chart when checking sensors.

Thermistor Sensor Testing Instructions

Use the resistance column to check the thermistor sensor while disconnected from the controllers (not powered).

Use the voltage column to check sensors while connected to powered controllers. Read voltage with meter set on DC volts. Place the “-” (minus) lead on GND terminal and the “+” (plus) lead on the sensor input terminal being investigated.

Temperature – Resistance – Voltage for Type III 10K Ohm Thermistor Sensors							
Temp (°F)	Temp (°C)	Resistance (Ohms)	Voltage @ Input (VDC)	Temp (°F)	Temp (°C)	Resistance (Ohms)	Voltage @ Input (VDC)
-10	-23.3	93333	4.51	72	22.2	11136	2.635
-5	-20.6	80531	4.45	73	22.8	10878	2.605
0	-17.8	69822	4.37	74	23.3	10625	2.576
5	-15	60552	4.29	75	23.9	10398	2.549
10	-12.2	52500	4.2	76	24.4	10158	2.52
15	-9.4	45902	4.1	77	25	10000	2.5
20	-6.6	40147	4.002	78	25.6	9711	2.464
25	-3.9	35165	3.891	80	26.7	9302	2.41
30	-1.1	30805	3.773	82	27.8	8893	2.354
35	1.7	27140	3.651	84	28.9	8514	2.3
40	4.4	23874	3.522	86	30	8153	2.246
45	7.2	21094	3.39	88	31.1	7805	2.192
50	10	18655	3.252	90	32.2	7472	2.139
52	11.1	17799	3.199	95	35	6716	2.009
54	12.2	16956	3.143	100	37.8	6047	1.884
56	13.3	16164	3.087	105	40.6	5453	1.765
58	14.4	15385	3.029	110	43.3	4923	1.65
60	15.6	14681	2.972	115	46.1	4449	1.54
62	16.7	14014	2.916	120	48.9	4030	1.436
64	17.8	13382	2.861	125	51.7	3656	1.339
66	18.9	12758	2.802	130	54.4	3317	1.246
68	20	12191	2.746	135	57.2	3015	1.159
69	20.6	11906	2.717	140	60	2743	1.077
70	21.1	11652	2.691	145	62.7	2502	1.001
71	21.7	11379	2.661	150	65.6	2288	0.931

Note: If the voltage is above 4.88 VDC the sensor or wiring is “open.” If the voltage is less than 0.05 VDC, the sensor or wiring is shorted.

Table 6: Temperature, Resistance, and Voltage for Type III Sensors

TROUBLESHOOTING

Head Pressure Transducer

If you suspect there is a problem related to the head pressure transducer, measurements can be taken at the HP terminal. See **Table 7**, this page.


Head Pressure Transducer Chart			
Voltage	Pressure	Voltage	Pressure
0.5	0	2.6	350
0.6	17	2.7	367
0.7	33	2.8	384
0.8	50	2.9	400
0.9	67	3.0	417
1.0	83	3.1	434
1.1	100	3.2	450
1.2	117	3.3	467
1.3	133	3.4	484
1.4	150	3.5	500
1.5	167	3.6	517
1.6	183	3.7	534
1.7	200	3.8	550
1.8	217	3.9	567
1.9	233	4.0	584
2.0	250	4.1	600
2.1	267	4.2	617
2.2	283	4.3	634
2.3	300	4.4	650
2.4	317	4.5	667
2.5	334		

Table 7: Head Pressure Transducer Chart

Single Condenser Per Module A

In Single Condenser Per Module wiring configuration, the Condenser Signal is wired to AO1 and RLY3 is enabled. Refer to the figures below for Prism 2 configuration and Modular Service Tool Screen selection.

RSMVQ2R Condenser Options Configuration Screen



Select the “1 Cond per RSMV” option on the above handheld Modular Service Tool screen.




Figure 10: Prism 2 - Single Condenser Module A Configuration

APPENDIX A: SYSTEM CONFIGURATION

Two Condensers Per Module A

Two Condensers Per Module A

In Two Condensers Per Module wiring configuration, the Condenser Signals are wired to AO1, AO2, RLY3, and RLY4.

Refer to the figures below for Prism 2 configuration and Modular Service Tool Screen selection.

RSMVQ2R Condenser Options Configuration Screen

RSM#1 CONFIGURATION
Condenser Options
2 Cond per RSMV
USE < or > TO CHANGE

Select the “2 Cond per RSMV” option on the above handheld Modular Service Tool screen.

The screenshot displays the 'RSM-V Configurations' screen. It features a table with columns A, B, C, and D, each containing a checkbox. To the right of the table are labels and default values for each option. A yellow box highlights the 'Condenser Configurations' section on the right, which includes radio button options for condenser counts per module. Below this is the 'RSMV-Q Tonnage Selection' section with a text input field set to '0 Tons' and a label 'Compressor Tonnage Rating'.

A	B	C	D
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Single Compressor { Default = Dual }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Fixed Compressors { Default = First is Modulating }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Copeland VFD Compressor { Default = Bitzer VFD Compressor }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Single Condenser Coil EXV { Default = Dual - Heat Pump Only }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Single Evaporator Coil EXV { Default = Dual }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Single Compressor Startup { Default = Dual }
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Emergency Shutdown Enabled
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> Active Alarm Status Enabled

Condenser Configurations

- Two Condensers Per Module
- Single Condenser Per Module
- Single Condenser Per Two Modules
- Single Condenser for Three Modules
- Single Condenser for Four Modules

RSMV-Q Tonnage Selection

0 Tons Compressor Tonnage Rating

Figure 11: Prism 2 - Two Condensers Module A Configuration

Prism 2 Compressor Type Selection

Refer to **Figure 12, this page** in setting RSMVQ2R compressor type selection.




Figure 12: RSMVQ2R Module A Compressor Type

You must select the type of compressor(s) you are using from the list below:

- Single Danfoss CDS803 VFD
- Single Danfoss CDS303 VFD
- Single Copeland™ EVxxxx Modular VFD
NOTE: You must also select the model number. See **Figure 13, this page**.
- Single Copeland™ EVCxxx Packaged VFD
NOTE: You must also select the model number. See **Figure 13, this page**.
- Compressor 1 - Single Danfoss CDS803 VFD, Compressor 2 - On/Off
- Compressor 1 - Single Danfoss CDS803 VFD, Compressor 2 - Two-Step
- Compressor 1 - Single Danfoss CDS303 VFD, Compressor 2 - On/Off
- Compressor 1 - Single Danfoss CDS303 VFD, Compressor 2 - Two-Step
- Compressor 1 - Copeland™ EVCxxx Packaged VFD, Compressor 2 - On/Off
NOTE: You must also select the model number. See **Figure 13, this page**.
- Compressor 1 - Copeland™ EVCxxx Packaged VFD, Compressor 2 - Two-Step
NOTE: You must also select the model number. See **Figure 13, this page**.

Copeland™ Compressor Model Selection

Refer to **Figure 13, this page**, in selecting Copeland™ Compressor Model.




Figure 13: Miscellaneous Setpoints Screen - Copeland™ Model Selection

After selecting the Copeland™ compressor model, you need to click the **<Update Copeland>** button and confirm that the model number is correct in the RSMVQ2R's LCD Compressor screen. If it does not appear correctly, try cycling power to the RSMVQ2R.




Figure 14: Update Copeland™

APPENDIX A: SYSTEM CONFIGURATION

Unit Tonnage Selection and Compressor Type Specification Table

Unit Tonnage Selection

You must enter the tonnage for the unit you are controlling. Please refer to **Table 8, this page**, to figure out the unit tonnage for the compressor(s) on your system. This is found on the RSMV Configuration Screen. Compressor Type Specifications

Refer to **Table 8, this page**, for compressor type unit tonnage and minimum and maximum compressor speeds.



Figure 15: RSMVQ2R Unit Tonnage Selection

COMPRESSOR TYPE SPECIFICATIONS TABLE			
Compressor Type(s)	Unit Tonnage	Minimum VFD Compressor Speed* (RPM)	Maximum VFD Compressor Speed* (RPM)
Single Danfoss CDS803 VFD	7	900	5250
Single Danfoss CDS303 VFD	8	1000	5100
Single Copeland EVxxxx Modular VFD	Determined by Compressor Model		
Single Copeland EVCxxx Packaged VFD	Determined by Compressor Model		
Compressor 1 - Danfoss CDS803 VFD Compressor 2 - On/Off	9	900	5100
	13	900	5610
Compressor 1 - Danfoss CDS803 VFD Compressor 2 - Two Step	11	900	5100
Compressor 1 - Danfoss CDS303 VFD Compressor 2 - On/Off	N/A	N/A	N/A
Compressor 1 - Danfoss CDS303 VFD Compressor 2 - Two Step	15	1000	5800
Compressor 1 - Copeland EVCxxx Packaged VFD Compressor 2 - On/Off	30	1200	4700
Compressor 1 - Copeland EVCxxx Packaged VFD Compressor 2 - Two-Step	20	1000	4900
	25	1200	5500
NOTE: *Speed limits given are before compressor envelope limits are set. See page 11 for envelope limit information.			

Table 8: Compressor Type Specification Table

RSMVQ2R Technical Guide
G068360 · Rev. B · 210818

AAON Controls Support: 866-918-1100
Monday through Friday, 7:00 AM to 5:00 PM
Central Standard Time

Controls Support website:
www.aaon.com/controlstechsupport

AAON Factory Technical Support: 918-382-6450
techsupport@aaon.com

NOTE: Before calling Technical Support, please have the model and serial number of the unit available.

PARTS: For replacement parts, please contact your local AAON Representative.



2425 South Yukon Ave • Tulsa, OK • 74107-2728
Ph: (918) 583-2266 • Fax: (918) 583-6094
AAON P/N: **G068360**, Rev. B

Created in the USA • Copyright August 2021 • All Rights Reserved