



Installation, Operation, and Maintenance Manual

2026



H3 and V3 Series

Horizontal & Vertical Indoor Air Handling Units

The information in this document is subject to change. Printed versions may not reflect the most current updates. Please ensure that you have the most recent version prior to referencing any information within the document. Visit www.aaon.com to confirm your version is up to date, or to download the most recent version.



TABLE OF CONTENTS

1. SAFETY.....	1
2. NOTES, CAUTIONS, AND WARNINGS	2
3. H3/V3 SERIES FEATURE STRING NOMENCLATURE	8
3.1. H3/V3 Series Feature String Description.....	8
4. GENERAL INFORMATION	17
4.1. Codes and Ordinances	18
4.2. Receiving Unit	18
4.3. Storage	19
4.4. Wiring Diagrams.....	19
5. INSTALLATION.....	20
5.1. Locating the Unit.....	20
5.2. Lifting and Handling the Unit.....	27
5.3. Control Box	30
5.4. Electrical	30
5.5. Duct Connection.....	34
5.6. Condensate Drain Pans.....	34
5.7. Condensate Drain Piping	34
6. STARTUP.....	36
6.1. Filters	36
6.2. Supply Fans	36
6.3. Fan Air Flow Adjustment.....	37
7. OPERATION.....	38
7.1. Refrigerant Detection System.....	38
7.2. Thermostat Operation.....	39
7.3. Split System DX Cooling Operation and Control.....	40
7.4. Chilled Water or Non-Compressorized DX Cooling Operation	40
7.5. Steam or Hot Water Preheating Operation	40
7.6. Electric Heating Operation	40
7.7. Gas Heater Operation.....	40
8. MAINTENANCE.....	41
8.1. DX Cooling.....	41
8.2. Condensate Drain Pans.....	41
8.3. Winterizing Coils.....	41
8.4. Supply Fans	41
8.5. E-Coated Coil Cleaning	41

8.6. Refrigerant Removal and Evacuation.....	43
9. OPTIONS.....	45
9.1. Heating Coils	45
9.2. Chilled Water Coil.....	45
9.3. Direct Expansion (DX) Systems.....	46
9.4. Evaporator Coil.....	47
9.5. Thermal Expansion Valve.....	47
9.6. Hot Gas Reheat.....	47
9.7. Hot Gas Bypass.....	48
9.8. Purge Circuit	48
9.9. Adjusting Refrigerant Charge.....	48
10. ENERGY RECOVERY UNITS	58
10.1. Initial Mechanical Check and Setup.....	58
10.2. Polymer Energy Recovery Wheel.....	59
10.3. Energy Recovery Wheel General Cleaning.....	65
11. GAS AND ELECTRIC HEATING	69
12. GAS HEATING	70
12.1. Unit Location and Clearances.....	70
12.2. Leak Testing.....	71
12.3. Phase and Brownout Protection Module	72
13. FILTER REPLACEMENT.....	73
14. REPLACEMENT PARTS	74
15. DECOMMISSIONING	75
16. WARRANTY.....	76
17. H3 SERIES STARTUP FORM.....	87
17.1. Pre Startup Checklist.....	87
17.2. Ambient Temperature	88
17.3. Voltage.....	88
17.4. Supply Fan Assembly.....	88
17.5. Energy Recovery Wheel Assembly	88
17.6. Dampers	88
17.7. Refrigeration System 1 - Cooling Mode	88
17.8. Refrigeration System 2 - Cooling Mode	88
17.9. Refrigeration System 3 - Cooling Mode	89
17.10. Refrigeration System 4 - Cooling Mode	89
17.11. Compressors/DX Cooling.....	89
17.12. Air-Cooled Condenser Fans	89

17.13. Refrigeration System 1 - Heating Mode (Heat Pump Only)	89
17.14. Refrigeration System 2 - Heating Mode (Heat Pump Only)	89
17.15. Refrigeration System 3 - Heating Mode (Heat Pump Only)	90
17.16. Refrigeration System 4 - Heating Mode (Heat Pump Only)	90
17.17. Water/Glycol System	90
17.18. Electric Heating.....	90
17.19. Gas Heating.....	90
17.20. A2L Mitigation Board.....	91
18. APPENDIX A: UNIT SAFETY HIERARCHY.....	92
19. APPENDIX B: MAINTENANCE LOG	93
19.1. Maintenance Log (E-Coated Coil)	94
20. LITERATURE CHANGE HISTORY	95

TABLE OF FIGURES

Figure 1: Gas Heater (81% Separated Combustion shown).....	20
Figure 2: Minimum Clearance Required for Access to Unit (H3 Series plan view).....	22
Figure 3: Minimum Clearance Required for Access to Unit (V3 Series plan view).....	22
Figure 4: Removeable Internal Control Panel.....	23
Figure 5: H3 Internal Control Panel With Top Access Panel Removed.....	23
Figure 6: V3 Internal Control Panel.....	23
Figure 7: Supply Fan Access after.....	23
Figure 8: H3 Series Platform Suspension Installation.....	25
Figure 9: H3 Series Parallel Beam Suspension Installation.....	25
Figure 10: H3 Series Unit Orientation.....	26
Figure 11: V3 Series Unit Orientation.....	26
Figure 12: H3 Schematic with (1) Mixing Box, (2) Air Handler, and (3) Final Filter	27
Figure 13: V3 Schematic with (1) Exhaust Fan, (2) Energy Recovery, (3) Air Handler.....	27
Figure 14: Low & High Voltage Quick Connect.....	28
Figure 15: Remove Access Panel	28
Figure 16: Apply Gasket	28
Figure 17: Connect Sections.....	28
Figure 18: Clamp Sections.....	28
Figure 19: Bar Clamp	29
Figure 20: Flange Overlap	29
Figure 21: Self-Tapping Screw.....	29
Figure 22: Forklift Base Assembly	29
Figure 23: Back View External Control Box.....	30
Figure 24: External Control Box Electrical Connections.....	31
Figure 25: H3 Internal Control Panel Electrical Connections	31
Figure 26: Drain Trap.....	34
Figure 27: Plenum Fan Gap Tolerances.....	37
Figure 28: A2L Sensor Location.....	39
Figure 29: Steam Distributing Piping	45
Figure 30: Hot & Chilled Water Piping.....	45
Figure 31: TXV Bulb Position	47
Figure 32: Hot Gas Purge Circuit.....	48
Figure 33: Energy Recovery Wheel.....	58
Figure 34: Lifting Hole Locations.....	58
Figure 35: Polymer Energy Recovery Wheel.....	59

Figure 36: Purge Screws	59
Figure 37: Purge Adjust	59
Figure 38: Determine Fit	60
Figure 39: Cross Section of Air Seal Structure	60
Figure 40: Avoid Racking of Cassette Frame.....	61
Figure 41: Diameter Seal Adjustment.....	61
Figure 42: Hub Seal Adjustment.....	61
Figure 43: Wheel Segment Removal Pattern	62
Figure 44: Segment Retainer	63
Figure 45: Segment Installation	63
Figure 46: Belt Replacement.....	65
Figure 47: H3 A Or B Cabinet Energy Recovery Wheel.....	67
Figure 48: H3 A Or B Cabinet Outside Air Filter Access	67
Figure 49: H3 C Cabinet Energy Recovery Wheel.....	67
Figure 53: H3 size C return air filters - access through top and left side of the filter box.....	68
Figure 54: H3 C Cabinet Outside Air Filter Access	68
Figure 55: H3 D or E Cabinet Energy Recovery Wheel	68
Figure 56: PBO.....	72
Figure 56: Unit Safety Hierarchy	92
Figure 57: A2L Priority Jumper	92
Figure 58: Building Smoke Control Priority Jumper.....	92

TABLE OF TABLES

Table 1: H3 & V3 Series Clearances (Metric)	21
Table 2: H3 & V3 Series Clearances (Imperial).....	21
Table 3: Coil Removal Clearances	22
Table 4: Nameplate Voltage Markings & Tolerances.....	30
Table 5: Control Wiring	33
Table 6: 35 KAIC Fuse Sizing	33
Table 7: 65 KAIC Fuse Sizing	33
Table 8: Drain Trap Dimensions (Imperial).....	35
Table 9: Drain Trap Dimensions (Metric).....	35
Table 10: Plenum Fan Set Screw Specifications	37
Table 11: Steam Distributing Coil Sweat Connection Sizes	45
Table 12: Hot Water Coil Sweat Connection Sizes.....	45
Table 13: Chilled Water Coil Sweat Connection Sizes.....	45
Table 14: Minimum and Maximum Coil Pressures and Temperatures	46
Table 15: Acceptable Refrigeration Circuit Values	50
Table 16: Acceptable Microchannel Air-Cooled Condenser Coil Liquid Sub-Cooling Values (Metric).....	51
Table 17: Acceptable Microchannel Air-Cooled Condenser Coil Liquid Sub-Cooling Values (Imperial)	51
Table 18: Minimum Circulation Airflow and Room Area for a Given Charge.....	53
Table 19: Minimum Circulation Airflow and Room Area for a Given Charge (continued)	54
Table 20: Minimum Circulation Airflow and Room Area for a Given Charge (continued)	55
Table 21: Minimum Airflow for Non-Ducted Applications by Box Size	55
Table 22: R-454B Refrigerant Temperature-Pressure Chart (Metric)	56
Table 23: R-454B Refrigerant Temperature-Pressure Chart (Imperial).....	57
Table 24: Energy Recovery Wheel Cleaning Information	66
Table 25: Heat Capacity Chart.....	69
Table 26: Unit Clearance Requirements.....	70
Table 27: Gas Piping Supports (Metric).....	71
Table 28: Gas Piping Supports (Imperial)	71
Table 29: H3 Series A Cabinet Unit Filters.....	77
Table 30: H3 Series B Cabinet Unit Filters.....	77
Table 31: H3 Series C Cabinet Unit Filters.....	78
Table 32: H3 Series D Cabinet Unit Filters	78
Table 33: H3 Series E Cabinet Unit Filters.....	79
Table 34: H3 Series A Cabinet Final Filters	79
Table 35: H3 Series B Cabinet Final Filters	80

Table 36: H3 Series C Cabinet Final Filters	80
Table 37: H3 Series D Cabinet Final Filters	81
Table 38: H3 Series E Cabinet Final Filters	81
Table 39: H3 Series Energy Recovery OA Filters (Feature 13 ≠ 0).....	82
Table 40: H3 Series Energy Recovery RA Filters (Feature 13 ≠ 0).....	82
Table 41: V3 Series A Cabinet Unit Filters.....	83
Table 42: V3 Series B Cabinet Unit Filters.....	83
Table 43: V3 Series C Cabinet Unit Filters.....	84
Table 44: V3 Series D Cabinet Unit Filters.....	84
Table 45: V3 Series E Cabinet Unit Filters.....	85
Table 46: V3 Series A Cabinet Final Filters	85
Table 47: V3 Series B Cabinet Final Filters	85
Table 48: V3 Series C Cabinet Final Filters	86
Table 49: V3 Series Energy Recovery OA Filters (Feature 13 = A-V)	86

1. SAFETY

Startup and service must be performed by a Factory Trained Service Technician competent in working with flammable refrigerants.

The unit is for indoor use only. See General Information section for more unit information.

The supply and return air ducts must be derived from the same space. It is recommended that ducts be provided with access panels to allow inspection for duct tightness. When a down flow duct is used with electric heat, the exhaust duct must be an L shaped duct.

For ducted applications, supply and return must be ducted directly to the space served by the unit. If plenum return is to be utilized, the return plenum must be provided with a refrigerant detection system or ventilation in accordance with ASHRAE 15 requirements.

These units must not be used for heating or cooling at any time during any phase of construction. Very low return air temperatures, harmful vapors, and misplacement of the filters will damage the unit and its efficiency.

Every unit has a unique equipment nameplate with electrical, operational, and unit clearance specifications. Always refer to the unit nameplate for specific ratings unique to the model you have purchased.

Clean duct and components upon completion of the construction setup.

When pairing with a condensing unit, ensure the refrigerant pressures for the paired system do not exceed the maximum allowable pressures listed on the unit nameplate.

Ensure that the unit is paired only with a condensing unit compatible with refrigerant marked on the nameplate.

Heatco gas-fired duct furnace cabinets are paired with AAON air handling units. The use of these cabinets must comply with all installation, operating, and maintenance requirements as detailed in the Heatco duct furnace's IOM. Refer to cabinet literature as additional considerations may need to be made. This literature is provided in the Heatco cabinet.

"The H3 & V3 is a PARTIAL UNIT AIR CONDITIONER, complying with PARTIAL UNIT requirements of UL 60335-2-40, and must only be connected to other units that have been confirmed as complying to corresponding PARTIAL UNIT requirements of UL 60335-2-40/ CSA C22.2 No. 60335-2-40, or UL 1995/ CSA C22.2 No 236.

READ THE ENTIRE INSTALLATION, OPERATION AND MAINTENANCE MANUAL. OTHER IMPORTANT SAFETY PRECAUTIONS ARE PROVIDED THROUGHOUT THIS MANUAL.

Keep this manual and all literature safeguarded near or on the unit.

2. NOTES, CAUTIONS, AND WARNINGS

Attention Must be paid to the following statements

Note: Notes are intended to clarify the unit installation, operation, and maintenance.



 WARNING	 WARNING
<u>Qualified Installer</u> Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Startup and service must be performed by a Factory Trained Service Technician competent in working with flammable refrigerants. A copy of this IOM must be kept with the unit.	<u>For Your Safety</u> Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
 WARNING	 WARNING
If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.	Electric shock hazard. Before servicing, disconnect all electrical power to the unit, including remote disconnects, to avoid shock hazard or injury from rotating parts. Follow proper Lockout-Tagout procedures.
 WARNING	 WARNING
<u>Electric Shock, Fire Or Explosion Hazard</u> Failure to follow safety warnings exactly could result in dangerous operation, serious injury, death or property damage. Improper servicing could result in dangerous operation, serious injury, death or property damage. Installation and service must be performed by a qualified technician, service agency or the gas supplier. <ul style="list-style-type: none">• Before servicing, disconnect all electrical power to the unit. More than one disconnect may be provided.• When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.• Verify proper operation after servicing. Secure all doors with key-lock or nut and bolt.	<u>Fire, Explosion Or Carbon Monoxide Poisoning Hazard</u> Failure to replace proper controls could result in fire, explosion or carbon monoxide poisoning. Failure to follow safety warnings exactly could result in serious injury, death or property damage. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this appliance.
	 CAUTION
	Unit power supply wire must be only copper or aluminum.

**WARNING****Grounding Required**

All field installed wiring must be completed by qualified personnel. Field installed wiring must comply with NEC/CEC, local and state electrical code requirements. Failure to follow code requirements could result in serious injury or death. Provide proper unit ground in accordance with these code requirements.

**WARNING**

During installation, testing, servicing and troubleshooting of the equipment it may be necessary to work with live electrical components. Only a qualified licensed electrician or individual properly trained in handling live electrical components shall perform these tasks.

Standard NFPA-70E, an OSHA regulation requiring an Arc Flash Boundary to be field established and marked for identification of where appropriate Personal Protective Equipment (PPE) be worn, must be followed.

**WARNING****Unit Handling**

To prevent injury or death lifting equipment capacity shall exceed unit weight by an adequate safety factor. Always test-lift unit not more than 61 centimeters (24 inches) high to verify proper center of gravity lift point to avoid unit damage, injury or death.

**WARNING****Rotating Components**

Unit contains fans with moving parts that can cause serious injury. Do not open door containing fans until the power to the unit has been disconnected and fan wheel has

**CAUTION**

Failure to properly drain and vent coils when not in use during freezing temperature may result in coil and equipment damage.

**CAUTION**

Rotation must be checked on all MOTORS of 3 phase units at startup by a qualified service technician. Fan motor rotation must be checked for proper operation. Alterations must only be made at the unit power connection.

**WARNING**

Do not use oxygen, acetylene or air in place of refrigerant and dry nitrogen for leak testing. A violent explosion may result causing injury or death.

**WARNING**

Some chemical coil cleaning compounds are caustic or toxic. Use these substances only in accordance with the manufacturer's usage instructions. Failure to follow instructions may result in equipment damage, injury or death.

 WARNING <p><u>Water Pressure</u></p> <p>Prior to connection of condensing water supply, verify water pressure is less than maximum pressure shown on unit nameplate. To prevent injury or death due to instantaneous release of high pressure water, relief valves must be field supplied on system water piping.</p>	 CAUTION <p>Do not clean DX refrigerant coils with hot water or steam. The use of hot water or steam on refrigerant coils will cause high pressure inside the coil tubing and damage to the coil.</p>
 WARNING <p>Always use a pressure regulator, valves and gauges to control incoming pressures when pressure testing a system. Excessive pressure may cause line ruptures, equipment damage or an explosion which may result in injury or death.</p>	 CAUTION <p>Door compartments containing hazardous voltage or rotating parts are equipped with door latches to allow locks. Door latch are shipped with nut and bolts requiring tool access. If you do not replace the shipping hardware with a pad lock always re-install the nut & bolt after closing the door.</p>
 CAUTION <p>To prevent damage to the unit, do not use acidic chemical coil cleaners. Do not use alkaline chemical coil cleaners with a pH value greater than 8.5, after mixing, without first using an aluminum corrosion inhibitor in the cleaning solution.</p>	 WARNING <p>Do not work in a closed area where refrigerant or nitrogen gases may be leaking. A sufficient quantity of vapors may be present and cause injury or death.</p>
 WARNING <p>Connected ductwork must be free of potential ignition sources, such as hot surfaces above 700 °C (1292 °F) or electrical devices prone to arcing or sparking. Potential ignition sources within the ductwork may only be allowed if the minimum air velocity across these components is above 1 m/s (200 ft/min) during any point which the component can function.</p>	 WARNING <p>Minimum circulation airflow is required to prevent stagnation of refrigerant in the event of a refrigerant leak. Zone dampers and VAV boxes must be operated to allow for minimum circulation airflow in the event of a refrigerant leak.</p>
 WARNING <p>This appliance contains a flammable refrigerant. Minimum floor area on nameplate is based on factory charge at a ceiling/release height of 2.2 m (7.2 ft) in accordance with UL 60335-2-40. Refer to Table 18, Table 19, and Table 20 for different allowable room areas based on other charges and ceiling/release heights. Apply altitude adjustment factor to table values as required by local codes.</p>	 WARNING <p>Do not use torch or other potential ignition source to detect refrigerant leaks. Use only electronic detector suitable for the refrigerant, or bubble method with chlorine free detergent.</p>

**WARNING**

If refrigerant leak is detected, remove/extinguish all sources of open flame. If repairing refrigerant leak requires brazing, remove all refrigerant before beginning brazing.

**WARNING**

If this appliance is installed to serve a conditioned area less than the minimum area as indicated in Table 18, Table 19 and Table 20, the served space must be free of continuously operating open flames or other sources of ignition. Additional ventilation is required in accordance with ASHRAE 15.

**WARNING**

Refrigerant Detection System activated circulation airflow. In the event of refrigerant leak within airstream, indoor blower is activated to provide circulation airflow. Mitigation board provided with alarm output. Wire all zone dampers and VAV boxes to alarm output to open in the event of a refrigerant leak alarm.

**WARNING**

Only auxiliary devices approved by manufacturer or declared suitable with the refrigerant may be installed in ductwork.

**WARNING**

Flammable refrigerant. Be aware that refrigerant does not contain an odor.

**WARNING**

Never attempt to open an access door or remove a panel while the unit is running. Pressure in the unit can cause excessive force against the panel.

**WARNING**

This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children must be supervised to ensure they do not play with this appliance.

**WARNING**

Do not weld or cut foam panel with plasma cutters or a cutting torch - When burnt the foam produces dangerous fumes.

**WARNING**

Ensure that sufficient dampers will be open to provide air path before fan is allowed to run.

**CAUTION**

In order to avoid a hazard due to inadvertent resetting of the THERMAL CUT-OUT, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

 CAUTION	 WARNING
PVC (Polyvinyl Chloride) and CPVC (Chlorinated Polyvinyl Chloride) are vulnerable to attack by certain chemicals. Polyolester (POE) oils used with R-454B and other refrigerants, even in trace amounts, in a PVC or CPVC piping system will result in stress cracking of the piping and fittings and complete piping system failure.	Ensure that there are no live electrical components or wiring exposed when adjusting charge, recovering charge, or purging the system. Ensure that earthing continuity is unbroken.
 WARNING	 WARNING
Flammable refrigerant. Do not pierce or burn tubing or refrigerant containing components.	Do not use means to accelerate the defrosting process or to clean, other than those recommended in this manual.
 WARNING	 CAUTION
Units with VFD driven motors/compressors have adjustable overload settings. These are set by the AAON factory for the protection of these motors/compressors and must not be adjusted over this factory setpoint or bypassed.	Field installed pipework must be protected from physical damage in operation and service. All joints must be accessibly for inspection in accordance with applicable local codes. In the absence of local codes, install in accordance with ASHRAE 15, ASHRAE 15.2, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. Do not install any field made joints within conditioned airstream.
 WARNING	 WARNING
The appliance shall be stored in a room without continuously operating ignition sources (i.e. open flames, an operating gas appliances or operating electric heater).	If any damage or fault to electrical equipment exists, do not provide power to unit. If the issue can not be resolved immediately, report issue to equipment owner to ensure power is not supplied before issue is resolved.
 CAUTION	 WARNING
If an electrical component requires changing, verify specifications and intended application match the component to be replaced, including sealed or intrinsically safe specifications. Damaged sealed or intrinsically safe components must be replaced. Electrical components must be free from producing arcs or sparks. The maintenance guidelines in this manual must always be followed. If in doubt, contact Factory Technical Support.	The appliance shall be stored in a room without continuously operating ignition sources (i.e. open flames, an operating gas appliances or operating electric heater).

3. H3/V3 SERIES FEATURE STRING NOMENCLATURE

The following is an example of the H3/V3 Series Feature String

H3-ARB-3-0-161D-41F:AABC-HGA-000-0A0-D0A00CA00BAP0B0000

3.1. H3/V3 Series Feature String Description

3.1.1. H3/V3 Model Options Breakdown

GEN	SIZE	ORENT	MJREV	VLT	CORR
H3	- A	R	B	- 3	- 0
- 161D-41F:AABC-HGA-000-0A0-D0A00CA00BAP0B0000					

Series and Generation

H3 = Horizontal - Back Intake, Front Discharge

V3 = Vertical - Back Intake, Top Discharge

Unit Size

A = Up to 1,200 cfm

B = Up to 2,000 cfm

C = Up to 4,000 cfm

D = Up to 6,000 cfm

E = Up to 10,000 cfm

Unit Orientation

R = Right-Hand Connections

L = Left-Hand Connections

Revision

B = Second Revision

Voltage

1 = 230V/1Φ/60Hz

2 = 230V/3Φ/60Hz

3 = 460V/3Φ/60Hz

4 = 575V/3Φ/60Hz

8 = 208V/3Φ/60Hz

9 = 208V/1Φ/60Hz

Corrosion Protection

0 = None

A = Interior Corrosion Protection

3.1.2. H3/V3 Model Options Breakdown

	A1	A2	A3	A4	
H3-ARB-3-0	-	1	6	1	D - 41F:AABC-HGA-000-0A0-D0A00CA00BAP0B0000

A1: Cooling Type

0 = No Cooling
2 = Chilled Water Cooling
4 = R-454B DX Cooling

A2: Cooling Rows

0 = No Cooling
4 = 4 Row Coil
6 = 6 Row Coil
8 = 8 Row Coil

A3: Cooling Stages

0 = No Cooling
1 = Single Circuit
2 = Two Circuits - Interlaced Coil
D = Double Serpentine
F = Single Serpentine
H = Half Serpentine
Q = Quarter Serpentine

A4: Cooling FPI

0 = No Cooling
A = 10 fpi
B = 8 fpi
C = 12 fpi
D = 14 fpi

3.1.3. H3/V3 Model Options Breakdown

B1 B2 B3

H3-ARB-3-0-161D - 4 1 F : AABC-HGA-000-0A0-D0A00CA00BAP0B0000

B1: Heating Type

0 = No Heating
1 = Hot Water
4 = Steam Distributing
6 = Hot Water (Reheat position)
7 = Electric Heat (UL 60335-2-40 Compliant)
J = HeatBoost Open Combustion Natural Gas Heat
K = HeatBoost Separated Combustion Natural Gas Heat
L = HeatBoost Open Combustion LP Gas Heat
M = HeatBoost Separated Combustion LP Gas Heat
N = HeatBoost Open Combustion Natural Gas Heat - High Altitude
P = HeatBoost Separated Combustion Natural Gas Heat - High Altitude
Q = HeatBoost Open Combustion LP Gas Heat - High Altitude
R = HeatBoost Separated Combustion LP Gas Heat - High Altitude

B2: Heating Designation

0 = No Heating
1 = 1 Row Coil
2 = 2 Row Coil
4 = 4 Row Coil
A = 7 kW (5.3 kW @ 208V)
B = 14 kW (10.5 kW @ 208V)
C = 21 kW (15.8 kW @ 208V) Or 50 MBH input
D = 28 kW (21.0 kW @ 208V)
E = 35 kW (26.3 kW @ 208V)
F = 42 kW (31.5 kW @ 208V)
G = 49 kW (37.0 kW @ 208V) Or 90 MBH input
H = 56 kW (42.0 kW @ 208V) Or 100 MBH input

B2: Heating Designation (Continued)

J = 63 kW (47.3 kW @ 208V) Or 125 MBH input
K = 70 kW (52.5 kW @ 208V) Or 135 MBH input
L = 150 MBH input
M = 84 kW (63.0 kW @ 208V) Or 180MBH input
N = 225MBH input
P = 200 MBH input
Q = 250 MBH input

B3: Heating Stages

0 = No Heating
1 = 1 Stage
2 = 2 Stage
3 = 3 Stage
4 = 4 Stage
5 = 5 Stage
6 = 6 Stage
A = Modulating 3:1 93% Efficient
B = Modulating 5:1 93% Efficient
C = Modulating 3:1 81% Efficient
D = Modulating 5:1 81% Efficient
F = Single Serpentine 12 fpi
H = Half Serpentine 12 fpi
K = Single Serpentine 8 fpi
L = Half Serpentine 8 fpi
M = Quarter Serpentine 8 fpi
N = Single Serpentine 10 fpi
P = Half Serpentine 10 fpi
Q = Quarter Serpentine 12 fpi
R = Quarter Serpentine 10 fpi
S = Modulating/SCR Electric

3.1.4. H3/V3 Model Options Breakdown

1A 1B 1C 1D

H3-ARB-3-0-161D-41F : A A B C - HGA-000-0A0-D0A00CA00BAP0B0000

1A: Supply Air Blower Configuration

E = 1 Blower + 1 Perm Magnet AC Totally Enclosed Motor+ 1 VFD

F = 2 Blowers + 2 Perm Magnet AC Totally Enclosed Motors + 2 VFDs

1B: Supply Air Blower Model

E = 13.5" Backward Curved Plenum, 50% Width

F = 13.5" Backward Curved Plenum, 70% Width

G = 15" Backward Curved Plenum, 70% Width

H = 22" Backward Curved Plenum, 70% Width

1 = 15" Backward Curved Plenum

2 = 15" Backward Curved Plenum, 50% Width

3 = 18.5" Backward Curved Plenum

4 = 18.5" Backward Curved Plenum, 70% Width

1C: Supply Air Blower Motor

1 = 1 hp

2 = 2 hp

3 = 3 hp

4 = 5 hp

1D: Supply Air Blower Control / Control Vendor

C = Field Installed Controls by Others

D = Field Installed Controls by Others + Isolation Relays

E = VCCX2 Orion Controls System

3.1.5. H3/V3 Model Options Breakdown

2 3 4
H3-ARB-3-0-161D-41F:AABC - H G A - 000-0A0-D0A00CA00BAP0B0000

2: Refrigeration Options

0 = Standard - None
A = Single Circuit External Hot Gas Bypass
B = Dual Circuit External Hot Gas Bypass
C = Heat Pump
D = Option B + H
F = Options C + H
H = Modulating Hot Gas Reheat
P = Option H (Circuit 1) + Option A (Circuit 2)
R = Option C + A
S = Option C + B
T = Option C + H + A
U = Option C + H + B

3: Special Controls

0 = Standard - None
A = Constant Volume Controller - CV Cool + CV Heat
C = VAV Controller - VAV Cool + CV Heat
E = Make Up Air Controller - CV Cool + CV Heat
H = DX-DOAS Controls
J = DX DOAS Controls Heat Pump

4: Additional Controls

0 = Standard - None
A = Phase and Brownout Protection
B = Return and Supply Air Firestat
C = Return Air Smoke Detector
D = Options A + B
E = Options A + C
F = Options B + C
G = Options A + B + C
H = Remote Safety Shutdown Terminals
J = Energy Recovery Wheel Rotation Detection
K = Options A + H
L = Options A + J
M = Options B + H
N = Options B + J
P = Options C + H
Q = Options C + J
R = Options H + J
S = Options A + B + H
T = Options A + B + J
U = Options A + C + H
V = Options A + C + J
W = Options A + H + J
Y = Options B + C + H
Z = Options B + C + J
1 = Options B + H + J
2 = Options C + H + J
3 = Options A + B + C + H
4 = Options A + B + C + J
5 = Options A + B + H + J
6 = Options A + C + H + J
7 = Options B + C + H + J
8 = Options A + B + C + H + J

3.1.6. H3/V3 Model Options Breakdown

	5A	5B	5C	6A	6B	6C
H3-ARB-3-0-161D-41F:AABC-HGA -	0	0	0	0	A	0 - D0A00CA00BAP0B0000

5A: Return Air Damper Position

0 = Standard - None

F = Front

L = Left Hand (Front OA Damper Required)

R = Right Hand (Front OA Damper Required)

T = Top (Front OA Damper Required)

5B: Outside Air Damper Position

0 = Standard - None

F = Front

L = Left Hand (Front RA Damper Required)

R = Right Hand (Front RA Damper Required)

T = Top (Front RA Damper Required)

5C: Mixing Box Damper Control

0 = Standard - None

A = 2 Position Actuators (24V)

B = Fully Modulating Actuators (DDC)

C = Fixed Position Dampers

D = Fully Modulating Actuator - Enthalpy Limit

E = Fully Modulating Actuator - Sensible Limit

6A: Pre Filter Box

0 = Standard - None

0 = No Unit Filters

A = 2" Pleated - MERV 8

B = 4" Pleated - MERV 8

C = 4" Pleated - MERV 11

D = 4" Pleated - MERV 13

E = 4" Pleated - MERV 14

F = 2" Pleated - MERV 8 + 4" Pleated - MERV 8

G = 2" Pleated - MERV 8 + 4" Pleated - MERV 11

H = 2" Pleated - MERV 8 + 4" Pleated - MERV 13

J = 2" Pleated - MERV 8 + 4" Pleated - MERV 14

6B: Unit Filter

0 = Standard - None

A = 2" Pleated - MERV 8

B = 4" Pleated - MERV 8

C = 4" Pleated - MERV 11

D = 4" Pleated - MERV 13

E = 4" Pleated - MERV 14

F = 2" Pleated - MERV 8 + 4" Pleated - MERV 8

G = 2" Pleated - MERV 8 + 4" Pleated - MERV 11

H = 2" Pleated - MERV 8 + 4" Pleated - MERV 13

J = 2" Pleated - MERV 8 + 4" Pleated - MERV 14

6C: Final Filter Box

0 = Standard - None

A = 2" Pleated - 30% Eff.

B = 12" Cartridge - MERV 11

C = 12" Cartridge - MERV 13

D = 12" Cartridge - MERV 14

E = 2" Pleated - MERV 8 + 12" Cartridge - MERV11

F = 2" Pleated - MERV 8 + 12" Cartridge - MERV13

G = 2" Pleated - MERV 8 + 12" Cartridge - MERV14

H = 4" Pleated - 30% Eff.

J = 4" Pleated - 65% Eff. - MERV11

K = 4" Pleated - 85% Eff. - MERV13

L = 4" Pleated - 95% Eff. - MERV14

3.1.7. H3/V3 Model Options Breakdown

	7	8	9	10	11	12
H3-ARB-3-0-161D-41F:AABC-HGA-000-0A0 - D	0	A	0	0	C	A00BAP0B0000

7: Filter Options

0 = Standard – None
 A = Magnehelic Gauge
 B = Clogged Filter Switch
 C = Options A + B
 D = Magnehelic Gauge – Unit Filter + ERW Filter
 F = Clogged Filter Switch – Unit Filter + ERW Filter
 G = Options D + F

8: Coil Coating

0 = Standard - None
 A = E-coated Cooling and Heating Coils
 D = Aluminum Finned Coils + Stainless Steel Coil Casing
 E = E-coated Cooling + Heating Coils + Stainless Steel Coil Casing

9: Expansion Valve

0 = None
 A = Thermal Expansion Valves

10: Expansion Valve Control

0 = None
 A = Standard Control

11: External Paint

0 = Standard - None
 A = AAON Gray Paint
 B = Special Paint

12: Tonnage

0 = Standard - None
 A = 2-ton Capacity
 B = 3-ton Capacity
 C = 4-ton Capacity
 D = 5-ton Capacity
 E = 6-ton Capacity
 F = 7-ton Capacity
 G = 8-ton Capacity
 U = 9-ton Capacity
 H = 10-ton Capacity
 V = 11-ton Capacity
 W = 13-ton Capacity
 J = 14-ton Capacity
 Y = 15-ton Capacity
 Z = 16-ton Capacity
 K = 17-ton Capacity
 1 = 18-ton Capacity
 2 = 20-ton Capacity
 L = 22-ton Capacity
 M = 25-ton Capacity
 3 = 26-ton Capacity
 N = 30-ton Capacity
 P = 31-ton Capacity
 Q = 34-ton Capacity
 R = 40-45-ton Capacity
 S = 50-55-ton Capacity
 4 = 60-ton Capacity
 T = 63-ton Capacity
 5 = 70-ton Capacity

3.1.8. H3/V3 Model Options Breakdown

H3-ARB-3-0-161D-41F:AABC-HGA-000-0A0-D0A00C

13	14A	14B	15	16	17
A	0	0	B	A	P

0B0000

13: Energy Recovery Type

- 0** = Standard – None
- A** = Energy Recovery Wheel – Total + High CFM, Polymer
- C** = Energy Recovery Wheel – Total + High CFM, 1% Purge, Polymer
- E** = Energy Recovery Wheel – Sensible + High CFM, Polymer
- G** = Energy Recovery Wheel – Sensible + High CFM, 1% Purge, Polymer
- J** = Energy Recovery Wheel – Total + High CFM, Aluminum
- L** = Energy Recovery Wheel – Total + High CFM, 1% Purge, Aluminum

14A: Power Options

- 0** = Standard Power Block

14B: Electrical Rating

- 0** = Standard
- J** = 10 kAIC

15: Control Panel

- 0** = Internal Control Panel
- A** = Small Control Panel - 16" x 16"
- B** = Medium Control Panel - 25" x 22"
- C** = Large Control Panel - 48" x 22"
- D** = Removable Internal Control Panel (Single Side Access)

16: Shipping Splits

- 0** = Standard – None
- A** = 1 Shipping Split (2 pallets)
- B** = 2 Shipping Splits (3 pallets)
- C** = 3 Shipping Splits (4 pallets)
- D** = 4 Shipping Splits (5 pallets)
- E** = 5 Shipping Splits (6 pallets)
- H** = Special Shipping Split (SPA Required)

17: Energy Recovery Cabinet

- 0** = Standard – None
- A** = Top RA + Back EA + Back OA Connections
- B** = Side RA + Back EA + Back OA Connections
- G** = OA + EA Dampers – Top RA + Back EA + Back OA Connections
- N** = OA + Economizer Dampers – Top RA + Back EA + Back Connections
- P** = OA + Economizer Dampers - Side RA + Back EA + Back OA Connections
- U** = OA + EA + Economizer Dampers – Top RA + Back EA + Back OA Connections

3.1.9. H3/V3 Model Options Breakdown

	18	19	20	21	22	23
H3-ARB-3-0-161D-41F:AABC-HGA-000-0A0-D0A00CA00BAP	0	B	0	0	0	0

18: Preheat

0 = Standard - None

19: Exhaust Fan

0 = Standard – None

A = 250 mm Exhaust Fan, 800 W EC Motor

B = 310 mm Exhaust Fan, 1.0 kW EC Motor

C = 310 mm Exhaust Fan, 1.7 kW EC Motor

D = 355 mm Exhaust Fan, 1.7 kW EC Motor

E = 450 mm Exhaust Fan, 3.0 kW EC Motor

F = 450 mm Exhaust Fan, 6.0 kW EC Motor

G = Dual 310 mm Exhaust Fan, 1.0 kW EC Motor

H = Dual 310 mm Exhaust Fan, 1.7 kW EC Motor

J = Dual 355 mm Exhaust Fan, 1.7 kW EC Motor

K = Dual 450 mm Exhaust Fan, 3.0 kW EC Motor

L = Dual 450 mm Exhaust Fan, 6.0 kW EC Motor

M = Option A + Piezo Ring

N = Option B + Piezo Ring

P = Option C + Piezo Ring

Q = Option D + Piezo Ring

R = Option E + Piezo Ring

S = Option F + Piezo Ring

T = Option G + Piezo Ring

U = Option H + Piezo Ring

V = Option J + Piezo Ring

W = Option K + Piezo Ring

Y = Option L + Piezo Ring

20: Crating

0 = Standard – None

A = Export Crating

B = Forkliftable Base – 5" Base

C = Options A + E

D = Options A + B

E = Shipping Shrink Wrap

F = Options B + E

G = Options A + B + E

21: Additional Controls

0 = Standard – None

D = High Condensate Level Switch

22: Warranty

0 = Standard - 1 Year Parts

A = 2 Year Parts Only Warranty (Begins at Date of Shipment)

B = 3 Year Parts Only Warranty (Begins at Date of Shipment)

C = 4 Year Parts Only Warranty (Begins at Date of Shipment)

D = 5 Year Parts Only Warranty (Begins at Date of Shipment)

23: Type

0 = Standard

X = Special Pricing Authorization

4. GENERAL INFORMATION

AAON® H3 & V3 Series indoor air handling units have been designed for indoor installation only. Units are assembled, wired, charged with dry nitrogen and run-tested at the factory. H3 & V3 Series units are not intended for residential use. Startup and service must be performed by a Factory Trained Service Technician. H3 & V3 Series units are intended for installation up to 3500 meters (11,500 ft).



WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Startup and service must be performed by a Factory Trained Service Technician. A copy of this IOM must be kept with the unit.



CAUTION

These units must not be used for heating or cooling at any time during any phase of construction. Very low return air temperatures, harmful vapors, and misplacement of the filters will damage the unit and its efficiency.



CAUTION

This equipment is protected by a standard limited warranty under the condition that initial installation, service, startup and maintenance is performed according to the instructions set forth in this manual. This manual must be read in its entirety prior to installation and before performing any service or maintenance work.

Equipment described in this manual is available with many optional accessories. If you have questions after reading this manual in its entirety, consult other factory documentation or contact your AAON Sales Representative to obtain further information before manipulating this equipment or its optional accessories.

Certification of Gas Heat Models

- a. Certified as a Category IV forced air furnace with or without cooling.
- b. Certified for indoor installation only.

Certification of Steam or Hot Water Heat Models

- a. Certified as a forced air heating system with or without cooling.
- b. Certified for indoor installation only.

Certification of Electric Heat Models

- a. Certified as an electric warm air furnace with or without cooling.
- b. Certified for indoor installation only.

Certification of Cooling Models

- a. Certified as a commercial central air conditioner with or without electrically operated compressors.
- b. Certified for indoor installation only.
- c. Certified with refrigerant R-454B coils or with chilled water-cooling coils.

4.1. Codes and Ordinances

H3 Series units have been tested and certified, by ETL, in accordance with UL Safety Standard 60335-2-40 4th Edition, ANSI Safety Standard Z21.47-2016.

H3 Series units are rated:

- IEC 60529 IPX0
- UL 60335-2-40 Class I Appliance

Size system in accordance with the American Society of Heating, Refrigeration and Air Conditioning Engineers Handbook.

Installation of H3 Series units must conform to the following codes:

- International Mechanical Code (IMC 2018 where revision not specified by State)
- Installation of Air Conditioning and Ventilating Systems Standard (NFPA 90A)
- National Electrical Code (NFPA 70)

Additional conditions for installation outside of these codes may be required for any region, state and/or city within the United States of America. It is the responsibility of the building system designer, qualified technician and person(s) responsible for the operation and maintenance of the AAON equipment to know and adhere to International and local code requirements in conjunction with the requirements of this document.



CAUTION

The Clean Air Act of 1990 bans the intentional venting of refrigerant as of July 1, 1992. Approved methods of recovery, recycling, or reclaiming must be followed.



WARNING

Coils and sheet metal surfaces present sharp edges and care must be taken when working with equipment.



Failure to observe the following instructions will result in premature failure of your system and possible voiding of the warranty.

4.2. Receiving Unit

When received, check the unit for damage that might have occurred in transit. If damage is found it must be noted on the carrier's Freight Bill. A request for inspection by carrier's agent must be made in writing at once.

Check nameplate to ensure the correct model sizes and voltages have been received to match the job requirements.

If repairs must be made to damaged goods, notify the factory before any repair action is taken in order to protect the warranty. Some alteration, repair, and manipulation of equipment without the manufacturer's consent may void the product warranty. Contact the AAON Technical Support for assistance with handling damaged goods, repairs, and freight claims: (918) 382-6450.

Note: Upon receipt, check shipment for items that ship loose such as remote sensors. Consult order and shipment documentation to identify potential loose-shipped items. Loose-shipped items may have been placed inside unit cabinet for security. Installers and owners must secure all doors with locks or nuts and bolts to prevent unauthorized access.

4.3. Storage

This equipment is not suitable for outdoor use of storage. If installation will not occur immediately following delivery, store equipment in a dry protected area away from construction traffic and in the proper orientation as marked on the packaging with all internal packaging in place. Secure all loose-shipped items. Unit must be stored in accordance with ASHRAE 15 requirements for machine rooms

4.4. Wiring Diagrams

Unit specific wiring diagrams are laminated and affixed inside the controls compartment door.

5. INSTALLATION

AAON equipment has been designed for quick and easy installation. Startup and service must be performed by Factory Trained Service Technician.

The H3 or V3 unit can either be shipped assembled or shipped in sections. See the Unit Assembly section of this document for instructions on assembling the sections.

If unit is to be installed indoors, or in areas without sufficient ventilation, provide venting from all pressure relief outlets to outdoors in accordance with ASHRAE 15 requirements.

5.1. Locating the Unit

Placement of the unit relative to ductwork, electrical and plumbing must be carefully considered. Return air plenum or duct can be mounted directly to the return air flanges. Use flexible gasket material to seal the duct to the unit.

Verify floor, foundation or suspension support can support the total unit weight, including accessory weights. Unit must be level in both horizontal axes to support the unit and reduce noise and vibration from the unit. If unit is to be installed in areas without sufficient ventilation, provide venting from all pressure relief outlets to outdoors in accordance with ASHRAE 15 requirements.

For units with supplementary electric heat installed with free air discharge, the supply air discharge opening must be located a minimum of 1.83 meters (6 feet) above the finished floor.

Separated combustion gas fired unit combustion air inlets and vent (flue) gas discharges are located in the unit roof. See Figure 1.




Figure 1: Gas Heater (81% Separated Combustion shown)

The open combustion gas fired unit has a louvered door instead of the combustion air inlet on the unit roof.

WARNING

Flue discharge vents must be located at least 120 inches away from any opening through which combustion products could enter the building.

WARNING

Distances from adjacent public walkways, adjacent buildings, operable windows and building openings, shall conform to local codes and/or the National Fuel Gas Code, ANSI Z223.1/NFPA 54, or the National Gas & Propane Code, CSA B149.1

Heatco duct-furnace Installation Requirements

All unit installations must be in accordance with the National Fuel Gas Code ANSI Z223.1 (NFPA 54) in the United States and Can/CGA-B149 Installation Code in Canada, and all other applicable local codes and ordinances. These requirements include but are not limited to:

- Furnace Location and clearances
- Circulating airflow and ductwork
- Combustion air supply to the heating equipment
- Venting of the products of combustion (flue gases)
- Gas supply, piping and connections

Refer to the provided Heatco IOM for all installation requirements.

Allow adequate space for piping access and panel removal. **To ensure proper access for field service, maintain minimum clearances for field piping and other obstructions as indicated in Table 1 and Table 2.** Consult local building codes for additional service clearance requirements.

Condensate drain connection for the coils is located on the access side of the unit. The high efficiency gas heater condensate drain connection is also located on the access side of the Heatco cabinet on an H3 unit and on the front side of the Heatco cabinet on a V3 unit. See Figure 2 and Figure 3 for unit orientation

Table 1: H3 & V3 Series Clearances (Metric)

Unit Size	Access Side Clearance ²	Opposite Access Side ^{3&4}	Top or Bottom ⁵
H3-A	0.91 meters	15.3 cm	55.9 cm
H3-B			57.2 cm
H3-C			68.6 cm
H3-D			68.6 cm
H3-E			86.4 cm

Unit Size	Access Side Clearance ²	Opposite Access Side ³	Front or Back ³
V3-A	0.91 meters	15.3 cm	15.3 cm
V3-B			
V3-C			
V3-D			
V3-E			

Table 2: H3 & V3 Series Clearances (Imperial)

Unit Size	Access Side Clearance ²	All Other Sides ^{3&4}	Top or Bottom ⁵
H3-A	36 in.	6 in.	22 in.
H3-B			22.5 in.
H3-C			27 in.
H3-D			27 in.
H3-E			34 in.

Unit Size	Access Side Clearnace ²	Opposite Access Side ³	Front or Back ³
V3-A	36 in.	6 in.	6 in.
V3-B			
V3-C			
V3-D			
V3-E			

1. Values in table apply to both combustible and non-combustible surfaces.
2. Additional clearance may be required to allow for coil removal. See Table 3
3. May be installed flush depending upon local codes. Maintain a minimum of 6 inches to combustibles for installation of Heatco duct furnace
4. Heatco duct-furnaces with back-to-back heat exchanger configuration (H3-E with 400 MBH or 360 MBH) require 36 in. for each access side. All other applicable installation considerations are also required.
5. Top or bottom clearance is 15.2 centimeters (6 inches) if no internal control panel. For units with internal control panel, the clearance in the table is needed for either top or bottom, but not both. The clearance is for supply fan removal.




Figure 2: Minimum Clearance Required for Access to Unit (H3 Series plan view)




Figure 3: Minimum Clearance Required for Access to Unit (V3 Series plan view)

Table 3: Coil Removal Clearances

Unit Size	Access Side	
H3-A	0.8 m	2.7 ft
H3-B	1.1 m	3.7 ft
H3-C	1.6 m	5.2 ft
H3-D	2.2 m	7.2 ft
H3-E	2.6 m	8.5 ft
<hr/>		
V3-A	0.8 m	2.7 ft
V3-B	0.8 m	2.7 ft
V3-C	1.1 m	3.7 ft
V3-D	1.5 m	4.8 ft
V3-E	1.5 m	4.8 ft

Internal Control Panel

H3 units with internal control panel have removable access panels on the top and bottom of the supply fan section. The supply flanges can be interchanged with the access panels, if necessary, as the openings have the same dimensions, except on size E.



Figure 4: Removeable Internal Control Panel



Figure 5: H3 Internal Control Panel With Top Access Panel Removed

V3 units with internal control panel have removable access panels on the front and back of the supply fan section. V3 units that have energy recovery only have one removable access panel on the front of the unit. The supply flanges can be interchanged with the access panels, if necessary, as the openings have the same dimensions.



Figure 6: V3 Internal Control Panel

Removable Internal Control Panel

V3 units with removable internal control panel have a removable access panel on the access side of the unit. Removing the electrical panel gives access to the supply fan. To access the supply fan, disconnect the wiring that connects from the unit to the removable control panel. Then remove the four corner bolts and use the handles to remove the electrical panel.



Figure 7: Supply Fan Access after

Floor Mounted Units

Make sure the unit is level and mounted on a field supplied platform with a minimum height to allow for proper depth of the condensate line p-trap. Other installation provisions may be necessary according to job specifications. V3 Series vertical air handling units are designed for up flow applications only.

Suspended Units

V3 Series vertical air handling units are not equipped for suspended installations.

H3 Series horizontal air handling units are equipped for suspended installations. Lift the

unit into position by supporting the unit with the skid used for shipping. The air handling unit must be installed level and care must be taken to prevent damage to the cabinet.

Other installation provisions may be necessary according to job specifications. Figure 8 and Figure 9 show factory recommended methods for suspended installations. It is the responsibility of the specifying engineer or installing contractor to ensure the installation is structurally safe and sound.




Figure 8: H3 Series Platform Suspension Installation




Figure 9: H3 Series Parallel Beam Suspension Installation




Figure 10: H3 Series Unit Orientation

Note: Access doors may be on the "left" or "right" side as designated by the unit orientation on the configurator string. "Back" will always be the same side as the pre-filter and return air opening. "Front" will always be the side opposite the pre-filter and return air opening.





Figure 11: V3 Series Unit Orientation

Note: Access doors may be on the "left" or "right" side as designated by the unit orientation on the configurator string. "Back" will always be the same side as the pre-filter and return air opening. "Front" will always be the side opposite the return air opening.

5.2. Lifting and Handling the Unit

Before lifting unit, be sure that all shipping material has been removed from unit.

Care must be taken if using spreader bars, blocking or other lifting devices to prevent damage to the cabinet, coil or fans.



Unit Assembly

Although H3 & V3 Series units are shipped factory assembled as standard, the unit may be ordered as shipping splits for certain applications such as for assembly in existing structures where modules must be manipulated separately. If the unit was ordered as shipping splits, then they must be assembled in the field.

Locate the schematic in the equipment's literature packet.

1. Identify and Situate Splits

- a. H3 Units can have the following ship split sections:
 1. Mixing Box
 2. Air Handler
 3. Final Filter
 4. Electric Heat
 5. Energy Recovery
 6. Heatco Gas Heater




Figure 12: H3 Schematic with (1) Mixing Box, (2) Air Handler, and (3) Final Filter

- b. V3 Units can have the following ship split sections:

1. Exhaust Fan
2. Energy Recovery
3. Air Handler
4. Pre Filter
5. Mixing Box
6. Heatco Gas Heater




Figure 13: V3 Schematic with (1) Exhaust Fan, (2) Energy Recovery, (3) Air Handler

2. Connect Power and Control Wiring between sections

H3 & V3 Series units are equipped with low and high voltage quick connects to connect wiring from one section to the next. It might be necessary to increase the hole size in the cabinet in order to get the quick connector through the opening. See the Electrical section for more information.



Figure 14: Low & High Voltage Quick Connect

A color-coded wiring diagram is laminated and affixed to the inside of the control compartment access door.

H3 & V3 Series units are equipped with a single point power connection. Wiring from the unit to external controls and power sources must be provided in the field.

3. Connect Sections

Remove the access side panel from the mixing box by removing the screws. It is also helpful to remove the access side panel from the air handling unit module.



Figure 15: Remove Access Panel

Apply 13 mm (1/2") thick, 16 mm (5/8") wide adhesive gasket around the edges of the box without the flanges.




Figure 16: Apply Gasket

Push the mixing box and air handling sections together so that the flange from the air handling section is inside of the mixing box.



Figure 17: Connect Sections

Use clamps to pull the sections together on the inside of the unit.



Figure 18: Clamp Sections

Use bar clamps or other non-destructive winching device to pull the tops of the modules together tightly.



Figure 19: Bar Clamp

At each of the pre-drilled holes in the flange, drill 8mm (5/16") hex head self-tapping screws to secure the two sections together. You may need a screwdriver extension to reach all of them.




Figure 20: Flange Overlap




Figure 21: Self-Tapping Screw

V3 units with a forklift base must be bolted together at the connection sections.



Figure 22: Forklift Base Assembly

4. Final Sealing

It is very important to keep air from infiltrating the unit cabinet. Seal all piping penetrations with Armaflex, Permagum or other suitable sealant. Also seal around drain connections, electrical connections and all other inlets where air may enter the cabinet. This is especially important when the unit is installed in an unconditioned area.



CAUTION

Proper sealing of the electrical and piping entries into the unit must be verified. Failure to seal the entries may result in damage to the unit and property.

5.3. Control Box

Some H3 & V3 units include an external control box that must be mounted in the field. The control box is designed with two mounting holes on the back panel. Make sure the wall fasteners can hold the weight of the control box. See Figure 23

External control boxes provided with conduit exceeding 1.8 m (6ft) in length must have conduit supported in compliance with the National Electrical Code NFPA 70. FMC and LMFC conduit must be supported within 30.5 cm (12 in.) of both the unit and the external control box and at intervals no more than 1.4 m (4.5 ft) along the length.



Figure 23: Back View External Control Box

5.4. Electrical

For units not equipped with incoming power disconnect, means for all pole disconnection must be provided in the fixed wiring in accordance with local or national electrical codes. Verify the unit nameplate agrees with power supply. Connect power and control field wiring as shown on the unit specific wiring diagram provided laminated and attached to the door in the controls compartment.

Table 4: Nameplate Voltage Markings & Tolerances

Hz	Nameplate Voltage	Nominal System Voltage	Operating Voltage Range ¹		Acceptable Performance Range ²	
			Min	Max	Min	Max
60	115	120	104	127	108	126
	208/230	208/240	187	254	187	252
	208	208	187	228	187	228
	230	240	208	254	216	252
	265	277	240	293	249	291
	460	480	416	508	432	504
	575	600	520	635	540	630
50	230	230	198	254	208	254
	400	400	344	440	360	440

Note: Operating voltage is the min and max voltage for which the unit can function. Never operate outside of this min and max voltage.

Note: The Acceptable Performance Range is the min and max voltage for which the unit performance is designed and rated to give acceptable performance.

Route power and control wiring, separately, through the utility entry in the unit. Do not run power and control signal wires in the same conduit.

**WARNING**

The foam insulation releases dangerous fumes when it is burnt. Do not cut a foam part with a cutting torch or plasma cutter. Do not weld to a foam filled part.

All units require field supplied electrical overcurrent and short circuit protection. Device must not be sized larger than the Maximum Overcurrent Protection (MOP) shown on the unit nameplate.

Codes may require a disconnect switch be within sight of the unit.

It is recommended that the field installed overcurrent protection or disconnect switch not be installed on the unit.

On units with external control box, electrical supply can enter through either side of the controls compartment.



Figure 24: External Control Box Electrical Connections

On units with internal control panel, electrical supply can enter through the supply air side (front) of the H3 unit.




Figure 25: H3 Internal Control Panel Electrical Connections

A single point connection to a terminal block is provided. High voltage conductors must enter the control panel in a separate opening and separate conduit than low voltage conductors.

Field wired disconnecting means of power, external to the unit, must be incorporated in the fixed wiring in accordance with the wiring rules and provide full disconnection of all poles under overvoltage Category III conditions.

**WARNING**

Electric shock hazard. Before attempting to perform any installation, service, or maintenance, shut off all electrical power to the unit at the disconnect switches. Unit may have multiple power supplies. Failure to disconnect power could result in dangerous operation, serious injury, death, or property damage.

To pass wires through the wall or roof of the unit, cut a hole and pass the conduit through it. Use the following procedure to cut a round hole in a foam panel.

Cutting Electrical Openings

1. Locate the placement of the hole. Be sure that the conduit will not interfere with the operation of any component or prevent access of any door or removable panel. Field cut openings must be a minimum of 15.24 centimeters (6 inches) away from all components and wiring to prevent damage due to drilling or cutting.
2. Drill a pilot hole all the way through the foam panel.
3. Using a hole saw, cut the hole through the metal on both sides of the foam part.
4. With a knife cut the foam out of the hole.
5. After the conduit is installed in the hole caulk the entire perimeter of the hole on both sides with an industrial grade silicone sealant or a duct seal compound.



CAUTION

Proper sealing of the electrical entries into the unit must be verified. Failure to seal the entries may result in damage to the unit and property.

If a larger cut-out is needed for additional duct connections not provided by the factory, it is very important that the foam be completely sealed. Fabricate insulation covers from sheet metal to cover the foam at the cut. Seal the edges and corners not covered using silicone caulking or a duct seal compound.

If a reciprocating saw is used to make the cut-out, take care that the metal skins of the foam part do not separate from the foam resulting in reduced structural integrity of the part.

Size supply conductors based on the unit Minimum Current Ampacity (MCA) rating. Supply conductors must be rated a minimum of 75°C (167°F).

Protect the branch circuit in accordance with code requirements. The unit must be electrically grounded in accordance with local codes, or in the absence of local codes, the current National Electric Code, ANSI/NFPA 70 or the current Canadian Electrical Code CSA C22.1.

Note: Units are factory wired for 208V, 230V, 460V or 575V. In some units, the 208V and 230V options may also be provided in single or three phase configurations. The transformer configuration must be checked by a qualified technician prior to startup.

Wire power leads to the unit's terminal block or main disconnect. All wiring beyond this point has been completed by AAON and cannot be modified without effecting the unit's agency/safety certification.

Supply voltage must be within the min/max range shown on the unit nameplate. Available short circuit current must not exceed the short circuit current rating (SCCR) shown on the unit nameplate.



CAUTION

Three phase voltage imbalance will cause motor overheating and premature failure.

Three phase voltage imbalance will cause motor overheating and premature failure. The maximum allowable imbalance is 2%.

Voltage imbalance is defined as 100 times the maximum deviation from the average voltage divided by the average voltage.

Example:

$(221V+230V+227V)/3 = 226V$, then $100*(226V-221V)/226V = 2.2\%$, which exceeds the allowable imbalance.

Check voltage imbalance at the unit disconnect switch and at the compressor terminal. Contact your local power company for line voltage corrections.

A qualified technician must check for proper motor rotation and check blower motor amperage listed on the motor nameplate is not exceeded.


CAUTION

Rotation must be checked on all MOTORS of three phase units. Supply fan motors must all be checked by a qualified service technician at startup and any wiring alteration must only be made at the unit power connection.

Wire control signals to the unit's low voltage terminal block located in the controls compartment.

If any factory installed wiring must be replaced, use a minimum 105°C (221°F) type AWM insulated conductors.

Thermostat Control Wiring

If a thermostat is used for unit control, locate the thermostat on an inside wall that is between 1.2 and 1.5 meters (4 - 5 feet) above the floor where it will not be subjected to drafts, sun exposure, or heat from electrical fixtures of appliances. Control wiring must deliver adequate voltage to components to assure proper operation. Control voltage returning from controller circuit must be a minimum of 21 VAC. To assure proper wiring use the following chart to determine the allowable wiring distances.

Table 5: Control Wiring

Wire Size (Standard) Copper Conductors Only	Total Wire Distance Allowable	
20 AWG	60.96 m	200 ft
18 AWG	106.7 m	350 ft
16 AWG	152.4 m	500 ft
14 AWG	228.6 m	750 ft
12 AWG	381.0 m	1250 ft

*Total Wire Distance Allowable =
(Quantity of Control Wires) x
(Control Wire Distance)*

Take the total wire distance allowable and divide by the number of wires to be connected. This indicates the distance allowable for that size wire. The wiring to the unit must not exceed the total wire distance allowable. If the voltage at the connectors is less than 21 VAC, isolation relays must be installed. If under external control 21 VAC must be field verified.

All external devices must be powered via a separate external power supply.

Example:

A total of 8 wires must be pulled 75 ft (22.9 m) to a control the unit. What size wire must be used?

According to the Table 5, 16 AWG allows for 63ft (500 ft/8 wires) and 14 AWG allows for 94ft (750 ft/8 wires). Thus, 14 AWG must be used.

Fuses and Circuit Breakers

The interrupting rating of fuses and circuit breakers is to be determined based on the KAIC rating of the unit. Refer to the wiring diagram for fuse sizing.

Table 6: 35 KAIC Fuse Sizing

35 KAIC Construction		
Component	Description	Interrupting Rating (kA)
Fuse	Class CC, 600V, 0.5A - 30A	200
Fuse	Class J, 600V, 35A - 600A	200
Disconnect	3P, 600V, 15A - 600A	35

Table 7: 65 KAIC Fuse Sizing

65 KAIC Construction		
Component	Description	Interrupting Rating (kA)
Fuse	Class CC, 600V, 0.5A - 30A	200
Fuse	Class J, 600V, 35A - 600A	200
Disconnect	3P, 600V, 15A - 600A	65

5.5. Duct Connection

Attach duct to flanges provided on the unit. The installer is responsible for sealing ducts to the flanges to prevent water leaks.



CAUTION

Ensure that wires are protected from damage and wear caused by normal operation of unit and environmental factors.

See Figure 10 and Figure 11 for return and supply air duct locations. Size the ductwork in accordance with the ASHRAE Handbook. Ductwork must be installed in accordance with NFPA Standard 90A.

When attaching duct to the unit, use a flexible/compressible material rated for duct connections. A 7.6 centimeter (3 inch) flexible connector for both return and supply duct connections is recommended.

5.6. Condensate Drain Pans

Units require field installed drain p-traps and lines to be connected to the condensate drain pans of the unit.

For condensate drain lines, the line must be the same pipe size or larger than the drain connection, include a p-trap, and pitch downward toward drain. Use an air break with long runs of condensate lines. See Installation section of this manual for more information.



CAUTION

Do not operate unit without a p-trap. Failure to install a p-trap may result in overflow of condensate water.

5.7. Condensate Drain Piping

A p-trap and drain line must be installed on the drain connection, with the p-trap not to exceed 15.3 cm (6") from the drain connection. The lines must be the same pipe size or larger than the drain connection, include a p-trap, and pitch downward toward drain. Use an air break with long runs of condensate lines.



CAUTION

Use an emergency drain pan for all applications where a risk of water damage to surrounding structure or furnishings. Refer to local codes.

Draw-through cooling coils will have a negative static pressure in the drain pan area. This will cause an un-trapped drain to back up due to air being pulled up through the condensate drain piping.

Condensate drain trapping and piping must conform to all applicable governing codes.




Figure 26: Drain Trap

Table 8: Drain Trap Dimensions (Imperial)

Draw-Through		
Drain Pan Pressure	Trap Dimensions	
Negative Static (inches of water)	X (in.)	X/2 (in.)
-0.50	1.50	0.75
-1.00	2.00	1.00
-1.50	2.50	1.25
-2.00	3.00	1.50
-2.50	3.50	1.75
-3.00	4.00	2.00
-3.50	4.50	2.25
-4.00	5.00	2.50

Table 9: Drain Trap Dimensions (Metric)

Draw-Through		
Drain Pan Pressure	Trap Dimensions	
Negative Static (mm of mercury)	X (mm)	X/2 (mm)
-0.93	38.10	19.05
-1.87	50.80	25.40
-2.80	63.50	31.75
-3.74	76.20	38.10
-4.67	88.90	44.45
-5.60	101.60	50.80
-6.54	114.30	57.15
-7.47	127.00	63.50

Note: The drain pan connection is a 24.4mm (1") MPT fitting.

The X dimension on the draw-through trap must be at least equal to the absolute value of the negative static pressure in the drain pan plus 2.54 centimeters (one inch). To calculate the static pressure at the drain pan add the pressure drops of all components upstream of the drain pan, including the cooling coil, and add the return duct static pressure. Include the dirt allowance pressure drop for the filters to account for the worst-case scenario.

The height from top of the bottom bend of the trap to the bottom of the leaving pipe must be at least equal to one half of the X dimension. This ensures that enough water is stored in the trap to prevent losing the drain seal during unit startup

Note: The absolute value of the fan inlet pressure will always be greater than or equal to the absolute value of the static pressure in the drain pan on draw-through units, so the fan inlet pressure is a safe value to use for the drain pan static pressure.

6. STARTUP

(See back of the manual for startup form)



WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Startup and service must be performed by a Factory Trained Service Technician. A copy of this IOM must be kept with the unit.



WARNING

Electric shock hazard. Shut off all electrical power to the unit to avoid shock hazard or injury from rotating parts.

During startup, it is necessary to perform routine checks on the performance of the unit. This includes checking of the air flow, the air filters and refrigerant charge.

6.1. Filters

Do not operate the unit without filters in place. Operation of the equipment without filters in place can result in clogged coils. Units are shipped with the selected filters installed. If filters have been removed during installation, open the filter access door and re-install the correct filters with the airflow indicator arrows pointing in the direction of airflow.

Check filters after a few days of operation after the unit has been started up as dust and debris from construction may cause premature filter loading. Replace the filters if necessary.

6.2. Supply Fans

H3 & V3 Series units are equipped with direct drive backward curved plenum supply fan assemblies that deliver the air volume specified according to unit size and job requirements.

6.3. Fan Air Flow Adjustment

For single set screw applications, tighten the set screw to the required torque setting

Table 10 using a calibrated torque wrench. For double set screw applications, tighten one set screw to half of the required torque setting

Table 10 using a calibrated torque wrench. Tighten the second set screw to the full required torque setting then tighten the first set screw to the full required torque setting.

Table 10: Plenum Fan Set Screw Specifications

SET SCREW DIAMETER	TORQUE (Nm [IN-LBS])
6.4 mm (1/4")	9 [80]
7.9 mm (5/16")	14.2 [126]
9.5 mm (3/8")	27.12 [240]

The gap tolerances that are allowed between the blower and the inlet cone for the plenum fan blowers are shown in Figure 27. The inlet cone can be moved as necessary to center the cone in relation to the blower. The blower can be moved on the motor shaft to set the correct overlap. These tolerances are critical to the performance of the blower.





Figure 27: Plenum Fan Gap Tolerances



CAUTION

Before completing startup and leaving the unit a complete operating cycle must be observed to verify that all components are functioning properly.

7. OPERATION

Unit operations must be controlled with the thermostat or unit controller, never at the main power supply, except for emergency or complete shutdown of the unit.

7.1. Refrigerant Detection System

Each DX unit is equipped with a Refrigerant Detection System (RDS) to detect leaked refrigerant within the conditioned airstream and in the cabinet. The RDS consists of refrigerant detection sensors in the conditioned airstream and cabinet connected to a corresponding mitigation board. In the event of a refrigerant leak, the RDS sensors will send an alarm to the mitigation board. Each A2L mitigation board is equipped with alarm output in the form of a NO/NC relay.

Applications using AAON VCC-X controls:

In the event of an airstream RDS alarm, the compressor operation is disabled and the indoor blower is enabled to provide circulation airflow in accordance with UL 60335-2-40. In the event of a Cabinet RDS alarm, compressor operation and gas heat operation is disabled. The indoor blower, and any form of heat other than gas, will resume normal operation. RDS alarm outputs are available via BACNet communication through the VCC-X controller.

For applications not using AAON VCC-X controls, mitigation board outputs will be wired to the low voltage terminal block.

In all cases, the mitigation board and VCCX-X board will remain in alarm state for five minutes after the RDS sensor has cleared the alarm below the concentration setpoint.

For VAV applications and applications utilizing zone dampers, the VAV boxes and zone dampers must be wired to the mitigation board output to open all VAV boxes and zone dampers to allow for the required circulation airflow to prevent stagnation of leaked refrigerant. Other applications requiring additional refrigerant leak mitigation measures as required by local code and ASHRAE 15 may be notified of detected refrigerant by this alarm output.

Verify functionality of RDS by removing sensor connection at the mitigation board and ensuring that all sequences above take place, including the opening of VAV boxes and zone dampers and additional mitigation procedures, if applicable. Refer to the A2L Mitigation Board Technical Guide for operation. See Figure 31 for sensor location.

Smoke control procedures may override the RDS alarm functions.



CAUTION
Refrigerant sensors may only be replaced with manufacturer approved sensors.



CAUTION
Certain applications may allow the unit to bring in unconditioned air. Freeze protection needs to be considered in the final application.




Figure 28: A2L Sensor Location



CAUTION

Additional mitigation procedures or fault conditions initiated outside of AAON controls are the responsibility of the Building Engineer and must give appropriate priority in accordance with local codes.

7.2. Thermostat Operation

Heating

- Thermostat system switch - "Heat"
- Thermostat fan switch - "Auto" or "On"
- Thermostat temperature set to desired point.

Cooling

- Thermostat system switch - "Cool"
- Thermostat fan switch - "Auto" or "On"
- Thermostat temperature set to desired point.

Air Circulation

- Thermostat system switch - "Off"
- Thermostat fan switch - "Auto" or "On"
- No change of the thermostat temperature.

With these settings, the supply blower will run continuously but the supply air will not be heated, cooled, or dehumidified.

System Off

- Thermostat system switch - "Off"
- Thermostat fan switch - "Auto"
- No change of the thermostat temperature.

With these settings the system is shut down, with the exception of control system power.

Night and Weekend Unoccupied Operation

To reduce the operating time of the unit when the space is unoccupied, such as nights and weekends, it is recommended that the temperature setting be raised about 2.8 °C (5°F) while unoccupied during the cooling season and lowered about 5.6°C (10°F) during the heating season.

7.3. Split System DX Cooling Operation and Control

When a call for cooling (G and Y1, Y2, etc.) is made the supply blower motors and compressors will energize.

Refrigerant sensors are located near the evaporator coil to detect leaked refrigerant. See Refrigerant Detection System section for more information.

7.4. Chilled Water or Non-Compressorized DX Cooling Operation

Valve controls for chilled water-cooling coil and non-compressorized DX coil are by others.

7.5. Steam or Hot Water Preheating Operation

Valve control for steam and hot water heating coils are by others. Heating is accomplished by passing steam or hot water through the steam or hot water coil assembly.

7.6. Electric Heating Operation

When a call for heating (G and W1, W2, etc.) is made the supply fan motors and electric resistance heaters will energize. Heating is accomplished by passing electrical current through a specified amount of resistance heaters which will produce the required heat.

On a fault condition the main limit located in the supply air or the auxiliary limit located downstream the supply blower will remove power from all contactors.

7.7. Gas Heater Operation

When heat (G and W1, W2, etc.) is called for the combustion motor starts and the ignition control is energized. See Gas Heater section for more details.

8. MAINTENANCE

(See back of the manual for maintenance log.)

At least once each year, a qualified service technician must check out the unit. Inspect supply fans, evaporator coils and air filters monthly.



WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a qualified installer. A copy of this IOM must be kept with the unit.

Periodically during operation, it is necessary to perform routine service checks on the performance of the unit. This includes checking the air flow, air filters, condenser water flow, and refrigerant charge.

See Startup section for information on air flow adjustment and refrigerant charge adjustment.

8.1. DX Cooling

Set unit controls to cooling mode of operation with supply fans on. Check the fans for correct operating direction, amperage and voltage.

8.2. Condensate Drain Pans

Drain pans will have moisture present and require periodic cleaning to prevent microbial growth. Cleaning of the drain pans will also prevent any possible plugging of the drain lines and overflow of the pan itself. Cleaning of the drain pans and inside of the unit must be done only by qualified personnel.

8.3. Winterizing Coils

In some cases it may be necessary to winterize water coils to prevent them from freezing.

First completely drain the coils. There is a drain located below the 'water in' connection

and a vent connection located above the 'water out' connection. Auxiliary drain piping can also be added to exterior water piping if yearly winterizing is necessary.

After the coil is drained, fill with an antifreeze solution using a circulating pump. Then thoroughly drain.

8.4. Supply Fans



CAUTION

Blower wheels must be inspected for excessive dust build up periodically and cleaned if required. Excessive dust build up on blower wheels may cause an unbalanced state; leading to vibration and/or component failure. Damages due to excessive dust build up will not be covered under factory warranty.



WARNING

Electric shock hazard. Shut off all electrical power to the unit to avoid shock hazard or injury from rotating parts.

8.5. E-Coated Coil Cleaning

Documented routine cleaning of e-coated coils is required to maintain coating warranty coverage for fin and tube and microchannel coils. See the AAON E Coated Coil Maintenance Record sheet.



WARNING

Electric shock hazard. Shut off all electrical power to the unit to avoid shock hazard or injury from rotating parts.

Surface loaded fibers or dirt must be removed prior to water rinse to prevent restriction of airflow. If unable to back wash the side of the coil opposite of the coils entering air side, then surface loaded fibers or dirt must be removed with a vacuum cleaner. If a vacuum cleaner is not available, a soft non-metallic bristle brush may be used. In either case, the tool must be applied in the direction of the fins. Coil surfaces can be easily damaged (fin edges bent over) if the tool is applied across the fins. Use of a water stream, such as a garden hose, against a surface loaded coil will drive the fibers and dirt into the coil. This will make cleaning efforts more difficult. Surface loaded fibers must be completely removed prior to using low velocity clean water rinse. A monthly clean water rinse is recommended for coils that are applied in coastal or industrial environments to help to remove chlorides, dirt, and debris. It is very important when rinsing, that water temperature is less than 54.4°C (130°F) and pressure is less than 689.5 kpa (100 psig) to avoid damaging the fin edges. An elevated water temperature (not to exceed 54.4°C [130°F]) will reduce surface tension, increasing the ability to remove chlorides and dirt.

 **CAUTION**

Harsh chemicals, household bleach, or acid cleaners should not be used to clean outdoor or indoor e-coated coils. These cleaners can be very difficult to rinse out of the coil and can accelerate corrosion and attack the E-coating. If there is dirt below the surface of the coil, use the recommended coil cleaners.

For routine quarterly cleaning, first clean the coil with the below approved coil cleaner. After cleaning the coils with the approved cleaning agent, use the approved chloride remover to remove soluble salts and revitalize the unit.

8.5.1. Recommended Coil Cleaner

The following cleaning agent, when used in accordance with the manufacturer's directions, has been approved for use on e-coated coils to remove mold, mildew, dust, soot, greasy residue, lint, and other particulate:

- Enviro-Coil Cleaner: AAON PN: V82540
- GulfClean™ Coil Cleaner ; AAON PN: G074480

**CAUTION**

High velocity water from a pressure washer or compressed air should only be used at a very low pressure to prevent fin and/or coil damages. The force of the water or air jet may bend the fin edges and increase airside pressure drop. Reduced unit performance or nuisance unit shutdowns may occur.

8.5.2. Recommended Chloride Remover

GulfClean Salt Reducer™; AAON PN: G074490

GulfClean Salt Reducer™ is used to remove soluble salts from the e-coated coil, follow the manufacturer's instructions. This product is not intended for use as a degreaser. Any grease or oil film must first be removed with GulfClean™ Coil Cleaner.

Remove Barrier - First ensure the power to the unit is off and locked out. Clean the area around the unit if needed to ensure leaves, grass or loose debris will not be blown into the coil. Soluble salts adhere themselves to the substrate. For the effective use of this product, the product must be able to come in contact with the salts. These salts may be beneath any soils, grease or dirt; therefore, these barriers must be removed prior to application of this product. As in all surface preparation, the best work yields the best results.

Application - Apply GulfClean™ Coil Cleaner directly onto the substrate. Sufficient product must be applied uniformly across the substrate to thoroughly wet out surface, with no areas missed. This may be accomplished by use of a pump-up sprayer or conventional spray gun. Apply the cleaner to unit interior air exiting side coil surfaces first. Work in sections/panels moving side to side and from top to bottom. Allow the cleaning solution to soak for 5 to 10 minutes. Then move on to the exterior using the same method.

Rinse - Using pressurized potable water such as a garden hose, (< 689.5 kpa [100 psi]), rinse the coils and continue to always work in sections/panels.

Continue until all coil areas on the inside of the unit have been rinsed. Note: Coils must always be cleaned / back flushed, opposite of airflow to prevent impacting the dirt into the coil.

Repeat these steps with GulfClean™ Salt Reducer. When finished replace all panels and tops that were removed.

8.6. Refrigerant Removal and Evacuation

If removal of refrigerant is required for any maintenance or servicing, conventional procedures must be used and removal of refrigerant must be in accordance with local and national regulations.

Safety precautions must be taken prior to beginning work to ensure that the risk of fire due to flammable refrigerants is minimized. Work is to be undertaken under a controlled procedure to reduce the amount of refrigerant vapor present while work is being performed. All maintenance staff and others working in the area are to be instructed on the nature of work being performed. Care should be taken to ensure that working in a confined space is avoided.

Check area with a refrigerant detector suitable for use with the refrigerant prior to and during work in order to be aware of potential flammable environment. Keep a dry powder or CO₂ fire extinguisher nearby if any hot work is being performed.

Ensure that work area is sufficiently ventilated before breaking into the system. Ventilation must continue throughout all of the work. Ensure that ventilation safely removes flammable refrigerant to an area that will adequately disperse refrigerant to avoid concentration above flammable levels.



WARNING

Prior to performing work that can result in release of a flammable refrigerant, inspect area to ensure it is free of any potential ignition sources. "No Smoking" signs are to be displayed while performing work.

Refrigerant must be recovered into the correct recovery cylinders in accordance with local and national regulations. Recovery cylinders must be labeled properly. Ensure that the correct number of cylinders are available for holding the entire charge of the system. Cylinders must have pressure relief and shut-off valves that are in proper working order. Fully evacuate a recovery cylinder before use.

The recovery equipment must be in good working order with a set of instructions concerning the equipment that is at hand. Ensure that equipment is suitable for the recovery of flammable refrigerant used. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales must be available and in good working order. Ensure hoses are complete with leak-free disconnect couplings and in good condition.

When removing refrigerant to open the system, evacuate the system and flush or purge the system continuously with an inert gas when using a flame to open the circuit.

The system must be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerant. Compressed air or oxygen must not be used. When pulling a vacuum, ensure that the outlet of the vacuum pump is not near any potential ignition source and in a well ventilated area.

The recovered refrigerant is to be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged.

Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. Do not heat the compressor body by using an open flame or other ignition sources to accelerate this process. Remove any drained oil safely.

9. OPTIONS

9.1. Heating Coils

One, two, or four row hot water and one or two row steam heating and preheating coils can be factory installed. These coils are supplied from a building hot water source. All valve controls for heating coil operation are field supplied and field installed. Hot water and steam coil connections are spun copper tube.

Connect the steam heating supply to the top of the coil and the return to the bottom.




Figure 29: Steam Distributing Piping

Table 11: Steam Distributing Coil Sweat Connection Sizes

Model (H3/V3-)	Supply and Return Connection Size (OD)	
A-E	5.4 cm	2 1/8"

Air handling units with steam heating coils **MUST BE** installed high enough to allow for a minimum of 0.31 meters (1 foot) condensate drop leg off of the steam coil, or as recommended by the steam trap manufacturer. Lines must be insulated with approved insulation and be properly fastened, sloped, and supported according to local code requirements.

Table 12: Hot Water Coil Sweat Connection Sizes

Model (H3/V3-)	Supply and Return Connection Size (OD)	
A	2.2 cm	7/8"
B	2.9 cm	1 1/8"
C	3.5 cm	1 3/8"
D & E	4.1 cm	1 5/8"

Connect the hot water heating supply to the bottom of the coil and return to the top.




Figure 30: Hot & Chilled Water Piping

Do not subject water coils to entering air temperatures below 3.3°C (38°F) to prevent coil freeze-up. If air temperature across the coil is going to be below this value, use a glycol solution to match the coldest air expected.

Water supply lines must be insulated, properly fastened, drained, and supported according to local code requirements.

9.2. Chilled Water Coil

Factory installed four, six or eight row chilled water-cooling coils can be factory mounted. These coils are supplied from a building chilled water source. All valve controls for the cooling coil operation are field supplied and field installed.

Table 13: Chilled Water Coil Sweat Connection Sizes

Model (H3/V3-)	Supply and Return Connection Size (OD)	
A	2.9 cm	1 1/8"
B	3.5 cm	1 3/8"
C	4.1 cm	1 5/8"
D & E	5.4 cm	2 1/8"

Connect the chilled water supply to the bottom of the coil and return to the top.

Water supply lines must be insulated with closed cell type pipe insulation or insulation that includes a vapor barrier. Lines must be properly fastened, drained and supported according to local code requirements, and job specifications.

Table 14: Minimum and Maximum Coil Pressures and Temperatures

	Chilled Water	Hot Water
Min. Entering Air	15.6°C (60°F)	4.4 °C (40°F)
Max Entering Air	37.8°C (100°F)	26.7°C (80°F)
Min. Entering Water	1.7°C (35°F)	60°C (140°F)
Max Entering Water	18.3°C (65°F)	93.3°C (200°F)
Min. Water Pressure	103 kpa (15 psig)	
Max Water Pressure	2068kpa (300 psig)	



WARNING

Prior to performing work that can result in release of a flammable refrigerant, inspect area to ensure it is free of any potential ignition sources. "No Smoking" signs are to be displayed while performing work.



CAUTION

Ensure water piping entries into the unit are properly sealed. Failure to seal the entries may result in damage to the unit and property.



CAUTION

Crankcase Heater Operation

Some units are equipped with compressor crankcase heaters, which must be energized at least 24 hours prior to cooling operation, to clear any liquid refrigerant from the compressors.

9.3. Direct Expansion (DX) Systems

All DX refrigerant coils are factory charged with a nitrogen holding charge. All DX systems include evaporator coils and thermal expansion valves (TXV).

Never turn off the main power supply to the unit, except for servicing, emergency, or complete shutdown of the unit. When power is cut off from the unit, crankcase heaters cannot prevent refrigerant migration into the split system condensing unit compressors. This means the compressor may cool down and liquid refrigerant may accumulate in the compressor. The compressor is designed to pump refrigerant gas and damage may occur when power is restored.

If power to the unit must be off for more than an hour, turn the thermostat system switch to "OFF", or turn the unit off at the control panel, and leave the unit off until the main power switch has been turned on again for at least 24 hours for units with compressor crankcase heaters. This will give the crankcase heater time to clear any liquid accumulation out of the compressor before it is started.

Always control the unit from the thermostat, or control panel, never at the main power supply, except for emergency or complete shutdown of the unit.

During the cooling season, if the air flow is reduced due to dirty air filters or any other reason, the cooling coils can get too cold which will cause excessive liquid to return to the compressor. As the liquid concentration builds up, oil is washed out of the compressor, leaving it starved for lubrication.

The compressor life will be seriously shortened by reduced lubrication and the pumping of excessive amounts of liquid oil and refrigerant.

Note: Low Ambient Operation Air-cooled DX units without a low ambient option, such as condenser fan cycling or the -17.8°C (0°F) low ambient option, will not operate in the cooling mode of operation properly when the outdoor temperature is below 12.8°C (55°F). Low ambient and/or economizer options are recommended if cooling operation below 12.8°C (55°F) is expected.

9.4. Evaporator Coil

The air handling unit coils are pressurized. The copper caps must be punctured to permit a gradual escape of the pressure prior to unscrewing those caps. Immediately couple the tubing to the indoor unit to avoid exposing the coils to moisture. A properly sized filter drier is furnished in the condenser. When making solder connections, make sure dry nitrogen flows through the lines, when heating the copper, to prevent oxidation inside of the copper. Field piping between the condensing unit and the air handler is required. Line sizes must be selected to meet actual installation conditions, not simply based on the connection sizes.



Refrigerant Piping

Line sizes must be selected to meet actual installation conditions, not simply based on the connection sizes at the condensing unit or air handling unit.

9.5. Thermal Expansion Valve

Thermal expansion valve bulbs must be mounted with good thermal contact on a horizontal section of the suction line close to the evaporator, but outside the cabinet, and well insulated. On suction lines less than or equal to 22.2 mm (7/8") OD, mount in the 12 o'clock position. On suction lines greater than 22.2 mm (7/8") OD, mount in either the 4 o'clock or 8 o'clock position.




Figure 31: TXV Bulb Position

9.6. Hot Gas Reheat

Hot Gas Reheat (HGRH) is available for use with DX systems that need humidity control. The AAON modulating hot gas reheat system diverts hot discharge gas from the condenser to the air handling unit through the hot gas line. Field piping between the condensing unit and the air handler is required. Line sizes must be selected to meet actual installation conditions, not simply based on the connection sizes.

The line delivers the hot discharge gas to the reheat coil and/or the hot gas bypass valve, so it is sized as a discharge line.

9.7. Hot Gas Bypass

Hot Gas Bypass is available for use with DX systems that may experience low suction pressure during the operating cycle. This may be due to varying load conditions associated with VAV applications or units supplying a large percentage of outside air. Hot Gas Bypass is not necessary in units with variable capacity compressors. The system is designed to divert refrigerant from the compressor discharge to the low pressure side of the system in order to keep the evaporator from freezing and to maintain adequate refrigerant velocity for oil return at minimum load.

Hot discharge gas is redirected to the evaporator inlet via an auxiliary side connector (ASC) to false load the evaporator when reduced suction pressure is sensed. Field piping between the condensing unit and the evaporator is required. Line sizes must be selected to meet actual installation conditions, not simply based on the connection sizes.

9.8. Purge Circuit

The purge circuit is required on hot gas reheat or hot gas bypass lines. The purge circuit needs to be field furnished and installed at the lowest point of the line set.

With this installation, oil drains into the drain leg of the hot gas reheat line. Oil accumulates until it reaches the level of the 3.2 mm (1/8") OD capillary tubing.




Figure 32: Hot Gas Purge Circuit

The combination of capillary action and the pressure difference between the hot gas reheat line (high pressure) and the suction line (low pressure) causes the oil to travel through the capillary tube into the suction line of the first circuit to return the oil to the compressor. The capillary tube connection to the suction line of the first circuit must be a minimum of 1.5 meters (5 feet) from the inlet to the compressor to allow the oil time to dissipate into the suction vapor and not slug the compressor with liquid oil.

9.9. Adjusting Refrigerant Charge

Adjusting the charge of a system in the field must be based on determination of liquid sub-cooling and evaporator superheat. On a system with a TXV, liquid sub-cooling is more representative of the charge than evaporator superheat but both measurements must be taken.

When charge is adjusted in the field, the total system charge must be written on the decal near the nameplate using a permanent marker. Ensure that the space served by the unit has a sufficient floor area in accordance with Table 18.

CAUTION

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFC's and HCFC's) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for non-compliance.

Before Charging

Refer to the Unit Nameplate to determine which refrigerant must be used to charge the system.

Unit being charged must be at or near full load conditions before adjusting the charge.

Units equipped with hot gas bypass must have the hot gas bypass valve closed to get the proper charge.

Units equipped with hot gas reheat must be charged with the hot gas reheat valves closed while the unit is in cooling mode to get the proper charge. After charging, operate the unit in reheat (dehumidification) mode to check for correct operation.

Units equipped with heat pump options must be charged in cooling mode to get the proper charge. After charging, operate the unit in heating mode to check for correct charge. Charge may need to be adjusted for heating mode. If adjustments are made in the heating mode, cooling mode must be rerun to verify proper operation.

After adding or removing charge the system must be allowed to stabilize, typically 10-15 minutes, before making any other adjustments.

The type of unit and options determine the ranges for liquid sub-cooling and evaporator superheat. Refer to the tables below when determining the proper sub-cooling.

For units equipped with low ambient (-17.78°C [0°F]) option see the special charging instructions in the CF Series Installation and Operation Manual.

Checking Liquid Sub-Cooling

Measure the temperature of the liquid line as it leaves the condenser coil.

Read the gauge pressure at the liquid line close to the point where the temperature was taken. Use liquid line pressure as it will vary from discharge pressure due to condenser coil pressure drop.

Convert the pressure obtained to a saturated temperature using the appropriate refrigerant temperature-pressure chart.

Subtract the measured liquid line temperature from the saturated temperature to determine the liquid sub-cooling.

Compare calculated sub-cooling to the table below for the appropriate unit type and options.

Table 15: Acceptable Refrigeration Circuit Values

	Cooling Mode Liquid Sub-Cooling Values (°C)	Cooling Mode Liquid Sub-Cooling Values (°F)
Cooling Only Unit4	4.4 - 8.3	8-15
Cooling Only Unit with Hot Gas Reheat1,4	2.8 - 8.3	5-15
Heat PumpUnit2,4	1.1 - 2.2	2-4
Heat Pump Unit with Hot Gas Reheat3,4	1.1 - 3.3	2-6
Cooling Only Unit with LAC4	4.4 - 8.3	8-15
Cooling Only Unit with Hot Gas Reheat & LAC4	4.4 - 8.3	8-15

Note: Must be charged with the hot gas valve closed. After charging, operate the unit in reheat (dehumidification) mode to check for correct operation.

Note: The sub-cooling value in this table is for the unit running in cooling mode of operation. If unit is a heat pump, operate the unit in heating mode to check for correct operation after charging in cooling.

Note: The sub-cooling value in this table is for the unit running in cooling mode of operation and the hot gas valve closed. After charging, operate the unit in reheat (dehumidification) mode to check for correct operation and then in heating mode to check for correct operation.

Note: Sub-cooling must be increased by 0.6°C (1°F) per 3.1 meters (10 feet) of vertical liquid line rise for R-454B (AHU above CU). For example, a cooling only unit with hot gas reheat and a vertical liquid drop can charge to a sub-cooling value between 2.8 and 8.3°C (5-15°F), but a cooling only unit with hot gas reheat and a vertical liquid rise of 9.1 m (30 ft) must charge to a sub-cooling value of at least between 4.4 and 8.3°C (8-15°F). DO NOT OVERCHARGE. Refrigerant overcharging leads to excess refrigerant in the condenser coils resulting in elevated compressor discharge pressure.

Table 16: Acceptable Microchannel Air-Cooled Condenser Coil Liquid Sub-Cooling Values (Metric)

Ambient (°C)	Cooling Mode Liquid Sub-Cooling Values(°C)				
	Evaporator Coil Saturation Temperature (°C)				
	4.4	7.2	8.9	10.0	12.8
19.4	5.0 - 7.8	4.4 - 7.2	4.4 - 7.2	3.9 - 6.7	2.8 - 5.6
22.2	5.6 - 8.3	5.0 - 7.8	5.0 - 7.8	4.4 - 7.2	3.9 - 6.7
27.8	5.6 - 8.3	5.6 - 8.3	5.6 - 8.3	5.0 - 7.8	3.9 - 6.7
35.0	5.6 - 8.3	5.6 - 8.3	5.6 - 8.3	5.0 - 7.8	4.4 - 7.2
40.6	6.1 - 8.9	6.1 - 8.9	5.6 - 8.3	5.6 - 8.3	4.4 - 7.2

Table 17: Acceptable Microchannel Air-Cooled Condenser Coil Liquid Sub-Cooling Values (Imperial)

Ambient (°F)	Cooling Mode Liquid Sub-Cooling Values(°F)				
	Evaporator Coil Saturation Temperature (°F)				
	40	45	48	50	55
67	9 - 14	8 - 13	8 - 13	7 - 12	5 - 10
72	10 - 15	9 - 14	9 - 14	8 - 13	7 - 12
82	10 - 15	10 - 15	10 - 15	9 - 14	7 - 12
95	10 - 15	10 - 15	10 - 15	9 - 14	8 - 13
105	11 - 16	11 - 16	10 - 15	10 - 15	8 - 13

Note: Microchannel condenser coils are more sensitive to charge. The system must be running in cooling mode with compressor, supply airflow & condenser fan speed at full load. The sub-cooling value changes depending on the ambient temperature reading and the evaporator coil saturation temperature. To find the correct sub-cooling value, find the ambient temperature on the first column and follow that across to the SST (4.4-12.8°C [40-55°F]).

Note: Superheat for Microchannel condenser coils must be between 4.4 and 8.3°C (8 - 15°F).

Checking Evaporator Superheat

Measure the temperature of the suction line close to the evaporator.

Read gauge pressure at the suction line close to the evaporator.

Convert the pressure obtained to a saturated temperature using the appropriate refrigerant temperature-pressure chart.

Subtract the saturated temperature from the measured suction line temperature to determine the evaporator superheat.

Compare calculated superheat to the acceptable cooling mode superheat values between 4.4 and 8.3°C (8 - 15°F) for all system types. Superheat will increase with long suction line runs.

For refrigeration systems with tandem compressors, it is critical that the suction superheat setpoint on the TXV is set with one compressor running. The suction superheat must be between 5.6 and 7.2°C (10-13°F) with one compressor running. The suction superheat will increase with both compressors in a tandem running. Inadequate suction superheat can allow liquid refrigerant to return to the compressors which will wash the oil out of the compressor. Lack of oil lubrication will destroy a compressor. Measure liquid sub-cooling with both compressors in a refrigeration system running.



CAUTION

Thermal expansion valve must be adjusted between 4.4 and 8.3°C (8-15°F) of suction superheat. Failure to have sufficient superheat will damage the compressor and void the warranty.

Adjusting Sub-Cooling and Superheat Temperatures

The system is overcharged if the sub-cooling temperature is too high and the evaporator is fully loaded (low loads on the evaporator result in increased sub-cooling) and the evaporator superheat is within the temperature range as shown in the table above (high superheat results in increased sub-cooling).

Correct an overcharged system by reducing the amount of refrigerant in the system to lower the sub-cooling.



CAUTION

Do Not Overcharge!

Refrigerant overcharging leads to excess refrigerant in the condenser coils resulting in elevated compressor discharge pressure. Maximum allowable charge is 130.4 kg (4600 oz). See Table 21.

If the sub-cooling is correct and the superheat is too high, the TXV may need adjustment to correct the superheat. Before adjusting the TXV, verify the sensing bulb is in the correct position according to Figure 34 and follow the guidelines below.

1. The suction line is clean where the sensing bulb is attached.
2. The entire length of the sensing bulb is in contact with the suction line.
3. Place the sensing bulb several centimeters (inches) downstream of the equalizer line.
4. The sensing bulb is fully insulated.
5. If the sensing bulb is installed on a vertical portion of the suction line, place the sensing bulb upstream of suction line trap.

Table 18: Minimum Circulation Airflow and Room Area for a Given Charge

Charge of Largest Circuit in kg (oz)	Min Circulation Airflow in m ³ /hr (CFM)	Minimum Room Area in m ² (ft ²)					
		1.8 m (6 ft) ceiling/release height		3 m (10 ft) ceiling/release height		3.7 m (12 ft) ceiling/release height	
1.4	50	144	85	5	57	3	34
1.9	66	190	112	7	76	4	45
2.3	82	236	139	9	94	5	56
2.8	98	282	166	10	112	6	67
3.2	114	328	193	12	131	7	78
3.7	130	374	220	14	149	8	89
4.1	146	419	247	16	167	9	100
4.6	162	465	274	17	186	10	111
5.0	178	511	301	19	204	11	122
5.5	194	557	328	21	222	12	133
6.0	210	603	355	22	241	13	144
6.4	226	649	382	24	259	14	155
6.9	242	695	409	26	277	15	166
7.3	258	741	436	27	296	16	177
7.8	274	787	463	29	314	17	188
8.2	290	833	490	31	332	19	199
8.7	306	879	517	33	351	20	210
9.2	326	937	551	35	373	21	224
9.6	340	977	575	36	389	22	234
10.2	360	1034	609	38	412	23	247
10.8	380	1092	643	40	435	24	261
11.3	400	1149	676	43	458	26	275
12.0	424	1218	717	45	486	27	291
12.7	448	1287	758	48	513	29	308
13.4	472	1356	798	50	541	30	324
14.1	496	1425	839	53	568	32	341
14.7	520	1494	879	55	596	33	357
15.4	544	1563	920	58	623	35	374
16.3	576	1655	974	61	660	37	396
17.2	608	1747	1028	65	696	39	418
18.1	640	1839	1082	68	733	41	440
19.1	672	1931	1136	72	770	43	462
20.0	704	2023	1191	75	806	45	484
20.9	736	2115	1245	78	843	47	506
21.8	768	2207	1299	82	880	49	528
						40	428

Table 19: Minimum Circulation Airflow and Room Area for a Given Charge (continued)

Charge of Largest Circuit in kg (oz)	Min Circulation Airflow in m ³ /hr (CFM)	Minimum Room Area in m ² (ft ²)					
		1.8 m (6 ft) ceiling/release height		3 m (10 ft) ceiling/release height		3.7 m (12 ft) ceiling/release height	
22.7	800	2299	1353	85	916	51	550
23.6	832	2391	1407	89	953	53	572
24.5	864	2482	1461	92	990	55	594
25.4	896	2574	1515	95	1026	57	616
26.3	928	2666	1569	99	1063	59	638
27.2	960	2758	1623	102	1100	61	660
28.1	992	2850	1678	106	1136	63	682
28.6	1010	2902	1708	107	1157	64	694
30.1	1060	3046	1793	113	1214	68	729
31.5	1110	3189	1877	118	1271	71	763
32.9	1160	3333	1962	123	1329	74	797
34.3	1210	3477	2046	129	1386	77	832
35.7	1260	3620	2131	134	1443	80	866
37.1	1310	3764	2215	139	1501	84	900
38.6	1360	3908	2300	145	1558	87	935
40.0	1410	4051	2385	150	1615	90	969
41.4	1460	4195	2469	155	1672	93	1003
42.8	1510	4339	2554	161	1730	96	1038
44.2	1560	4482	2638	166	1787	100	1072
45.6	1610	4626	2723	171	1844	103	1107
47.1	1660	4770	2807	177	1901	106	1141
48.5	1710	4913	2892	182	1959	109	1175
49.9	1760	5057	2976	187	2016	112	1210
51.3	1810	5201	3061	193	2073	116	1244
52.7	1860	5344	3146	198	2131	119	1278
54.1	1910	5488	3230	203	2188	122	1313
55.6	1960	5632	3315	209	2245	125	1347
57.0	2010	5775	3399	214	2302	128	1381
59.5	2100	6034	3551	223	2405	134	1443
62.4	2200	6321	3721	234	2520	140	1512
65.2	2300	6608	3890	245	2635	147	1581
68.0	2400	6896	4059	255	2749	153	1649
70.9	2500	7183	4228	266	2864	160	1718
73.7	2600	7470	4397	277	2978	166	1787
76.5	2700	7758	4566	287	3093	172	1856
79.4	2800	8045	4735	298	3207	179	1924
						145	1560

Table 20: Minimum Circulation Airflow and Room Area for a Given Charge (continued)

Charge of Largest Circuit in kg (oz)		Min Circulation Airflow in m ³ /hr (CFM)		Minimum Room Area in m ² (ft ²)					
				1.8 m (6 ft) ceiling/release height		3 m (10 ft) ceiling/release height		3.7 m (12 ft) ceiling/release height	
82.2	2900	8332	4904	309	3322	185	1993	150	1616
85.0	3000	8620	5073	319	3436	192	2062	155	1672
87.9	3100	8907	5243	330	3551	198	2131	160	1727
90.7	3200	9194	5412	341	3665	204	2199	166	1783
93.6	3300	9482	5581	351	3780	211	2268	171	1839
96.4	3400	9769	5750	362	3895	217	2337	176	1895
99.2	3500	10056	5919	372	4009	223	2405	181	1950
102.1	3600	10344	6088	383	4124	230	2474	186	2006
104.9	3700	10631	6257	394	4238	236	2543	192	2062
107.7	3800	10918	6426	404	4353	243	2612	197	2118
110.6	3900	11206	6595	415	4467	249	2680	202	2173
113.4	4000	11493	6765	426	4582	255	2749	207	2229
116.2	4100	11780	6934	436	4696	262	2818	212	2285
119.1	4200	12068	7103	447	4811	268	2887	217	2340
121.9	4300	12355	7272	458	4925	275	2955	223	2396
124.7	4400	12642	7441	468	5040	281	3024	228	2452
127.6	4500	12930	7610	479	5155	287	3093	233	2508
130.4	4600	13217	7779	490	5269	294	3161	238	2563

Table 21: Minimum Airflow for Non-Ducted Applications by Box Size

Box Size	Maximum Charge of any Single Circuit in kg (oz)	Minimum Airflow for Non-Ducted Applications in m ³ /hr (CFM)		
A	20.1	706	705	415
B	36.9	1300	1201	707
C	70.9	2500	2241	1319
D	99.2	3500	3264	1921
E	130.4	4600	4815	2834

Table 22: R-454B Refrigerant Temperature-Pressure Chart (Metric)

°C	KPA	°C	KPA	°C	KPA	°C	KPA	°C	KPA
-6.7	484.5	8.3	843.3	23.3	1348.0	38.3	2034.6	53.3	2946.9
-6.1	495.6	8.9	859.3	23.9	1370.0	38.9	2064.1	53.9	2985.7
-5.6	506.9	9.4	875.3	24.4	1392.2	39.4	2093.9	54.4	3024.9
-5.0	518.2	10.0	891.6	25.0	1414.6	40.0	2123.9	55.0	3064.5
-4.4	529.7	10.6	908.1	25.6	1437.3	40.6	2154.3	55.6	3104.5
-3.9	541.5	11.1	924.8	26.1	1460.3	41.1	2185.0	56.1	3144.9
-3.3	553.3	11.7	941.7	26.7	1483.5	41.7	2216.1	56.7	3185.8
-2.8	565.4	12.2	958.8	27.2	1507.0	42.2	2247.4	57.2	3227.0
-2.2	577.6	12.8	976.2	27.8	1530.8	42.8	2279.1	57.8	3268.6
-1.7	589.9	13.3	993.7	28.3	1554.8	43.3	2311.1	58.3	3310.7
-1.1	602.5	13.9	1011.5	28.9	1579.0	43.9	2343.5	58.9	3353.2
-0.6	615.2	14.4	1029.4	29.4	1603.6	44.4	2376.2	59.4	3396.1
0.0	628.1	15.0	1047.6	30.0	1628.4	45.0	2409.2	60.0	3439.5
0.6	641.2	15.6	1066.0	30.6	1653.5	45.6	2442.6	60.6	3483.3
1.1	654.4	16.1	1084.7	31.1	1678.8	46.1	2476.2	61.1	3527.6
1.7	667.8	16.7	1103.5	31.7	1704.4	46.7	2510.3	61.7	3572.3
2.2	681.4	17.2	1122.6	32.2	1730.4	47.2	2544.7	62.2	3617.4
2.8	695.2	17.8	1141.9	32.8	1756.6	47.8	2579.4	62.8	3663.0
3.3	709.2	18.3	1161.5	33.3	1783.0	48.3	2614.5	63.3	3709.2
3.9	723.3	18.9	1181.3	33.9	1809.9	48.9	2650.0	63.9	3755.7
4.4	737.6	19.4	1201.3	34.4	1836.9	49.4	2685.7	64.4	3802.7
5.0	752.2	20.0	1221.5	35.0	1864.3	50.0	2721.9	65.0	3850.3
5.6	766.9	20.6	1242.0	35.6	1891.9	50.6	2758.5	65.6	3898.4
6.1	781.8	21.1	1262.8	36.1	1919.8	51.1	2795.4		
6.7	796.9	21.7	1283.7	36.7	1948.1	51.7	2832.7		
7.2	812.2	22.2	1304.9	37.2	1976.7	52.2	2870.4		
7.8	827.7	22.8	1326.3	37.8	2005.5	52.8	2908.4		

Table 23: R-454B Refrigerant Temperature-Pressure Chart (Imperial)

°F	PSIG	°F	PSIG	°F	PSIG	°F	PSIG	°F	PSIG
20	70.3	47	122.3	74	195.5	101	295.1	128	427.4
21	71.9	48	124.6	75	198.7	102	299.4	129	433.0
22	73.5	49	127.0	76	201.9	103	303.7	130	438.7
23	75.2	50	129.3	77	205.2	104	308.0	131	444.5
24	76.8	51	131.7	78	208.5	105	312.5	132	450.3
25	78.5	52	134.1	79	211.8	106	316.9	133	456.1
26	80.3	53	136.6	80	215.2	107	321.4	134	462.0
27	82.0	54	139.1	81	218.6	108	326.0	135	468.0
28	83.8	55	141.6	82	222.0	109	330.6	136	474.1
29	85.6	56	144.1	83	225.5	110	335.2	137	480.2
30	87.4	57	146.7	84	229.0	111	339.9	138	486.3
31	89.2	58	149.3	85	232.6	112	344.6	139	492.6
32	91.1	59	151.9	86	236.2	113	349.4	140	498.8
33	93.0	60	154.6	87	239.8	114	354.3	141	505.2
34	94.9	61	157.3	88	243.5	115	359.1	142	511.6
35	96.9	62	160.1	89	247.2	116	364.1	143	518.1
36	98.8	63	162.8	90	251.0	117	369.1	144	524.6
37	100.8	64	165.6	91	254.8	118	374.1	145	531.3
38	102.9	65	168.5	92	258.6	119	379.2	146	538.0
39	104.9	66	171.3	93	262.5	120	384.3	147	544.7
40	107.0	67	174.2	94	266.4	121	389.5	148	551.5
41	109.1	68	177.2	95	270.4	122	394.8	149	558.4
42	111.2	69	180.1	96	274.4	123	400.1	150	565.4
43	113.4	70	183.1	97	278.4	124	405.4		
44	115.6	71	186.2	98	282.5	125	410.8		
45	117.8	72	189.3	99	286.7	126	416.3		
46	120.0	73	192.4	100	290.9	127	421.8		

10. ENERGY RECOVERY UNITS

Some H3 & V3 units have been equipped with an energy recovery wheel. This section is provided to assure the energy recovery feature will be properly setup to perform in accordance with the job specifications for your particular application.




Figure 33: Energy Recovery Wheel

The Energy Recovery Cassette consists of a frame wheel, wheel drive system, and energy transfer segments. Segments are removable for cleaning or replacement. The segments rotate through counter flowing exhaust and outdoor air supply streams where they transfer heat and/or water vapor from the warm, moist air stream to the cooler and/or drier air stream.

The initial setup and servicing of the energy recovery wheel is very important to maintain proper operation efficiency and building occupant comfort.

Normal maintenance requires periodic inspection of filters, the cassette wheel, drive belts, air seals, wheel drive motor, and its electrical connections.

Wiring diagrams are provided with each motor. When wired according to wiring diagram, motor rotates clockwise when viewed from the shaft/pulley side.

By carefully reviewing the information within this section and following the instructions, the risk of improper operation and/or component damage will be minimized.

It is important that periodic maintenance be performed to help assure trouble free operation.

10.1. Initial Mechanical Check and Setup

Outdoor air intake adjustments must be made according to building ventilation, or local code requirements.

After the unit installation is complete, open the cassette access door and determine that the energy wheel rotates freely when turned by hand. Apply power and observe that the wheel rotates at approximately 30 RPM. If the wheel does not rotate when power is applied, it may be necessary to readjust the "diameter air seals".

Handle cassettes with care. Lift all cassettes by the bearing support beam. Holes are provided on both sides of the bearing support beams to facilitate rigging as shown in the following illustration.




Figure 34: Lifting Hole Locations

10.2. Polymer Energy Recovery Wheel

This section is provided to assure the energy recovery feature will be properly setup to perform in accordance with the job specifications for your particular application.




Figure 35: Polymer Energy Recovery Wheel

1. Removable Segment
2. Permanent Tension Belt
3. Pulley
4. Embedded Segment Stiffeners
5. Segment Retaining Latches
6. Bearing Beam and Bearing Access Cover Plate (Diameter Seals are behind Bearing Beam on both sides)
7. Adjustable Purge
8. Motor

Polymer Wheel Set Purge Angle

When installed, the purge angle is factory set to 5 degrees. If a different angle is required, complete the following steps to adjust the purge:




Figure 36: Purge Screws

9. Loosen the three purge adjusting screws.
10. Adjust purge sector to the specified angle.




Figure 37: Purge Adjust

11. Tighten the purge adjusting screws.
12. Turn the wheel by hand clockwise (when viewed from pulley side) to check for interference.

Polymer Wheel Check Purge Seal

If a purge is installed, check for a slight interference fit between the seal and the face of the wheel by sliding a piece of paper ("feeler gauge") between the seal and the media a multiple locations along the purge seal as you rotate the wheel slowly by hand (clockwise when viewed from the pulley side). Verify that the media slightly grabs the paper during rotation.




Figure 38: Determine Fit

If it is necessary to adjust a purge seal to the face of the wheel, loosen the two or three screws along the bearing beam and adjust to the proper distance from the media surface. Tighten the screws and retest the seal.

Polymer Wheel Air Seal Adjustments

Pile type air seals across both sides of the energy wheel diameter are factory adjusted to provide close clearance between the air seal and wheel.




Figure 39: Cross Section of Air Seal Structure

Racking of the unit or cassette during installation, and/or mounting of the unit on a non-level support or in other than the factory orientation can change seal clearances. Tight seals will prevent rotation.

Polymer Wheel to Air Seal Clearance

To check wheel to seal clearance; first disconnect power to the unit, in some units the energy recovery wheel assembly can be pulled out from the cabinet to view the air seals. On larger units, the energy recovery wheel may be accessible inside the walk-in cabinet.

A business card or two pieces of paper can be used as a feller gauge, (typically each 1 mm [.004"] thick) by placing it between the face of the wheel and pile seal.

Using the paper, determine if a loose slip fit exist between the pile seal and wheel when the wheel is rotated by hand.

To adjust air seal clearance, loosen all seal plate retaining screws holding the separate seal retaining plates to the bearing support channels and slide the seals plates away from the wheel. Using the paper feeler gauge, readjust and retighten one seal plate at a time to provide slip fit clearance when the wheel is rotated by hand.

Confirm that the wheel rotates freely. Apply power to the unit and confirm rotation. Visually inspect the belt and ensure the belt is tracking near the center of the rim. Verify the wheel speed is approximately 45-50 RPM. Confirm there is no excessive noise such as scraping, brushing, or banging.

Polymer Wheel Orientation & Support

The Energy Recovery Cassette may be mounted in any orientation. However, Care must be taken to make certain that the cassette frame remains flat and the bearing beams are not racked.




Figure 40: Avoid Racking of Cassette Frame

To verify, make certain that the distance between wheel rim and bearing beam is the same at each end of the bearing beam, to within 6.4 mm (1/4") (dimension A & B). This amount of racking can be compensated for by adjusting the diameter seals.

If greater than 1/4 inch (dimension C), racking must be corrected to ensure that drive belt will not disengage from wheel.

Polymer Wheel Startup

Open the access door and determine that the energy recovery wheel rotates freely when turned by hand with no interference noise. Apply power and observe that the wheel rotates. If the wheel does not rotate when power is applied, it may be necessary to readjust the "diameter air seals".

1. By hand, turn wheel clockwise (as viewed from the pulley side), to verify wheel turns freely through 360° rotation.
2. Before applying power to drive motor, confirm wheel segments are fully engaged in wheel frame and segment retainers are completely fastened. (See Segment Installation Diagram).
3. With hands and objects away from moving parts, activate unit and confirm wheel

rotation. Wheel rotates clockwise (as viewed from the pulley side).

4. If wheel has difficulty starting, turn power off and inspect for excessive interference between the wheel surface and each of the four (4) diameter seals. To correct, loosen diameter seal adjusting screws and back adjustable diameter seals away from surface of wheel, apply power to confirm wheel is free to rotate, then re-adjust and tighten hub and diameter seals, as shown in hub seal adjustment diagram.
5. Start and stop wheel several times to confirm seal adjustment and to confirm belt is tracking properly on wheel rim (approximately 6.4 mm [1/4"] from outer edge of rim).




Figure 41: Diameter Seal Adjustment




Figure 42: Hub Seal Adjustment

Controls

A variety of controls and electrical accessories may be provided with the equipment. Identify the controls on each unit by consulting appropriate submittal, or order documents, and operate according to the control manufacturer's instructions. If you cannot locate installation, operation, or maintenance information for the specific controls, then contact your sales representative, or the control manufacturer for assistance.



WARNING

Do not alter factory wiring. Deviation from the supplied wiring diagram will void all warranties, and may result in equipment damage or personal injury. Contact the factory with wiring discrepancies.

Aluminum Wheel Cleaning

See general energy recovering cleaning section for how often to clean.

To clean, gain access to the aluminum energy recovery wheel then use the following methods:

- Use a brush or vacuum cleaner to remove small materials.
- Use compressed air at a distance of at least 0.6 m (2 ft) from the wheel. Too much pressure can easily damage the aluminum media.
- First remove the energy recovery wheel from the unit. Then use water at a distance of at least 0.6 m (2 ft) from the wheel. Do not use detergents. Keep temperature below 25°C (77 F). Tightly cover all electric parts and bearings while used pressurized water. Remove excess water before reinstalling the wheel.

Polymer Energy Recovery Cleaning

To clean, gain access to the polymer energy recovery wheel, remove the segments, then use the following methods:

- Soak in the solution until grease and tar deposits are loosened (Note: some staining of the desiccant may remain and is not harmful to performance).
- Before removing, rapidly run finger across surface of segment to separate polymer strips for better cleaning action.
- Rinse dirty solution from segment and remove excess water before reinstalling in wheel.



CAUTION

Do not use acid based cleaners, aromatic solvents, steam or temperatures in excess of 170°F; damage to the wheel may occur!

Polymer Wheel Segment Installation & Replacement

An uneven number of segments in the wheel will cause the wheel to accelerate in rotation. Minimize wheel imbalance and unwanted rotation during service by installing or removing opposing segments for even weight distribution. Failure to maintain control of the wheel rotation while removing or installing all segments could cause severe injury to fingers or hands. Always close and secure segment retaining latches before rotating wheel.




Figure 43: Wheel Segment Removal Pattern

Wheel segments are secured to the wheel frame by a Segment Retainer which pivots on the wheel rim and is held in place by Segment Retaining Latches.




Figure 44: Segment Retainer

To install wheel segments, follow the steps below. Reverse procedure for segment removal.

1. Disconnect power from the wheel.
2. Gain access to the wheel and slide wheel frame out of cabinet.
3. Unlock two segment retainers (one on each side of the selected segment opening).
4. With the embedded stiffener facing the motor side, insert the nose of the segment between the hub plates.




Figure 45: Segment Installation

5. Holding segment by the two outer corners, press the segment towards the center of the wheel and inwards against the spoke flanges. If hand pressure does not fully seat the segment, insert the flat tip of a screwdriver between the wheel rim and outer corners of the segment and apply downward force while guiding the segment into place.
6. Close and latch each Segment Retainer under Segment Retaining Catch.
7. Slowly rotate the wheel 180°. Install the second segment opposite the first for counterbalance. Rotate the two installed segments 90° to balance the wheel while the third segment is installed. Rotate the wheel 180° again to install the fourth segment opposite the third. Repeat this sequence with the remaining four segments.

Polymer Wheel Air Seals

Four adjustable diameter seals are provided on each cassette to minimize transfer of air between the counter flowing airstreams.

To adjust diameter seals, loosen diameter seal adjusting screws and back seals away from wheel surface. Rotate wheel clockwise until two opposing spokes are hidden behind the bearing support beam. Using a folded piece of paper as a feeler gauge, position paper between the wheel surface and diameter seals.

Adjust seals towards wheel surface until a slight friction on the feeler gauge (paper) is detected when gauge is moved along the length of the spoke. Retighten adjusting screws and recheck clearance with "feeler" gauge.

Polymer Wheel Drive Components

The wheel drive motor bearings are pre-lubricated and no further lubrication is necessary.

The wheel drive pulley is secured to the drive motor shaft by a combination of either a key or D slot and set screw.

The set screw is secured with removable locktite to prevent loosening. Annually confirm set screw is secure. The wheel drive belt is a urethane stretch belt designed to provide constant tension through the life of the belt. No adjustment is required. Inspect the drive belt annually for proper tracking and tension. A properly tensioned belt will turn the wheel immediately after power is applied with no visible slippage during start-up.

Polymer Wheel Drive Motor and Pulley Replacement

1. Disconnect power to wheel drive motor.
2. Remove belt from pulley and position temporarily around wheel rim.
3. Loosen set screw in wheel drive pulley using a hex head wrench and remove pulley from motor drive shaft.
4. While supporting weight of drive motor in one hand, loosen and remove (4) mounting bolts.
5. Install replacement motor with hardware kit supplied.
6. Install pulley to dimension as shown and secure set screw to drive shaft.
7. Stretch belt over pulley and engage in groove.
8. Follow start-up procedure.

Polymer Wheel Belt Replacement

1. Obtain access to the pulley side bearing access plate if bearing access plates are provided. Remove two bearing access plate retaining screws and the access plate.
2. Using hexagonal wrench, loosen set screw in bearing locking collar. Using light hammer and drift (in drift pin hole) tap collar in the direction of wheel rotation to unlock collar. Remove collar.
3. Using socket wrench with extension, remove two nuts which secure bearing housing to the bearing support beam. Slide bearing from shaft. If not removable by hand, use bearing puller.
4. Form a small loop of belt and pass it through the hole in the bearing support beam. Grasp the belt at the wheel hub and pull the entire belt down.

Note: Slight hand pressure against wheel rim will lift weight of wheel from inner race of bearing to assist bearing removal and installation.


CAUTION

Protect hands and belt from possible sharp edges of hole in Bearing Support Beam.

5. Loop the trailing end of the belt over the shaft (belt is partially through the opening).
6. Reinstall the bearing onto the wheel shaft, being careful to engage the two locating pins into the holes in the bearing support beam. Secure the bearing with two self-locking nuts.
7. Install the belts around the wheel and pulley according to the instructions provided with the belt.
8. Reinstall diameter seals or hub seal and tighten retaining screws. Rotate wheel in clockwise direction to determine that wheel rotates freely with slight drag on seals.
9. Reinstall bearing locking collar. Rotate collar by hand in the direction the wheel rotates (see label provided on each cassette for wheel rotation).
10. Lock in position by tapping drift pin hole with hammer and drift. Secure in position by tightening set screw.
11. Reinstall Bearing Access Cover.
12. Apply power to wheel and ensure that the wheel rotates freely without interference.




Figure 46: Belt Replacement

10.3. Energy Recovery Wheel General Cleaning

Routine maintenance of the Energy Recovery Wheel includes periodic cleaning of the Energy Recovery Wheel as well as inspection of the Air Seals and Wheel Drive Components.


CAUTION

Disconnect electrical power before servicing energy recovery cassette. Always keep hands away from bearing support beam when installing or removing segments. Failure to do so could result in severe injury to fingers or hand.

Cleaning the energy transfer media will help maintain optimal performance. The frequency of cleaning is largely dependent on the application and air quality. Use ASHRAE's Classes of Air categories, to create a routine cleaning schedule.

Class 1 air has low contaminant concentration with inoffensive odor and sensory irritation intensity.

Class 2 air has moderate contaminant concentration, with mildly offensive odors or sensory-irritation intensity.

Class 3 air has significant contaminant concentration and significant offensive odor or sensory-irritation intensity.

Class 4 air has highly objectionable fumes or gases and potentially contains dangerous particles, bio-aerosols, or gases at a concentration high enough to be considered harmful, not suitable for recirculation or transfer to any other space.

Table 24: Energy Recovery Wheel Cleaning Information

Class of Air	Examples	Cleaning Frequency
Class 1 Clean Air	<ul style="list-style-type: none"> Offices Classrooms Assembly rooms Churches 	Every 8-10 years
Class 2 Moderately Clean Air	<ul style="list-style-type: none"> Restrooms Swimming pools Dining rooms Locker rooms Warehouse Dorms 	Every 4-6 years
Class 3 Dirty Air	<ul style="list-style-type: none"> Kitchens Dry cleaners Beauty salons Laboratories Pet shops 	Every 1-2 years
Class 4 Contaminated Air	<ul style="list-style-type: none"> Paint spray booths Laboratory fume exhaust Kitchen grease exhaust 	Do not use in this application

The energy recovery wheel is "self-cleaning" with respect to dry particles due to its laminar flow characteristics. Smaller particles pass through; larger particles land on the surface and are blown clear as the flow direction is reversed. Any material that builds up on the face of the wheel can be removed with a brush or vacuum. The primary need for cleaning is to remove oil based aerosols that have condensed on energy transfer surfaces.

A characteristic of all dry desiccants, such films can close off micron sized pores at the surface of the desiccant material, reducing the efficiency by which the desiccant can adsorb and desorb moisture and also build up so as to reduce airflow.

In a reasonably clean indoor environment such as a school or office building, measurable reductions of airflow or loss of sensible (temperature) effectiveness may not occur for several years. Measurable changes in latent energy (water vapor) transfer can occur in shorter periods of time in applications such as moderate occupant smoking or cooking facilities. In applications experiencing unusually high levels of occupant smoking or oil based aerosols such as industrial applications involving the ventilation of machine shop areas for example, annual washing of energy transfer may be necessary to maintain latent transfer efficiency. Proper cleaning of the energy recovery wheel will restore latent effectiveness to near original performance.



Figure 47: H3 A Or B Cabinet Energy Recovery Wheel
H3 Size A & B Return Air Filters - Access Through Top And Bottom Of The Filter Box.




Figure 48: H3 A Or B Cabinet Outside Air Filter Access
H3 Size A & B Outside Air Filters - Access Through Removing The Sheet Metal Piece Shown Above.




Figure 49: H3 C Cabinet Energy Recovery Wheel




Figure 50: H3 size C return air filters - access through top and left side of the filter box.



Figure 52: H3 D or E Cabinet Energy Recovery Wheel

H3 size D or E return air filters & outside air filters - access by removing the energy recovery wheel access panel.



Figure 51: H3 C Cabinet Outside Air Filter Access

H3 size C outside air filters - access through removing the sheet metal piece shown above, and removing another sheet metal piece once inside.

11. GAS AND ELECTRIC HEATING

The unit is designed to heat a given amount of air while operating. If this amount of air is greatly reduced, approximately 1/3 during the heating season, the electric heating coil may overheat, and may cut the heater off entirely by action of the safety high temperature limit devices which are factory mounted at the heat exchanger and supply fan areas.

Adjust airflow after installation to obtain an air temperature rise within the range specified on the unit rating plate at the required external static pressure.

The tested minimum and maximum range of static pressure for the H3 is 0.4 – 5.6 mmHg [electric is 0.2 – 3.0 in. w.c]. The maximum supply air temperature is 60°C (140°F). The minimum allowable air temperature entering the gas heater is -40 °C (-40°F).

Table 25: Heat Capacity Chart

	Electric Heat Capacity		Gas Heat Input Capacity	
	kW (230V, 460V)	kW (208V)	MBH	Unit Size
A = Heat A	7.0	5.3		
B = Heat B	14.0	10.5		
C = Heat C	21.0	15.8	50 MBH	H3/V3-A, B
D = Heat D	28.0	21.0		
E = Heat E	35.0	26.3		
F = Heat F	42.0	31.5		
G = Heat G	49.0	37.0	90 MBH	H3/V3-A, B, C
H = Heat H	56.0	42.0	100 MBH	H3/V3-A, B
J = Heat J	63.0	47.3	125 MBH	V3-C
K = Heat K	70.0	52.5		
L = Heat L			150 MBH	H3-C, D V3-D
M = Heat M	84.0	63.0	180 MBH	H3-D V3-C, D
N = Heat N			225 MBH	H3-C, D, E V3-E
P = Heat P			200 MBH	H3-D V3-C, D
Q = Heat Q			250 MBH	H3-C, D V3-E
R = Heat R			360 MBH	H3-E V3-D, E
S = Heat S			400 MBH	H3-E V3-D, E
T = Heat T			300 MBH	H3-E

12. GAS HEATING



WARNING

For Your Safety

Read the entire gas heating installation section of this manual before beginning installation of the gas heating section.

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

12.1. Unit Location and Clearances

1. Be sure unit is located with respect to building construction and other equipment to provide ready access and clearance to access panels or doors that must be opened to permit adjustment and servicing of the heating module.
2. The heating unit provided is listed for installation on the positive side of the circulating air blower only.
3. Locate unit to insure an adequate supply of fresh air to replace air used in the combustion and ventilation process.
4. Do not install exhaust vent where flue products can be drawn into adjacent building openings such as windows, doors, or fresh air intakes. Minimize the number of elbows or turns in vent pipe.
5. Do not install unit where it may be exposed to potentially explosive or flammable vapors.
6. Do not locate unit in areas where corrosive vapors (such as chlorinated, halogenated, or acidic) are present in the atmosphere or can be mixed with combustion air entering heater.

Gas-Fired Heating

The Heatco gas-fired duct furnace is designed to heat a given amount of air while operating. Adjust airflow after installation to obtain an air temperature rise within the range specified on the unit rating plate at the required external static pressure.

For all installation, operation, and maintenance information, refer to the Heatco IOM.

Table 26: Unit Clearance Requirements

Model / Rated Input	H3/V3 Cabinet	Min. Rise	Max. Rise
HDG050	H3-A, B V3-A, B	30	90
HDG100	H3-A, B V3-A, B		
HDG125	V3-C		
HDG200	H3-E x 2 V3-C		
HDA150	H3-C, D V3-D	30	100
HDA200	H3-D V3-D		
HDA250	H3-C, D V3-E		
HDA400	V3-D, E		
HDB225	H3-E	30	90
HDB300	H3-E		
EMG090	H3-A, B, C V3-A, B, C	30	100
EMG180	H3-E x 2 V3-C		
EMA180	H3-D V3-D	30	100
EMA225	H3-C, D, E V3-E		
EMA360	V3-D, E		

Input

The correct heat capacity of the furnace is controlled by the burner orifices and the gas manifold pressure. The manifold pressure is factory set but must be checked at the time of start-up.

The unit's nameplate input rate value is calculated based on the altitude where the unit was shipped. Units installed at an elevation less than 610 meters (2000 feet) above sea level require no derating. At 610 meters (2000 feet) above sea level, a 4% derate adjustment must be applied to the standard input rate. For every additional 305 meters (1000 feet), there is an additional 4% derate adjustment.

For example, at 914 meters (3000 feet) above sea level, the derate adjustment for elevation would be 8%, resulting in a new heat exchanger rate of 92% of the standard input rate listed.

Piping Supports

Gas supply piping must be supported directly at the connection to the unit and at intervals listed in the following table with metal straps, blocks, or hooks. Piping must not be strained or bent.

Table 27: Gas Piping Supports (Metric)

Pipe Size (mm)	Support Intervals
12.7 to 19.1	Every 1.8 m
19.1 to 25.4	Every 2.4 m
44.5 or Larger (Horizontal)	Every 3 m
31.8 or Larger	Every Floor

Table 28: Gas Piping Supports (Imperial)

Pipe Size	Support Intervals
1/2" to 3/4"	Every 6 ft
3/4" to 1"	Every 8 ft
1-3/4" or Larger (Horizontal)	Every 10 ft
1-1/4" or Larger (Vertical)	Every Floor

12.2. Leak Testing

All components of gas supply system, including manual shut off valves and the piping in the interior of the unit, must be leak tested with a soap solution before operating the appliance and at least on an annual basis thereafter.

WARNING

Gas pressure to appliance controls must never exceed 14" w.c. (1/2 psi)

1. When pressure testing at 1/2 psi or less, close the manual shutoff valve on the appliance before testing.
2. When pressure testing gas supply line at 1/2 psi or higher, close manual gas valve and disconnect heater from supply line to be tested. Cap or plug the supply line.


DANGER

Leak Check Gas Pipe

The gas pipe in the unit shall be checked for leaks before operation and startup. Unit must not be placed in operation until a leak check has been conducted for all gas piping connections. All connections shall be checked for leaks annually after installation. Gas leaks could result in fire, explosion, or other hazardous situations.

CAUTION

Some soaps used for leak detection can be corrosive to certain metals. Rinse piping thoroughly after leak test has been completed.



12.3. Phase and Brownout Protection Module




Figure 53: PBO


The PBO-3P-T monitors line voltages from 200VAC to 575VAC 3 ϕ . The PBO-3P-T must be wired according to unit specific wiring diagram included in the control compartment.

output relay will be de-energized after the trip

UV Lights

Some units include UV lights for airstream disinfection. The UV fixture is installed directly downstream of cooling coil. Door interlock switches are provided with this option.

UV lamps ship loose in the vestibule and require installation during startup. Useful lamp life shall be 9000 hours (minimum) with no more than a 15% output loss at the end of the lamps life. Use AAON Part # R68850 for lamp replacement.



13. FILTER REPLACEMENT

Monthly filter inspection is required to maintain optimum unit efficiency.



WARNING

Electric shock hazard. Shut off all electrical power to the unit to avoid shock hazard or injury from rotating parts.

It is strongly recommended that filter media be replaced monthly. Filters are located upstream of the evaporator coil. Open access panel and pull filters straight out to inspect all of the filters. Replace filters with the size indicated on each filter. Arrow on the replacement filters must point towards the blower. Units with an energy recovery wheel have additional filters. See the Filter replacement section under the energy recover wheel section for more information.



14. REPLACEMENT PARTS

Parts for AAON equipment may be obtained from your local representative <https://www.aaon.com/find-a-rep>. When ordering parts, reference the unit serial number and part number.

AAON
Warranty, Service and Parts Department
203 Gum Springs Rd.
Longview, TX 75602
Ph: (918) 382-6450
techsupport@AAON.com
www.AAON.com

Note: Before calling, technician must have model and serial number of the unit available for the service department to help answer questions regarding the unit.

15. DECOMMISSIONING

Before decommissioning unit, ensure you are familiar with the unit and its operation. Only individuals qualified for handling refrigerant may remove charge from the unit. Unit must be isolated electrically before beginning any decommissioning work. Proper PPE is required

Ensure any equipment that may be needed for handling refrigerant cylinders safely is available. Equipment and cylinders used for recovery must be in good working order and comply with appropriate standards.

Operate recovery machine in accordance with the instructions. Remove refrigerant from all parts of the refrigeration system. On heat pumps, refrigerant must be recovered from discharge, suction and common liquid lines.

Weigh out refrigerant when removing to ensure that all refrigerant is removed and cylinders are not overfilled. Place refrigerant cylinder on scales before beginning recovery process. Do not exceed maximum pressure of cylinder.

When recovery is completed, remove all cylinders containing recovered refrigerant from the site. Ensure all isolation valves on equipment are closed and all warning decals are still visible on unit. Label the unit as having been decommissioned and date and sign label.

16. WARRANTY

Refer to the Limited Warranty Certificate for the unit warranty details. Contact your AAON representative for a unit specific copy of the certificate for your serial number.

Limited Warranty Certificate

GENERAL CONDITIONS

AAON Coil Products, Inc. (hereinafter referred to as "ACP") warrants this ACP equipment, as manufactured, to be free from defects in material and workmanship for a period of one (1) year from date of original installation or use, except for the following. All warranties, express and implied, and obligations under this warranty must be limited to repairing or replacing the defective part or parts. The original purchase-user's sole obligation under this warranty must be limited to repairing or replacing the defective part or parts. ACP is not liable for labor charges or other costs incurred for removing, shipping, handling or transporting defective part or parts required to repair or replace the defective part or parts. The original purchase-user, or parts.

The limited warranty is effective one (1) year from date of original installation, or eighteen (18) months from date of original shipment from the factory, whichever occurs first and covers all parts and components in the original purchase-user's equipment. This limited warranty does not cover parts and components which are subject to normal wear and loss of refrigerant, which are not included in any part of this limited warranty. The original purchase-user is responsible for the removal of the original limited warranty and are shipped to the factory. The factory and freight prepared by the factory.

The limited warranty is effective for products manufactured at the Tulsa, Oklahoma, or Carrollton, Texas facility.

The limited warranty is not effective for products manufactured at the Tulsa, Oklahoma, or Carrollton, Texas facility.

THIS LIMITED WARRANTY ONLY APPLIES WHEN THE ORIGINAL MODEL NUMBER AND SERIAL NUMBER OF THE ACP UNIT ARE OWNED BY THE ORIGINAL PURCHASE-USER AND NOT BY A RETAILER OR PARTS DEALER. DEFECTIVE PART, OR PARTS, MUST BE RETURNED WITHIN FORTY-FIVE (45) DAYS OF RECEIPT OF THE REPAIR/REPLACEMENT PART OR PARTS.

EXTENDED LIMITED WARRANTY ON COMPRESSORS PROVIDED IN SMALL CAPACITY EQUIPMENT, NOT INCLUDING CHILLED WATER, IS OPTIONAL ON OTHER EQUIPMENT

For the extended limited warranty on the first year of shipment, an buyer agrees to repair or replace the full helical compressor, at our option, for the original purchase-user only. The repaired or replaced full helical compressor will be shipped to the original purchase-user at no cost to the original purchase-user. The repaired or replaced full helical compressor is repaired/replaced with a full helical compressor of the same model number and part number. This extended limited warranty covers all parts and components in materials or workmanship. This extended limited warranty does not include additional costs incurred for shipping, handling, transporting, or repairing the full helical compressor. This extended limited warranty does not include additional costs incurred for shipping, handling, transporting, or repairing of electric controls such as relays, capacitors, pressure controls, or starters. The original purchase-user is responsible for the standard one-year limited warranty.

EXTENDED LIMITED WARRANTY OF MOVING SERIES GAS FIRED HEAT EXCHANGERS

For the second through the year after first date of original installation, we further warrant the steel heat exchanger against failure due to defects in materials and workmanship for the original purchase-user only, in normal use and service. The original purchase-user must return the heat exchanger, or parts, to the factory for repair or replacement. The original purchase-user must pay the shipping charges for the return of the heat exchanger. We agree to repair or replace the heat exchanger, at our option, for the original purchase-user. The original purchase-user will pay 50% of the current list price for repairing/replacing the steel heat exchanger, as the heat exchanger, during the seventh year, 60%, during the eighth year, 70%, and during the ninth year, 90%.

In the event, the repairer or replacement heat exchanger will be supplied in full, our factory freight paid, providing the defective heat exchanger is returned prepared, and it is proved to be defective due to defects in materials and workmanship. The original purchase-user must pay the shipping charges for the return of the heat exchanger and does not include labor charges, or other costs incurred for removing, shipping, handling, transporting, or repairing the heat exchanger. This extended warranty does not apply where the furnace has been operated in an atmosphere contaminated by chlorine, fluorine, or any other damaging chemical compounds.

OPTION FOR FIFTEEN YEAR EXTENDED LIMITED WARRANTY OF COOLING COILS

For the second through fifth year from date of shipment, we further warrant the cooling of e-coated coils on the equipment to the original purchase-user only. The repaired or replaced cooling coil must be repaired/replaced with a cooling coil of the same model number and part number. The original purchase-user must pay the shipping charges for the return of the cooling coil. Cool cleaning, maintenance, and record keeping must be followed by the original purchase-user. (See Installation, Operation and Maintenance Manual to maintain warranty).

OTHER CONDITIONS

The original purchase-user may not cover any ACP unit or part therewith which has been subjected to abuse, negligence, damage in transit, misuse or abuse, or which has been tampered with in any way, or which has not been properly serviced and maintained in accordance with our instructions, or which has been installed outside of the Continental United States. The original purchase-user must pay the shipping charges if the number has been altered, defaced, or removed. ACP will not be liable for damage to the original purchase-user's property, including but not limited to, fire, explosion, water damage, lightning damage, wind damage, hail damage, ice damage, power outages, power surges, power spikes, open circuit breakers, or other damages due to the inadequacy or interruption of electric service.

This warranty does not cover equipment containing a water-cooled coil or heat exchanger which has suffered damage resulting from freezing, flooding, corrosion or clogging.

ACP must not be liable for any defect or delay in performance resulting, caused by a contingency beyond our control, including governmental restrictions or restraint, strikes, short or reduced supply of raw materials or parts, floods, winds, fire, lightning strikes, or any other acts of God.

1 of 2

Table 29: H3 Series A Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(1) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G	(1) 40.6 x 63.5 x 5.1 and (1) 40.6 x 63.5 x 10.2 [16 x 25 x 2 and 16 x 25 x 4]	Pleated MERV 8 and Pleated MERV 11
H		Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 30: H3 Series B Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(2) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G	(2) 40.6 x 50.8 x 5.1 and (2) 40.6 x 50.8 x 10.2 [16 x 20 x 2 and 16 x 20 x 4]	Pleated MERV 8 and Pleated MERV 11
H		Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 31: H3 Series C Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(2) 50.8 x 50.8 x 5.1 and (1) 40.6 x 50.8 x 5.1 [20 x 20 x 2 and 16 x 20 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F	(2) 50.8 x 50.8 x 5.1 and (1) 40.6 x 50.8 x 5.1 and	Pleated MERV 8 and Pleated MERV 8
G	(2) 50.8 x 50.8 x 10.2 and (1) 40.6 x 50.8 x 10.2 [20 x 20 x 2 and 16 x 20 x 2]	Pleated MERV 8 and Pleated MERV 11
H	and [20 x 20 x 4 and 16 x 20 x 4]	Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 32: H3 Series D Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(1) 50.8 x 50.8 x 5.1 and (4) 40.6 x 50.8 x 5.1 [20 x 20 x 2 and 16 x 20 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F	(1) 50.8 x 50.8 x 5.1 and (4) 40.6 x 50.8 x 5.1 and	Pleated MERV 8 and Pleated MERV 8
G	(1) 50.8 x 50.8 x 10.2 and (4) 40.6 x 50.8 x 10.2 [20 x 20 x 2 and 16 x 20 x 2]	Pleated MERV 8 and Pleated MERV 11
H	and [20 x 20 x 4 and 16 x 20 x 4]	Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 33: H3 Series E Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(6) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G	(6) 40.6 x 63.5 x 5.1 and (6) 40.6 x 63.5 x 10.2 [16 x 25 x 2 and 16 x 25 x 4]	Pleated MERV 8 and Pleated MERV 11
H		Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 34: H3 Series A Cabinet Final Filters

Feature 6C	Qty. Size (cm) [in.]	Type
0	No Final Filters	
A	(1) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B		Cartridge MERV 11
C		Cartridge MERV 13
D		Cartridge MERV 14
E		Pleated MERV 8 and Cartridge MERV 11
F	(1) 40.6 x 63.5 x 5.1 and 40.6 x 63.5 x 30.5 [16 x 25 x 2 and 16 x 25 x 12]	Pleated MERV 8 and Cartridge MERV 13
G		Pleated MERV 8 and Cartridge MERV 14

Table 35: H3 Series B Cabinet Final Filters

Feature 6C	Qty. Size (cm) [in.]	Type
0	No Final Filters	
A	(2) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated MERV 8
B		Cartridge MERV 11
C		Cartridge MERV 13
D		Cartridge MERV 14
E		Pleated MERV 8 and Cartridge MERV 11
F		Pleated MERV 8 and Cartridge MERV 13
G		Pleated MERV 8 and Cartridge MERV 14

Table 36: H3 Series C Cabinet Final Filters

Feature 6C	Qty. Size (cm) [in.]	Type
0	No Final Filters	
A	(2) 50.8 x 50.8 x 5.1 and (1) 40.6 x 50.8 x 5.1 [20 x 20 x 2 and 16 x 20 x 2]	Pleated MERV 8
B		Cartridge MERV 11
C		Cartridge MERV 13
D		Cartridge MERV 14
E	(2) 50.8 x 50.8 x 5.1 and (1) 40.6 x 50.8 x 5.1 and	Pleated MERV 8 and Cartridge MERV 11
F	(2) 50.8 x 50.8 x 30.5 and (1) 40.6 x 50.8 x 30.5 [20 x 20 x 2 and 16 x 20 x 2] and	Pleated MERV 8 and Cartridge MERV 13
G	[20 x 20 x 12 and 16 x 20 x 12]	Pleated MERV 8 and Cartridge MERV 14

Table 37: H3 Series D Cabinet Final Filters

Feature 6C	Qty. Size (cm) [in.]	Type
0	No Final Filters	
A	(4) 50.8 x 50.8 x 5.1 [20 x 20 x 2]	Pleated MERV 8
B		Cartridge MERV 11
C		Cartridge MERV 13
D		Cartridge MERV 14
E		Pleated MERV 8 and Cartridge MERV 11
F		Pleated MERV 8 and Cartridge MERV 13
G		Pleated MERV 8 and Cartridge MERV 14

Table 38: H3 Series E Cabinet Final Filters

Feature 6C	Qty. Size (cm) [in.]	Type
0	No Final Filters	
A	(6) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B		Cartridge MERV 11
C		Cartridge MERV 13
D		Cartridge MERV 14
E		Pleated MERV 8 and Cartridge MERV 11
F		Pleated MERV 8 and Cartridge MERV 13
G		Pleated MERV 8 and Cartridge MERV 14

Table 39: H3 Series Energy Recovery OA Filters (Feature 13 ≠ 0)

Unit Size	Qty. Size (cm) [in.]	Type
A	(1) 70 x 30.5 x 5.1 [24 x 12 x 2]	Pleated MERV 8
B	(1) 50.8 x 63.5 x 5.1 [20 x 25 x 2]	Pleated MERV 8
C	(2) 70 x 70 x 5.1 [24 x 24 x 2]	Pleated MERV 8
D	(4) 40.6 x 50.8 x 5.1 (1) 50.8 x 50.8 x 5.1 [16 x 20 x 2] [20 x 20 x 2]	Pleated MERV 8
E	(6) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8

Table 40: H3 Series Energy Recovery RA Filters (Feature 13 ≠ 0)

Unit Size	Qty. Size (cm) [in.]	Type
A	(1) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated MERV 8
B	(1) 50.8 x 63.5 x 5.1 [20 x 25 x 2]	Pleated MERV 8
C	(2) 50.8 x 63.5 x 5.1 [20 x 25 x 2]	Pleated MERV 8
D	(4) 40.6 x 50.8 x 5.1 (1) 50.8 x 50.8 x 5.1 [16 x 20 x 2] [20 x 20 x 2]	Pleated MERV 8
E	(6) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8

Table 41: V3 Series A Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(1) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G		Pleated MERV 8 and Pleated MERV 11
H	(1) 40.6 x 63.5 x 5.1 and (1) 40.6 x 63.5 x 10.2 [16 x 25 x 2 and 16 x 25 x 4]	Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 42: V3 Series B Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(1) 61 x 61 x 5.1 [24 x 24 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G		Pleated MERV 8 and Pleated MERV 11
H	(1) 61 x 61 x 5.1 and (1) 61 x 61 x 10.2 [24 x 24 x 2 and 24 x 24 x 4]	Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 43: V3 Series C Cabinet Unit Filters

Feature 6B	Qty. Size (cm) [in.]	Type
0	No Pre Filters	
A	(4) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated MERV 8
B		Pleated MERV 8
C		Pleated MERV 11
D		Pleated MERV 13
E		Pleated MERV 14
F		Pleated MERV 8 and Pleated MERV 8
G		Pleated MERV 8 and Pleated MERV 11
H		Pleated MERV 8 and Pleated MERV 13
J		Pleated MERV 8 and Pleated MERV 14

Table 44: V3 Series D Cabinet Unit Filters

Feature 6B	(Qty.) Size (cm) [in.]	Type
0	No Unit Filters	
A	(4) 45.7 x 61 x 5.1 [18 x 24 x 2]	Pleated, MERV 8
B		Pleated, MERV 8
C		Pleated, MERV 11
D		Pleated, MERV 13
E		Pleated, MERV 14
F		Pleated, MERV 8 and Pleated, MERV 8
G		Pleated, MERV 8 and Pleated, MERV 11
H		Pleated, MERV 8 and Pleated, MERV 13
J		Pleated, MERV 8 and Pleated, MERV 14

Table 45: V3 Series E Cabinet Unit Filters

Feature 6A	(Qty.) Size (cm) [in.]	Type
0	No Unit Filters	
A	(6) 45.7 x 61 x 5.1 [18 x 24 x 2]	Pleated, MERV 8
B		Pleated, MERV 8
C		Pleated, MERV 11
D		Pleated, MERV 13
E		Pleated, MERV 14
F		Pleated, MERV 8 and Pleated, MERV 8
G		Pleated, MERV 8 and Pleated, MERV 11
H	(6) 45.7 x 61 x 5.1 and (6) 45.7 x 61 x 10.2 [18 x 24 x 2 and 18 x 24 x 4]	Pleated, MERV 8 and Pleated, MERV 13
J		Pleated, MERV 8 and Pleated, MERV 14

Table 46: V3 Series A Cabinet Final Filters

Feature 6C	(Qty.) Size (cm) [in.]	Type
0	No Final Filters	
H		Pleated, MERV 8
J		Pleated, MERV 11
K		Pleated, MERV 13
L		Pleated, MERV 14

Table 47: V3 Series B Cabinet Final Filters

Feature 6C	(Quantity) Size	Type
0	No Final Filters	
H		Pleated, MERV 8
J		Pleated, MERV 11
K		Pleated, MERV 13
L		Pleated, MERV 14

Table 48: V3 Series C Cabinet Final Filters

Feature 6C	(Qty.) Size (cm) [in.]	Type
0	No Final Filters	
H		Pleated, MERV 8
J		Pleated, MERV 11
K		Pleated, MERV 13
L	[20 x 25 x 4]	Pleated, MERV 14

Table 49: V3 Series Energy Recovery OA Filters (Feature 13 = A-V)

Unit Size	Qty. Size (cm) [in.]	Type
A	(1) 40.6 x 63.5 x 5.1 [16 x 25 x 2]	Pleated MERV 8
B	(1) 61 x 61 x 5.1 [24 x 24 x 2]	Pleated MERV 8
C	(4) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated MERV 8
D	(4) 45.7 x 61 x 5.1 [18 x 24 x 2]	Pleated, MERV 8
E	(8) 40.6 x 50.8 x 5.1 [16 x 20 x 2]	Pleated, MERV 8

Refrigerant Piping Diagrams

See the matching Condensing Unit IOM for Piping Diagrams

17. H3 SERIES STARTUP FORM

Job Name:	Date
Address:	
Model Number:	
Serial Number:	Tag:
Startup Contractor:	
Address:	
	Phone:

17.1. Pre Startup Checklist

Installing contractor must verify the following items.	
1. Is there any visible shipping damage?	
2. Is the unit level?	
3. Are the unit clearances adequate for service and operation?	
4. Do all access doors open freely and are the handles operational?	
5. Have all shipping braces been removed?	
6. Have all electrical connections been tested for tightness?	
7. Does the electrical service correspond to the unit nameplate?	
8. On 208/230V units, has transformer tap been checked?	
9. Has overcurrent protection been installed to match the unit nameplate requirement?	
10. Have all set screws on the fans been tightened?	
11. Do all fans rotate freely?	
12. Does the field water piping to the unit appear to be correct per design parameters?	
13. Is all copper tubing isolated so that it does not rub?	
14. Have the damper assemblies been inspected?	
15. Are air filters installed with proper orientation?	
16. Have condensate drain and p-trap been connected?	
17. Is the TXV sensing bulb in the correct location?	
18. Does the TXV sensing bulb have proper thermal contact and is properly insulated?	
19. Are all ship-loose components and cabinets (if applicable) installed per unit drawing and wiring diagram.	
20. Is the actual refrigerant charge of the largest circuit in accordance with the required conditioned floor area according to Table 18, Table 19, Table 20?	
21. Are ventilation and exhaust openings unobstructed?	
22. Are markings, decals, and warnings on unit clearly visible?	
23. Are all damaged or illegible markings and warnings replaced?	
24. Has the functionality of the Refrigerant Detection System been verified?	

17.2. Ambient Temperature

Ambient Dry Bulb Temperature _____ °C/°F	Ambient Wet Bulb Temperature _____ °C/°F
--	--

17.3. Voltage

L1-L2	L2-L3	L1-L3	L1-Ground	L2-Ground	L3-Ground

17.4. Supply Fan Assembly

Alignment	<input type="checkbox"/>	Check Rotation	<input type="checkbox"/>	Nameplate Amps _____
Number	hp	L1 Volts/Amps	Number	hp
1			1	
2			2	
VFD Frequency _____			VAV Controls _____	

17.5. Energy Recovery Wheel Assembly

Wheels Spin Freely	<input type="checkbox"/>	Check Rotation	<input type="checkbox"/>	FLA _____
Number	hp	L1 Volts/Amps	L2 Volts/Amps	L3 Volts/Amps
1				

17.6. Dampers

OA Operation Check	<input type="checkbox"/>	Damper Wiring Check	<input type="checkbox"/>	Gears Check	<input type="checkbox"/>
RA Operation Check	<input type="checkbox"/>	Damper Wiring Check	<input type="checkbox"/>	Gears Check	<input type="checkbox"/>
EA Operation Check	<input type="checkbox"/>	Damper Wiring Check	<input type="checkbox"/>	Gears Check	<input type="checkbox"/>
Damper Actuator Type: _____					
Economizer Changeover Type and Operation: _____					

17.7. Refrigeration System 1 - Cooling Mode

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.8. Refrigeration System 2 - Cooling Mode

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.9. Refrigeration System 3 - Cooling Mode

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.10. Refrigeration System 4 - Cooling Mode

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.11. Compressors/DX Cooling

Check Rotation <input type="checkbox"/>						
Number	L1 Volts/Amps	L2 Volts/Amps	L3 Volts/Amps	Head Pressure KPA/PSIG	Suction Pressure KPA/PSIG	Crankcase Heater Amps
1						
2						
3						
4						

17.12. Air-Cooled Condenser Fans

Alignment <input type="checkbox"/>		Check Rotation <input type="checkbox"/>		Nameplate Amps _____	
Number	hp	L1 Volts/Amps	L2 Volts/Amps	L3 Volts/Amps	
1					
2					
3					
4					

17.13. Refrigeration System 1 - Heating Mode (Heat Pump Only)

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.14. Refrigeration System 2 - Heating Mode (Heat Pump Only)

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat

Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.15. Refrigeration System 3 - Heating Mode (Heat Pump Only)

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.16. Refrigeration System 4 - Heating Mode (Heat Pump Only)

	Pressure	Saturated Temperature	Line Temperature	Sub-cooling	Superheat
Discharge				N/A	N/A
Suction				N/A	
Liquid					N/A

17.17. Water/Glycol System

1. Has the entire system been flushed and pressure checked?	
2. Has the entire system been filled with fluid?	
3. Has air been bled from the heat exchangers and piping?	
4. Is the glycol the proper type and concentration (N/A if water)?	
5. Is there a minimum load of 50% of the design load?	
6. Has the water piping been insulated?	
7. What is the freeze point of the glycol (N/A if water)? _____	

17.18. Electric Heating

Stages _____		Limit Lockout <input type="checkbox"/>		Aux. Limit Lockout <input type="checkbox"/>	
Stage	Amps	Stage	Amps		
1		5			
2		6			
3		7			
4		8			

17.19. Gas Heating

1. Does the unit include a shipped loose Heatco gas heater? Refer to provided Heatco IOM for all installation requirements.	
--	--

17.20. A2L Mitigation Board

1. Does each port (sensor 1-3) have a male connector plugged in on both the Cabinet and Airstream board?	
2. Do the compressor(s) and gas heat operation shut off when the Cabinet Board is in the alarm state?	
3. Does the unit operate normally except compressor and gas heat operation when the Cabinet Board is in the alarm state?	
4. Do the compressor(s) shut off and fan(s) stay on when the Airstream Board is in the alarm state?	
5. Does non-compressor or gas heating/cooling stay on when both A2L Mitigation boards are in the alarm state?	

18. APPENDIX A: UNIT SAFETY HIERARCHY




Figure 54: Unit Safety Hierarchy

Default (A2L Priority)

Units will ship with A2L sequences at the highest priority. This may activate the indoor blower in the event of an A2L leak, even if Building Smoke Controls or Non-smoke safeties interrupt the 24V/120V safety circuit. The terminal block labeled 'Hierarchy Control' will control the priority.

The jumper will connect 'Com' and 'A2L' for A2L priority.




Figure 55: A2L Priority Jumper

Building Smoke Control Priority

Units will have the option to shift the Unit Safety Hierarchy in the field. To shift the priority, turn the power off to the unit and move the jumper to 'Com' and 'BSC' on the 'Hierarchy Control' terminals.




Figure 56: Building Smoke Control Priority Jumper

Example Scenario

If priority is given to Building Smoke Controls, and simultaneously both A2L and any of the Building Smoke Controls goes into alarm, the 24V/120V safety circuit will shut down the unit, and A2L mitigation will not take place.

Locating the "Hierarchy Control" LVTB

Locate the low voltage control section

Identify the 'Hierarchy Control' label by the (3) terminals labeled "BSC", "COM", and "A2L"

19. APPENDIX B: MAINTENANCE LOG

This log must be kept with the unit. It is the responsibility of the owner and/or maintenance/service contractor to document any service, repair or adjustments. AAON Service and Warranty Departments are available to advise and provide phone help for proper operation and replacement parts. The responsibility for proper startup, maintenance and servicing of the equipment falls to the owner and qualified licensed technician.

19.1. Maintenance Log (E-Coated Coil)

AAON E-COATED COIL MAINTENANCE RECORD

Installation Site		Installation Date	
Unit Model #		Unit Location	
Unit Serial #		Customer	
Year 20	Ambient Temp (°F)	Surface Debris Removed	Approved Cleaner Used
Jan			
Feb			
Mar			
Apr			
May			
Jun			
Jul			
Aug			
Sep			
Oct			
Nov			
Dec			

The following cleaning agents have been approved for use on AAON E-Coated Coils to remove mold, mildew, dust, soot, greasy residue, lint and similar particulate without harming the coated surfaces.

RECOMMENDED CHLORIDE REMOVER	
Rectorseal	2601 Spennwick Drive, Houston, Texas (P): 713-263-8001
	2601 Spennwick Drive, Houston, Texas (P): 713-263-8001

CLEANING AGENT	SELLER	PART NUMBER
GulfClean™ Coil Cleaner or Enviro-Coil Cleaner	Rectorseal 2601 Spennwick Drive, Houston, Texas (P): 713-263-8001	G074480 / 80406 or V82540
GulfClean Salt Reducer™	" "	G074480 / 80408

20. LITERATURE CHANGE HISTORY

September 2022

New H3 Series IOM.

May 2023

Added metric conversions equivalents in text and tables. Added new warning labels. Added safety statements. Added KAIC tables for fuse sizing. Removed gas heating information.

October 2023

Added statement 1 about V3 clearances tables. Added they must consider combustible and non-combustible surfaces. Add statement about PARTIAL UNIT AIR CONDITIONERS in section after warning boxes. Added statement in electric heat section about the tested min and max static pressures are between 0.2 – 4.0 inH2O.

April 2024

Additional warnings added. Text added to installation section about proper ventilation requirements. Minimum Floor Area for charge table added. Added "Refrigerant Detection System" for new mitigation board for A2L refrigerant. Additional checklist items added to Startup form. Sentence added to storage section in regards to ASHRAE 15 requirements. Added section about proper Refrigerant removal and Evacuation.

July 2024

Added text for UV lights and lamp replacement part number. Added text to the RDS section about the "COMP" relay if paired to a condensing unit.

August 2024

Added process of Decommissioning the unit. Added text to General Information stating the maximum installation elevation is 11,500 ft.

September 2024

Added details to the RDS text for the mitigation board operation.

October 2024

Created 454B part number. Added plenum fan gap tolerances to supply fan section.

January 2025

Updated decommissioning section. Updated RDS section, updated startup form. Updated Warnings and caution section.

November 2025

Updated Heating section to reflect Heatco products. Updated Features B1,B2, 1A, 1B, 1C, 3, 8, 15, 19; added Unit Safety Hierarchy Appendix



AAON
203 Gum Springs Road
Longview, TX 75602-1721
Phone: 903-236-4403
Fax: 903-125-4463
www.AAON.com

H3/V3 Installation, Operation,
and Maintenance
R94190 · Rev. E · 20251126
(ACP 30585)

It is the intent of AAON to provide accurate and current product information. However, in the interest of product improvement, AAON reserves the right to change pricing, specifications, and/or design of its product without notice, obligation, or liability.

Copyright © AAON, all rights reserved throughout the world.

AAON® and AAONAIR® are registered trademarks of AAON, Inc., Tulsa, OK.